



Manuals.plus /

› Vivilumens /

› Vivilumens Bedside Table LED Night Light User Manual

Vivilumens S22

Vivilumens Bedside Table LED Night Light

Model: S22
User Manual

INTRODUCTION

Thank you for choosing the Vivilumens Bedside Table LED Night Light. This versatile device combines a dimmable LED night light, a wireless phone charger, a Bluetooth speaker, a white noise machine, and a phone holder, designed to enhance your bedside experience. Please read this manual thoroughly before use to ensure proper operation and maintenance.

SAFETY INFORMATION

- Ensure the device is connected to a stable power source using the provided USB cable.
- Do not expose the device to water or excessive moisture.
- Avoid placing the device in direct sunlight or near heat sources.
- Do not attempt to disassemble or repair the device yourself. Contact customer support for assistance.
- Keep out of reach of children.

PACKAGE CONTENTS

- Vivilumens Bedside Table LED Night Light
- USB Charging Cable
- User Manual

Note: A 9V/2A power adapter is required for wireless charging and is not included.

PRODUCT OVERVIEW

The Vivilumens Bedside Table LED Night Light integrates multiple functions into a compact and elegant design.



Figure 1: Vivilumens Bedside Table LED Night Light with a smartphone placed on its wireless charging pad.

Key features include:

- **LED Night Light:** Dimmable with 3 brightness levels (30%, 70%, 100%) controlled by touch.
- **Wireless Charger:** Conveniently charge compatible smartphones by placing them on the designated area.
- **Bluetooth Speaker:** Connect your device via Bluetooth 5.0 to play audio.
- **White Noise Machine:** Built-in nature sounds and sleep-aid music.
- **Phone Holder:** Adjustable light bar acts as a phone stand for horizontal or vertical viewing.

5-in-1 Touch Lamp Great for Gift



White-noise
sounds



Wireless
Charging



Brightness
adjustment



Bluetooth
speaker



Phone
holder



Figure 2: Visual representation of the 5-in-1 functionalities: White-noise sounds, Wireless Charging, Brightness adjustment, Bluetooth speaker, and Phone holder.

SETUP

Power Connection

1. Connect the provided USB cable to the charging port on the back of the device.
2. Plug the other end of the USB cable into a compatible 9V/2A power adapter (not included) and then into a wall outlet.
3. The device will power on, and the light bar may illuminate briefly.

Wireless Charging Setup

To utilize the wireless charging feature, ensure your smartphone is compatible with wireless charging (Qi standard).

Wireless Phone Charger

Please use 9V/2A Adaptor(Not included)

7.5W

For iOS device

10W

For Android device



Notice: Make sure your phone supports wireless charging
Keep the table lamp power on when using wireless charging function

Figure 3: A hand placing a smartphone onto the wireless charging area of the lamp. The image indicates 7.5W for iOS and 10W for Android devices.

1. Ensure the bedside lamp is plugged into a wall charger.
2. Place your mobile phone in the center of the charging pad.
3. The phone's screen should indicate that it is charging. If not, adjust the phone's position slightly until charging begins.

Note: Wireless charging requires the lamp to be powered on. Some phone cases may interfere with wireless charging.

OPERATING INSTRUCTIONS

Light Function

The LED night light offers three levels of brightness.

3 Brightness adjustment



Figure 4: The lamp demonstrating its three brightness levels: Low (30%), Mid (70%), and High (100%).

- To adjust brightness, touch anywhere on the light bar.
- Each touch cycles through the brightness levels: 30% (Low), 70% (Mid), 100% (High), and Off.

Bluetooth Speaker

Connect your smartphone or other Bluetooth-enabled device to play audio through the integrated speaker.

1. Ensure the lamp is powered on.
2. On your mobile device, enable Bluetooth and search for available devices.
3. Select "Vivilumens S22" (or similar name) from the list to pair.
4. Once paired, you can play music or other audio from your device through the lamp's speaker.
5. Use the volume buttons on the lamp's base or your connected device to adjust the volume.

Nature Sounds & White Noise Machine

The lamp features a selection of nature-like sounds to aid relaxation and sleep.



Figure 5: The control panel displaying icons for White noise, Fan sounds, Rain and thunder, Wave, and Serene sounds, along with timer options (30, 60 minutes) and a cancel timer button.

- Press the dedicated sound icons on the lamp's base to activate different sounds (e.g., White noise, Fan sounds, Wave sounds, Rain and thunder, Sleep-aid music).
- Use the volume buttons to adjust the sound level.
- Timer Function: Press the '30' or '60' minute buttons to set a sleep timer for the sounds. Press the 'X' button to cancel the timer.

Phone Holder

The adjustable light bar can serve as a convenient phone or tablet holder.

- Rotate the light bar to find the optimal viewing angle for your device.
- Place your smartphone, iPad, or e-book in the holder horizontally or vertically for hands-free viewing.

Product Demonstration Video

Your browser does not support the video tag.

Video 1: An official product video demonstrating the 5-in-1 features of the Vivilumens Bedside Table LED Night Light, including its

wireless charger, Bluetooth speaker, and various functions.

Your browser does not support the video tag.

Video 2: A short demonstration highlighting the 4-in-1 capabilities of the nightlight, speaker, charger, and sound machine.

MAINTENANCE

- To clean the device, wipe it with a soft, dry cloth.
- Do not use abrasive cleaners or solvents.
- Ensure the device is unplugged before cleaning.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Light does not turn on or respond to touch.	Device is not powered on or connected properly.	Ensure the USB cable is securely connected and the power adapter is plugged into a working outlet.
Wireless charging is not working.	Phone is not compatible, not positioned correctly, or power adapter is insufficient.	Verify phone compatibility. Reposition phone on the center of the charging pad. Ensure a 9V/2A power adapter is used. Remove thick phone cases.
Bluetooth speaker cannot pair or has poor sound.	Device is too far, not in pairing mode, or interference.	Ensure the lamp is within 33 feet of your device. Restart both devices and try pairing again. Reduce interference from other electronic devices.
Nature sounds are not playing.	Sound function is off or volume is too low.	Press the desired sound icon on the base. Increase the volume using the '+' button.

SPECIFICATIONS

Feature	Detail
Model Number	S22
Dimensions (D x W x H)	2.28"D x 8.38"W x 8.9"H
Item Weight	0.4 Kilograms (14.1 ounces)
Power Source	Corded Electric
Wattage	7.5 watts
Voltage	120 Volts (AC)
Light Source Type	LED
Brightness Levels	3 (30%, 70%, 100%)
Control Method	Touch
Connectivity Technology	Bluetooth 5.0
Wireless Charging Output	7.5W (iOS), 10W (Android)
Material	Acrylonitrile Butadiene Styrene, Polycarbonate
Color	Brown
UPC	739608481477

WARRANTY AND SUPPORT

Vivilumens is committed to providing quality products and customer satisfaction. For warranty information, technical support, or any inquiries regarding your Vivilumens Bedside Table LED Night Light, please contact Vivilumens customer support.

Live Customer Support is available Monday - Friday, 9 AM - 5 PM (EST).

You can also visit the official Vivilumens store for more information and support:[Vivilumens Store](#)