

Denfany KD2328

DENFANY Nano Ionic Facial Steamer Instruction Manual

Model: KD2328

1. PRODUCT OVERVIEW

The DENFANY Nano Ionic Facial Steamer is designed to provide a professional facial spa experience at home. Utilizing advanced ionic vaporization technology, it produces ultra-fine steam that penetrates the skin more effectively than traditional steamers, aiding in deep cleansing, pore opening, and moisturizing.



Image 1.1: The DENFANY Nano Ionic Facial Steamer, showcasing its sleek black design, transparent water tank, and adjustable steam arm.

Key Features:

- **Nano Ionic Steam Technology:** Produces ultra-fine steam for 10X more effective skin penetration and moisture supplementation.
- **Deep Cleansing:** Helps open pores to thoroughly remove dirt, oil, dead skin, and blackheads.
- **Adjustable Design:** Features an extendable arm and 360° rotatable sprayer for comfortable use in various positions.
- **Aromatherapy Function:** Includes a dedicated cotton pad for adding essential oils, enhancing the spa experience.
- **Large Water Tank:** 300ml capacity provides steam for at least 35 minutes.
- **Ozone Function:** Provides additional skin benefits through ozone emission.



Image 1.2: Illustration demonstrating the superior penetration of DENFANY's strong nano ionic steam compared to weaker, ordinary steam.

2. SAFETY INFORMATION

Please read all safety instructions carefully before using the DENFANY Nano Ionic Facial Steamer to ensure safe operation and prevent injury.

- Always keep your face at least **7.9 inches (20 cm)** from the nozzle to avoid burns from hot steam.
- Use only **distilled water or pure water** in the water tank. Do not add tap water or water containing impurities.
- Do not overfill the water tank beyond the **MAX** mark to prevent hot water spray out.
- Only use essential oils specifically intended for skin application and aromatherapy. Place them on the designated aromatherapy cotton pad, not directly into the water tank.
- Keep the steamer out of reach of children and pets.
- Do not leave the steamer unattended while in operation.
- Allow the steamer to cool down completely before handling, cleaning, or refilling the water tank.
- Ensure the power cord is not damaged and is properly connected to a suitable power outlet (110 volts_of_direct_current).

- The device has an auto shut-off function for safety when the water level is too low.



Image 2.1: Important safety guidelines: Do not exceed the MAX water level and use the aromatherapy cotton pad for essential oils.

3. COMPONENTS AND PARTS

Familiarize yourself with the main components of your DENFANY Nano Ionic Facial Steamer:

- **Main Unit:** Houses the heating element and water tank.
- **Water Tank:** Removable reservoir for distilled or pure water.
- **Extendable & Rotatable Arm:** Directs the steam flow.
- **Nozzle/Sprayer:** Emits the nano ionic steam.
- **Aromatherapy Compartment:** Located on the nozzle, for essential oil cotton pads.
- **Control Buttons:** Power/Steam switch, Ozone switch.
- **Power Cord:** For connecting to an electrical outlet.



Image 3.1: Overview of the steamer's adjustable arm and key functional features.

4. SETUP

Follow these steps for the initial setup of your facial steamer:

1. **Unpack:** Carefully remove all components from the packaging.
2. **Place:** Position the main unit on a stable, flat, and heat-resistant surface.
3. **Fill Water Tank:** Remove the water tank from the main unit. Fill it with **distilled water or pure water** up to the MAX line. Do not exceed this line.
4. **Reinsert Water Tank:** Securely place the filled water tank back into the main unit.
5. **Connect Power:** Plug the power cord into a standard 110V AC electrical outlet.



Facial Care

Open the water supply cap, fill the water supply tank with water. Make sure the water level does not exceed the MAX mark.



Intimate Fragrance Function Design

Open the aroma compartment, drop essential oil on the felt, close the compartment. The steam will then sent the aroma out.



Provide Skin Care Kits

We offer acne needle sets and spa hair bands to make your skincare process more convenient.

Image 4.1: Visual guide for filling the water tank and utilizing the aromatherapy function.

5. OPERATION

Once set up, follow these steps to operate your facial steamer:

1. **Turn On:** Press the "Steam" switch to turn on the device. The indicator light will illuminate.
2. **Wait for Steam:** Allow **3-5 minutes** for the steamer to heat up and begin producing steam.
3. **Adjust Arm:** Adjust the extendable arm and rotate the sprayer to direct the steam towards your face.
4. **Position Face:** Position your face at least **7.9 inches (20 cm)** away from the nozzle.
5. **Aromatherapy (Optional):** If desired, open the aromatherapy compartment on the nozzle, place a few drops of your favorite essential oil onto the cotton pad, and close the compartment.
6. **Steaming Session:** Enjoy your facial steaming session. A full tank of water provides approximately 35 minutes of steam. The device will automatically shut off when the water level is too low.
7. **Turn Off:** After your session, press the "Steam" switch to turn off the device. Unplug the power cord from the outlet.



Image 5.1: A user enjoying a facial steaming session, demonstrating proper distance from the nozzle.

6. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and longevity of your steamer:

- **Cool Down:** Always ensure the steamer is unplugged and completely cooled before cleaning.
- **Empty Water Tank:** Remove the water tank and empty any remaining water.
- **Clean Water Tank:** Rinse the water tank with clean water. For thorough cleaning, use a mild detergent and a soft brush, then rinse thoroughly to remove all soap residue.
- **Wipe Exterior:** Wipe the exterior of the main unit with a soft, damp cloth. Do not immerse the main unit in water.
- **Clean Aromatherapy Pad:** Remove and clean the aromatherapy cotton pad as needed. Replace if it becomes discolored or worn.
- **Descaling (Monthly):** To prevent mineral buildup, especially if using non-distilled water (though distilled is recommended), mix equal parts white vinegar and water. Fill the tank with this solution, let it sit for 30 minutes, then empty and rinse thoroughly. Run a tank of plain distilled water through the steamer to flush out any residue.
- **Storage:** Store the steamer in a cool, dry place when not in use.

7. TROUBLESHOOTING

Refer to this section for common issues and their solutions:

Problem	Possible Cause	Solution
No steam produced.	Water tank empty or below MIN level. Power cord not properly connected. Device not turned on. Insufficient heating time.	Refill water tank to MAX line. Ensure power cord is securely plugged in. Press the "Steam" switch. Wait 3-5 minutes for steam to generate.
Steam output is weak or inconsistent.	Mineral buildup in the heating element. Water tank not properly seated.	Perform descaling procedure (see Maintenance section). Re-seat the water tank firmly.
Water leaks from the unit.	Water tank overfilled. Water tank not properly seated. Damaged water tank or seal.	Do not fill past the MAX line. Ensure water tank is securely in place. Contact customer support if damage is suspected.
Device automatically shuts off prematurely.	Water level is too low.	This is a safety feature. Refill the water tank.

8. SPECIFICATIONS

Specification	Detail
Product Dimensions	6.6 x 6.6 x 9 inches
Weight	2.82 Pounds
Model Number	KD2328
Manufacturer	DENFANY
Color	Black
Material	Acrylonitrile Butadiene Styrene (ABS)
Power Source	Corded Electric
Wattage	350 watts
Voltage	110 volts_of_direct_current
Water Tank Capacity	Approx. 300ml
Steam Duration	Not less than 35 minutes (per full tank)

9. WARRANTY AND SUPPORT

For any questions or concerns regarding your DENFANY Nano Ionic Facial Steamer, please refer to the following:

- **Customer Support:** DENFANY offers 24-hour customer support. If you have any questions, please contact us through Amazon's messaging system or refer to the customer Q&A section on the product listing.
- **Protection Plans:** Extended protection plans are available for purchase separately. Please refer to the product listing for details on 2-Year and 3-Year protection plans.
- **Return Policy:** This product is subject to a 30-day return policy for refund or replacement.
- **Legal Disclaimer:** Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

Note: The legal disclaimer provided is a general statement and may not directly apply to the operation of this device. It is included as per product information.

© 2023 DENFANY. All rights reserved.
For more information, visit the [Denfany Store on Amazon](#).