

Anthter CY-305R

Anthter CY-305R Professional Blender User Manual

Model: CY-305R | Brand: Anthter

1. INTRODUCTION AND IMPORTANT SAFEGUARDS

Thank you for choosing the Anthter CY-305R Professional Blender. This manual provides essential information for the safe and efficient operation of your new appliance. Please read all instructions carefully before use and retain for future reference.

Important Safeguards

- Always ensure the blender is unplugged before assembling, disassembling, or cleaning.
- Do not immerse the motor base in water or other liquids.
- Keep hands and utensils out of the container while blending to reduce the risk of severe injury to persons or damage to the blender. A scraper may be used only when the blender is not running.
- Blades are sharp. Handle with care when cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- Ensure the lid is securely in place before operating the blender.
- Do not blend hot liquids in the main jar as pressure buildup can cause the lid to eject and result in burns.
- This appliance is for household use only.

2. KEY FEATURES

The Anthter CY-305R Professional Blender is designed for versatile kitchen tasks, offering powerful performance and user-friendly features:

- **High Efficiency with Low Noise:** Equipped with a powerful 950W motor and 4 different speeds for processing various ingredients. The silicone gel base helps reduce operational noise.
- **Durable Stainless Steel Base:** Features a German Standard Stainless Base for long-lasting performance. Anti-slip feet ensure stability during use.

- **4-Tip QuadPro Blade Technology:** Four stainless steel blades efficiently break down food cell walls, releasing more nutrients. Functions as a juicer, nuts and coffee grinder, and ice smoothie machine.
- **1.5L Thickened Glass Jug:** The 50 Oz glass jar is made of thickened glass, offering durability and scratch resistance, providing a safer alternative to plastic pitchers.
- **Easy To Clean:** The BPA-Free glass jar features a self-cleaning function for convenient post-use cleaning.



Image: The Anthter CY-305R Blender prepared with fresh fruits for blending.

3. PRODUCT COMPONENTS

Your Anthter CY-305R Blender consists of the following main parts:

1. **Motor Base:** The main unit housing the 950W motor, speed control knob, and power cord.
2. **Glass Jar (50 Oz / 1.5L):** The thickened glass container where ingredients are blended. Features measurement markings.
3. **Lid:** Securely fits on top of the glass jar to prevent spills during operation.
4. **Blade Assembly:** Integrated 4-tip QuadPro stainless steel blades at the bottom of the glass jar.

5. **Power Cord:** For connecting the blender to an electrical outlet.



Image: Overview of the Anthter CY-305R Professional Blender components.

4. SETUP AND ASSEMBLY

Before first use, wash all parts that will come into contact with food. Ensure the blender is unplugged during assembly.

1. Place the motor base on a clean, dry, and stable surface.
2. Ensure the glass jar is clean and dry.
3. Carefully place the glass jar onto the motor base. Align the jar with the base until it clicks securely into place. The blender will not operate if the jar is not correctly seated.
4. Add your desired ingredients to the glass jar. Do not exceed the MAX fill line.
5. Place the lid securely onto the glass jar. Ensure the lid is properly sealed to prevent leakage during blending.
6. Plug the power cord into a standard electrical outlet.

5. OPERATING INSTRUCTIONS

The Anthter CY-305R Blender features a rotary knob for speed control and a pulse function.

Speed Control

1. With the blender assembled and plugged in, turn the rotary knob to select your desired speed (1-4). Start with lower speeds for thicker mixtures and gradually increase as needed.
2. The blue light around the knob indicates the blender is ready for operation.
3. To stop blending, turn the knob back to the "0" position.

Pulse Function (P)

The "P" setting provides short bursts of power at maximum speed, ideal for chopping, crushing ice, or when you need more control over the blending process.

- To use the pulse function, turn the rotary knob to the "P" position and hold it. The blender will operate as long as the knob is held in this position.
- Release the knob to stop the pulse action.

Blending Tips

- For best results, add liquids first, then soft ingredients, followed by hard ingredients and ice.
- Do not overload the blender. If the motor strains, reduce the amount of ingredients.
- For thick mixtures, use the pulse function to break down ingredients before continuous blending.
- Always ensure the lid is securely fastened before starting the blender.

4 Speed Control



Image: The illuminated speed control knob of the Anthter CY-305R Blender.

Your browser does not support the video tag.

Video: Demonstrates the Anthter CY-305R blender in operation, showing blending of various ingredients and the pouring of smoothies.

6. CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and extends the life of your blender. Always unplug the blender before cleaning.

Self-Cleaning Function

1. After use, rinse the glass jar.
2. Fill the glass jar with warm water (approximately half full) and add a drop of dish soap.
3. Secure the lid and place the jar back on the motor base.
4. Turn the rotary knob to the "P" (Pulse) position and hold for 30-60 seconds, or until clean.
5. Rinse the jar thoroughly with clean water.

Manual Cleaning

- The glass jar and lid are dishwasher safe.
- Wipe the motor base with a damp cloth. Do not immerse the motor base in water.
- For stubborn residue on the blades, use a brush to clean carefully.

7. TROUBLESHOOTING

If you encounter issues with your Anthter CY-305R Blender, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Blender does not start.	Not plugged in; jar not correctly seated; lid not secured.	Check power connection; ensure jar is locked onto the base; ensure lid is properly closed.
Blender leaks during operation.	Lid not properly secured; ingredients exceed MAX fill line.	Ensure lid is tightly closed; do not overfill the jar.
Ingredients are not blending smoothly.	Too little liquid; ingredients too large; blender overloaded.	Add more liquid; cut ingredients into smaller pieces; reduce quantity of ingredients. Use pulse function to break down larger items.
Motor smells or overheats.	Overloading; continuous operation for too long.	Unplug immediately and let cool down. Reduce ingredients and blend in shorter intervals.

8. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	Anthter
Model Number	CY-305R
Power Source	Corded Electric
Motor Power	950W
Voltage	110 Volts
Number of Speeds	4 (plus Pulse)
Capacity	50.72 Fluid Ounces (1.5L)
Jar Material	Thickened Glass (BPA Free)
Blade Material	Stainless Steel
Product Dimensions	17.2"D x 8.11"W x 7.91"H
Item Weight	1.5 pounds
Special Feature	Safety Lock, Anti-slip feet

9. WARRANTY AND CUSTOMER SUPPORT

The Anthter CY-305R Professional Blender comes with a limited warranty. For specific details regarding warranty coverage, please refer to the warranty card included with your product or contact Anthter customer support.

Customer Support

If you have any questions, require assistance, or need to report an issue with your blender, please contact Anthter customer support through the retailer's platform or the official Anthter website. Please have your model number (CY-305R) and purchase date ready when contacting support.

© 2024 Anthter. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question