

[Manuals.plus](#) /

› [SIMATE](#) /

› SIMATE Hoverboard Model P6 Instruction Manual

SIMATE P6

SIMATE Hoverboard Model P6 Instruction Manual

Your Guide to Safe and Enjoyable Riding

1. INTRODUCTION

Thank you for choosing the SIMATE Hoverboard Model P6. This self-balancing scooter is designed for an engaging and dynamic riding experience, suitable for various users. This manual provides essential information for the safe operation, maintenance, and optimal performance of your hoverboard. Please read it thoroughly before first use.




Image 1: The SIMATE Hoverboard Model P6, showcasing its vibrant LED lights and integrated Bluetooth speaker functionality.

2. SAFETY INFORMATION

Your safety is paramount. Always wear appropriate safety gear, including a helmet, knee pads, and elbow pads, when operating the hoverboard. Adhere to local regulations regarding personal mobility devices.

2.1. General Safety Guidelines

- **Weight Limits:** The hoverboard supports a minimum weight of 45 lbs and a maximum weight of 220 lbs. Ensure riders are within this range for safe operation.
- **Age Recommendation:** Suitable for kids and adults. Adult supervision is recommended for younger riders.
- **Surface Conditions:** Operate on smooth, dry, and level surfaces. Avoid wet conditions, loose gravel, steep inclines (maximum 15-degree slope), or uneven terrain.
- **UL 2272 Certified:** The battery system is UL 2272 certified, ensuring compliance with electrical safety standards.
- **Awareness:** Be aware of your surroundings, pedestrians, and other vehicles.

SAFETY CERTIFIED




Image 2: Key safety and design features of the SIMATE Hoverboard Model P6.

3. PACKAGE CONTENTS

Upon opening your SIMATE Hoverboard Model P6 package, please verify that all components are present:

- SIMATE Hoverboard Model P6
- Charging Adapter
- User Manual (this document)

4. PRODUCT OVERVIEW

The SIMATE Hoverboard Model P6 is equipped with features designed for performance and user experience:

- **Self-Balancing Control System:** Facilitates ease of learning and stable riding.

- **300W Dual Motors:** Provides reliable power for movement.
- **6.5" Solid Rubber Wheels:** Durable and suitable for various terrains.
- **Non-Slip Footpads:** Ensures secure foot placement during operation.
- **Integrated LED Lights:** Enhances visibility and aesthetic appeal.
- **Bluetooth Speaker:** Allows for audio playback during rides.
- **Battery Indicator Light:** Displays current battery status.
- **Charging Port:** For connecting the charging adapter.

5. SETUP AND INITIAL CHARGING

Before your first ride, ensure the hoverboard is fully charged.

5.1. Charging the Hoverboard

1. Locate the charging port on the side of the hoverboard.
2. Connect the charging adapter to the hoverboard, then plug it into a power outlet.
3. The charging indicator light on the adapter will typically show red during charging and turn green when fully charged. A full charge takes approximately 2-3 hours.
4. Do not overcharge the device. Disconnect the charger once the battery is full.



Built-In Bluetooth Speaker and Led Lights



Image 3: The hoverboard features a built-in Bluetooth speaker and LED lights for an enhanced riding experience.

6. OPERATING INSTRUCTIONS

Familiarize yourself with the controls and balancing techniques before riding.

6.1. Powering On/Off

Press the power button located near the charging port to turn the hoverboard on or off. The battery indicator will illuminate upon activation.

6.2. Riding and Balancing

The SIMATE Hoverboard features a self-balancing system for ease of use. Step onto the footpads one foot at a time, ensuring the hoverboard remains level. Lean slightly forward to move forward, backward to reverse, and apply pressure to one footpad to turn.




Image 4: Visual guide to the self-balancing system, making it easy to learn and use.

6.3. Speed Modes

The hoverboard offers three adjustable speed modes:

- **Safe Mode:** Lowest speed, ideal for beginners.
- **Beginner Mode:** Moderate speed for intermediate riders.
- **Sports Mode:** Highest speed (up to 6 mph) for experienced riders.



Image 5: The three adjustable speed modes for varying skill levels.

6.4. Bluetooth Speaker Functionality

Connect your mobile device to the hoverboard via Bluetooth to play music through its built-in speaker. This feature enhances the riding experience with your favorite audio.

6.5. APP Control (XsCar App)

Download the exclusive XsCar app to unlock additional control features:

- Power on/off the hoverboard remotely.
- Adjust LED light settings.
- Monitor current speed and battery power.
- Set and switch between speed modes.



Image 6: Control your hoverboard with the XsCar app for advanced features.

6.6. Official Product Videos

Your browser does not support the video tag.

Video 1: SIMATE Scooter with Colorful LED Lights. This video demonstrates the hoverboard's vibrant LED lights and overall design.

Your browser does not support the video tag.

Video 2: SIMATE Scooter, All Terrain, Kids & Adults & Girls & Boy. This video showcases various individuals riding the SIMATE hoverboard on different surfaces.

Your browser does not support the video tag.

Video 3: SIMATE Kids Scooter. This video highlights children enjoying the SIMATE hoverboard, demonstrating its ease of use for younger riders.

7. MAINTENANCE

Proper maintenance ensures the longevity and performance of your hoverboard.

- **Cleaning:** Use a soft, damp cloth to wipe down the exterior. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the hoverboard in a cool, dry place away from direct sunlight and extreme temperatures. Ensure it is fully charged before long-term storage.
- **Battery Care:** Do not allow the battery to fully deplete for extended periods. Charge regularly, even if not in use.

8. TROUBLESHOOTING

If you encounter issues with your SIMATE Hoverboard, refer to the following common solutions:

- **Hoverboard not turning on:** Ensure the battery is charged. Connect the charger and check the indicator light.
- **Difficulty balancing:** Ensure you are on a flat, stable surface. Practice stepping on and off with assistance until comfortable.
- **Short battery life:** Ensure the hoverboard is fully charged before each use. Battery performance can vary based on rider weight, terrain, and speed mode.
- **Bluetooth connectivity issues:** Ensure Bluetooth is enabled on your mobile device and the hoverboard is powered on. Try restarting both devices.

9. SPECIFICATIONS

Feature	Detail
Model Name	P6
Brand	SIMATE
Item Dimensions (LxWxH)	22 x 7 x 7 inches
Package Weight	6.01 Kilograms
Material	Aluminum
Max Load	220 lbs
Top Speed	6 mph (3 adjustable speed modes)
Top Range	7 miles
Motor Power	300W Dual Motors
Wheel Size	6.5 inches
Special Features	Built-In Bluetooth speaker, LED Light, Light Up Wheel, Lightweight, Long Battery Life, APP Control

10. WARRANTY AND SUPPORT

SIMATE offers a 2-year warranty on the hoverboard. For any inquiries or assistance, please contact SIMATE customer

support. We provide 7*24 hours online service and 365 days after-sales support to ensure excellent value.



Image 7: SIMATE customer support is available to assist with any product-related questions or issues.

11. OPTIONAL ACCESSORIES

Enhance your riding experience with optional accessories. The SIMATE Hoverboard can be converted into a go-kart with a separately sold seat attachment, offering a different way to enjoy your device.



Image 8: The SIMATE Hoverboard can be transformed into a go-kart with an additional seat attachment.

© 2025 SIMATE. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0B6NY7TL5>

More documents and user manuals: <https://manuals.plus/>