

- Manuals.plus /
- › [klatre](#) /
- › Klatre KS1-N Smartwatch User Manual

klatre KS1N

Klatre KS1-N Smartwatch User Manual

Model: KS1-N

1. PRODUCT OVERVIEW

The Klatre KS1-N Smartwatch is a versatile fitness and health monitoring device designed for daily use. It features a 1.69-inch HD touch display, 5ATM water resistance, and comprehensive health tracking capabilities including heart rate, blood oxygen, and sleep monitoring. The smartwatch connects to your smartphone via Bluetooth, allowing for notifications and control of various functions.



Image: Klatre KS1-N Smartwatch in pink, showcasing the main watch unit with a digital display and an additional pink perforated strap. The watch face shows time 10:09 and some health metrics.

2. SETUP

2.1 Charging the Device

Before initial use, fully charge your Klatre KS1-N Smartwatch. Connect the charging cable (included) to the charging port on the back of the watch and to a USB power source. A full charge typically takes a few hours. The battery life is approximately 10 days on a single charge.

2.2 App Installation and Pairing

1. Download the "Onwear Pro" application from your smartphone's app store (available for Android and iOS).
2. Ensure Bluetooth is enabled on your smartphone.
3. Open the "Onwear Pro" app and follow the on-screen instructions to create an account or log in.

4. Within the app, navigate to the device pairing section and select your Klatre KS1-N Smartwatch from the list of available devices. Confirm the pairing request on both your phone and the smartwatch.
5. Once paired, the watch will synchronize with the app, and you can begin customizing settings and tracking data.

3. OPERATING INSTRUCTIONS

3.1 Navigating the Display

The Klatre KS1-N features a 1.69-inch TFT-LCD high-definition touchscreen with a resolution of 240*280. Swipe left, right, up, and down to access different functions and menus. Tap to select items.

3.2 Health Monitoring

- **Heart Rate Monitoring:** The advanced optical sensor automatically tracks your real-time heart rate 24/7. View your heart rate data directly on the watch or in the Onwear Pro APP.
- **Blood Oxygen Monitoring:** Monitor your blood oxygen levels. Data is accessible on the watch and in the Onwear Pro APP.
- **Sleep Monitoring:** The watch monitors your sleep status, providing comprehensive analysis of sleep quality, including deep sleep, light sleep, and awake time. Review detailed sleep reports in the Onwear Pro APP.

3.3 Sports Modes

The smartwatch includes 16 built-in sports modes to track various activities. These modes include, but are not limited to, running, cycling, rope skipping, basketball, badminton, and yoga. Select the appropriate mode before starting your workout for accurate tracking.

3.4 Notifications and Smart Features

When paired with your smartphone, the Klatre KS1-N can receive notifications for incoming calls (supports call rejection only), SMS messages, and alerts from apps such as WhatsApp, Facebook, Twitter, Instagram, Line, Skype, and Gmail. Ensure your phone is within Bluetooth range for continuous connectivity.

Additional practical functions include:

- Alarm Clock
- Timer
- Stopwatch
- Sedentary Reminder
- Pedometer (step counter)
- Camera Remote Control
- Music Control
- Weather Forecast
- Find Your Phone function
- Brightness Adjustment

3.5 Customizing Watch Faces

Choose from over 150 stylish watch faces available through the Onwear Pro App. You can also upload your favorite image to customize the watch face and create a personalized look.

4. MAINTENANCE

4.1 Cleaning the Smartwatch

Regularly clean your smartwatch and strap to prevent skin irritation and maintain device functionality. Use a soft, lint-free cloth. If

necessary, slightly dampen the cloth with water. Do not use harsh chemicals or abrasive materials.

4.2 Water Resistance

The Klatre KS1-N is designed with 5ATM water resistance (50 meters waterproof). This means it can be worn during swimming, surfing, or intense exercise without concern. However, it is not suitable for diving or high-pressure water activities. Avoid exposing the watch to hot water or steam.

4.3 Storage

When not in use for extended periods, store the smartwatch in a cool, dry place away from direct sunlight and extreme temperatures. Ensure the battery is not completely depleted before storage.

5. TROUBLESHOOTING

- **Device not turning on:** Ensure the watch is fully charged. Connect it to the charger and wait a few minutes before attempting to power it on again.
- **Unable to pair with smartphone:**
 - Ensure Bluetooth is enabled on your phone and the watch.
 - Make sure the watch is within close proximity to your phone.
 - Restart both your smartphone and the smartwatch.
 - Clear the Bluetooth cache on your phone (if applicable) and try pairing again.
 - Ensure the "Onwear Pro" app is updated to the latest version.
- **Inaccurate health data:**
 - Ensure the watch is worn snugly on your wrist, not too loose or too tight.
 - Clean the sensor on the back of the watch.
 - Avoid excessive movement during measurements.
- **Notifications not appearing:**
 - Verify that notification permissions are enabled for the "Onwear Pro" app in your phone's settings.
 - Ensure the watch is connected via Bluetooth to your phone.
 - Check notification settings within the "Onwear Pro" app.

If you encounter persistent issues, refer to the "Klatre Customer Service" section for support.

6. SPECIFICATIONS

Brand	klatre
Model	KS1N
Screen Size	1.69 Inches
Display Type	TFT-LCD, HD Touchscreen
Resolution	240*280
Water Resistance	5ATM (50 meters)
Battery Life	Up to 10 days

Battery Composition	Lithium-ion
Connectivity	Bluetooth
Operating System	Android Wear 2.6 (compatible with Android/iOS)
Health Features	Heart Rate, Blood Oxygen, Sleep Monitor
Sports Modes	16 (e.g., running, cycling, yoga)
App Compatibility	Onwear Pro APP
Color	Pink

7. WARRANTY AND SUPPORT

Klatre offers a warranty of up to 2 years for the KS1-N Smartwatch. For any issues, questions, or support needs, please contact Klatre customer service. They provide 24/7 customer support to ensure your satisfaction. Contact information can typically be found on the official Klatre website or through the "Onwear Pro" application.

© 2023 Klatre. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0B73JC3PQ>

More documents and user manuals: <https://manuals.plus/>