

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Chicco](#) /
- › [Chicco SterilNatural 3-in-1 Bottle Sterilizer User Manual](#)

## Chicco SterilNatural

# Chicco SterilNatural 3-in-1 Bottle Sterilizer

User Instruction Manual



## PRODUCT OVERVIEW

The Chicco SterilNatural 3-in-1 Sterilizer is designed to disinfect baby bottles, breast pumps, and pacifiers using natural steam. This method effectively eliminates 99.9% of germs without the need for chemical additives, leaving no residual odors or tastes. Its modular design offers three configurations to suit various sterilization needs.



Image: The Chicco SterilNatural 3-in-1 Sterilizer in its full assembly, ready for use.

## KEY FEATURES

- **Natural Steam Sterilization:** Eliminates 99.9% of household germs using only natural steam, without chemicals.
- **3-in-1 Modular Design:** Offers Full Size, Compact ECO, and Microwave configurations for versatile use.

- **Fast Sterilization:** Disinfects items in as little as 5 minutes (excluding heating time) or 3 minutes in microwave mode.
- **24-Hour Protection:** Items remain disinfected for up to 24 hours if the lid remains closed.
- **Automatic Shut-off:** The sterilizer automatically turns off at the end of the cycle for safety.
- **Compact Design:** Space-saving design suitable for most kitchen countertops.
- **Universal Compatibility:** Compatible with most baby bottles, breast pumps, pacifiers, and accessories on the market.

## COMPONENTS

---

The Chicco SterilNatural 3-in-1 Sterilizer consists of the following main components:

- Base Unit with Heating Plate and Control Panel
- Lower Basket (for Full Size configuration)
- Upper Basket (for Compact and Microwave configurations)
- Lid

# 3 EN 1 TAMAÑO AJUSTABLE

## ELIGE ENTRE 3 CONFIGURACIONES



### 1. TAMAÑO COMPLETO Hasta 6 biberones y pequeños objetos

### 2. TAMAÑO COMPACT Hasta 2 biberones y objetos pequeños

### 3. MICROONDAS en solo 3 minutos



Image: The sterilizer demonstrating its three modular configurations: Full Size, Compact, and Microwave.

## SETUP

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Clean:** Before first use, wash all removable parts (baskets, lid) with warm soapy water and rinse thoroughly. Wipe the base unit with a damp cloth.
3. **Assemble:**
  - For **Full Size**: Place the lower basket onto the base unit, then the upper basket on top of the lower basket.
  - For **Compact**: Place only the upper basket directly onto the base unit.
  - For **Microwave**: Use only the upper basket and its lid, without the base unit.
4. **Position:** Place the assembled sterilizer on a flat, stable, heat-resistant surface, away from direct sunlight or heat sources. Ensure adequate ventilation around the unit.

## OPERATING INSTRUCTIONS

## Steam Sterilization (Full Size or Compact Mode)

1. **Add Water:** Pour 150 ml of distilled water into the heating plate of the base unit. Using distilled water helps prevent limescale buildup.
2. **Load Items:** Place clean bottles, pacifiers, or breast pump components upside down into the appropriate basket(s). Ensure items do not block steam vents.
3. **Close Lid:** Securely place the lid on top of the assembled baskets.
4. **Power On:** Plug the sterilizer into a suitable electrical outlet. The display will illuminate.
5. **Select Mode:**
  - For **Full Size** (up to 6 x 330ml bottles): Press the power button. The cycle will typically take 12 minutes (excluding heating time).
  - For **Compact ECO** (up to 2 x 330ml bottles, 1 breast pump, or small items): Press the "COMPACT ECO" button. This mode saves up to 25% time and energy, with a cycle typically taking 9 minutes (excluding heating time).
6. **Sterilization Cycle:** The sterilizer will begin heating the water and generating steam. The display will show the remaining time.
7. **Automatic Shut-off:** The unit will automatically turn off and emit a series of beeps when the cycle is complete.
8. **Cool Down:** Allow the unit to cool down for at least 5 minutes before opening the lid. Use caution as steam will be hot.
9. **Remove Items:** Carefully remove sterilized items using tongs to avoid recontamination. Items remain disinfected for 24 hours if the lid is kept closed.

# FUNCIÓN MICROONDAS

**HASTA 2 BIBERONES Y  
OBJETOS PEQUEÑOS.**

**ESTERILIZA EN 3  
MINUTOS**



**\* a 1.000 W**

Image: The sterilizer illustrating that items remain disinfected for 24 hours with the lid closed.

## **Microwave Sterilization Mode**

1. **Prepare:** Place the upper basket with items and its lid directly into a microwave oven.
2. **Add Water:** Pour 80 ml of distilled water into the base of the upper basket.
3. **Microwave:** Heat in the microwave for 3 minutes at 1200 W. Adjust time based on microwave wattage (e.g., 5 minutes at 800 W).
4. **Cool Down:** Allow the unit to cool down for at least 5 minutes before opening the lid. Use caution as steam will be hot.
5. **Remove Items:** Carefully remove sterilized items using tongs.

# AHORRO DE ENERGÍA



**CON MODO ECO  
COMPACTO AHORRA  
HASTA UN 25% EN  
TIEMPO Y ENERGÍA**



Image: The sterilizer's upper basket configured for microwave sterilization, highlighting its 3-minute cycle.

## MAINTENANCE

### Daily Cleaning

- After each use, unplug the sterilizer and allow it to cool completely.
- Discard any remaining water from the heating plate.
- Wash the baskets and lid with warm soapy water and rinse thoroughly. They are not dishwasher safe.
- Wipe the heating plate and exterior of the base unit with a damp cloth. Do not immerse the base unit in water.
- Dry all parts thoroughly before storing to prevent mold or mildew.

### Descaling (Monthly or as needed)

Limescale buildup on the heating plate can affect performance. Descale regularly, especially if using hard water.

1. Mix 100 ml of white vinegar with 200 ml of water.

2. Pour the solution onto the heating plate of the base unit.
3. Let it soak for 30 minutes to 1 hour, or longer for heavy buildup. Do not turn on the sterilizer with the descaling solution.
4. Pour out the solution and gently scrub any remaining limescale with a soft brush or sponge.
5. Rinse the heating plate thoroughly with clean water several times to remove all vinegar residue.
6. Run a sterilization cycle with clean water before next use to ensure all residue is gone.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Sterilizer does not turn on.	Not plugged in; power outlet issue; unit malfunction.	Ensure plug is fully inserted. Test outlet with another appliance. If problem persists, contact customer support.
Sterilization cycle is too short/long.	Incorrect water volume; incorrect mode selected; microwave wattage mismatch.	Ensure correct water volume (150ml for steam, 80ml for microwave). Verify correct mode (Full Size/Compact). Adjust microwave time for wattage.
White residue on heating plate or items.	Limescale buildup from hard water.	Descal the unit regularly using vinegar solution. Use distilled water for sterilization.
Items are still wet after cycle.	Condensation is normal; no drying function.	This sterilizer uses steam and does not have a drying function. Allow items to air dry on a clean surface or use a clean cloth.

## SPECIFICATIONS

- **Model Name:** Chicco SterilNatural
- **Model Number:** 00007391000000
- **Dimensions:** 42 x 48 x 12 cm (approximate, assembled)
- **Weight:** 2.2 kg
- **Power Source:** Corded Electric
- **Wattage:** 1200 W (for microwave mode reference)
- **Capacity (Full Size):** Up to 6 x 330 ml bottles
- **Capacity (Compact):** Up to 2 x 330 ml bottles, 1 breast pump, or small accessories
- **Sterilization Time:** 5 minutes (steam, excluding heating time); 3 minutes (microwave at 1200W)
- **Material:** BPA-free plastic
- **Color:** White

## WARRANTY AND SUPPORT

Chicco products are designed and manufactured to the highest quality standards. For information regarding warranty coverage, product registration, or technical support, please refer to the warranty card included with your purchase or visit the official Chicco website.



**Official Chicco Website:** [www.chicco.com](http://www.chicco.com)

Please have your model number (00007391000000) and purchase date available when contacting support.



© 2025 Chicco. All rights reserved.