

Denver 116111000470

Denver SWC363 Bluetooth Smartwatch User Manual

1. INTRODUCTION

This manual provides essential information for the safe and effective operation of your Denver SWC363 Bluetooth Smartwatch. Please read this manual thoroughly before using the device and retain it for future reference. This smartwatch is designed to monitor various health and fitness metrics, display notifications, and facilitate Bluetooth calls when connected to a compatible smartphone.

2. PACKAGE CONTENTS

- Denver SWC363 Bluetooth Smartwatch
- USB Charging Cable
- User Manual

3. DEVICE OVERVIEW

The Denver SWC363 Smartwatch features a 1.7-inch full-touch IPS color display and a comfortable black silicone strap. It includes a side button for navigation and control, and sensors on the rear for health monitoring.



The image displays the Denver SWC363 smartwatch with its black strap and square face. The watch face shows the time (09:30), steps (00436), heart rate (100 BPM), distance (12.06), and calories (2000). A smartphone is also visible, showing the smartwatch's companion app interface with activity data and a call notification screen.

4. SETUP

4.1. Charging the Smartwatch

Before initial use, fully charge the smartwatch. Connect the provided USB charging cable to the charging contacts on the back of the watch and to a standard USB power adapter (not included). The watch display will indicate charging status. A full charge typically takes approximately 2 hours.

4.2. Installing the Companion Application

To unlock the full functionality of your smartwatch, download and install the dedicated companion application on your smartphone. Search for the app name (usually mentioned in the quick start guide or on the watch itself) in your smartphone's app store (Google Play Store for Android or Apple App Store for iOS).

4.3. Pairing with Your Smartphone

1. Ensure your smartwatch is charged and powered on.
2. Enable Bluetooth on your smartphone.
3. Open the companion application on your smartphone.
4. Follow the in-app instructions to search for and connect to your Denver SWC363 smartwatch. You may need to confirm the pairing on both the watch and the phone.
5. Once paired, the watch will synchronize data with the app.

5. OPERATING INSTRUCTIONS

5.1. Basic Navigation

- **Touch Screen:** Swipe left/right, up/down to navigate through menus and features. Tap to select an option.
- **Side Button:** Press to return to the previous screen or the watch face. Long press may power on/off the device or access specific functions.

5.2. Health Monitoring Features

The smartwatch integrates sensors to monitor various health metrics:

- **Heart Rate:** Access the heart rate interface to measure your current heart rate (BPM).
- **Blood Pressure:** Navigate to the blood pressure function to take a reading.
- **Blood Oxygen (SpO2):** Use the blood oxygen feature to measure your blood oxygen saturation level.
- **Sleep Monitoring:** The watch automatically tracks your sleep patterns when worn during sleep. View detailed sleep data in the companion app.
- **Daily Activity Tracking:** Monitors steps taken, distance covered, and calories burned throughout the day.

5.3. Multi-Sport Mode

The smartwatch supports various sports modes to track your workouts. Select from activities such as running, football, basketball, tennis, cycling, and climbing. The watch will record specific data relevant to your chosen activity.

5.4. Notifications

Once paired with your smartphone, the smartwatch can display notifications for incoming SMS messages, calls, social media activity, and calendar events. Ensure notification permissions are enabled in both your phone settings and the companion app.

5.5. Bluetooth Call Functionality

The SWC363 allows you to make and receive phone calls directly from the watch. Ensure the Bluetooth connection is stable and the call function is enabled in the app settings.

5.6. Remote Control Features

- **Remote Shutter:** Control your smartphone camera remotely by activating the shutter function on the watch.
- **Music Control:** Play, pause, skip tracks, and adjust volume for music playing on your smartphone.

6. MAINTENANCE

- **Cleaning:** Regularly clean the watch and strap with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- **Water Resistance:** The device has an IP67 rating, meaning it is protected against dust and temporary immersion in water (up to 1 meter for 30 minutes). It is suitable for daily use and splash protection but not recommended for swimming or showering.
- **Storage:** Store the smartwatch in a cool, dry place when not in use.

7. TROUBLESHOOTING

- **Watch not turning on:** Ensure the watch is fully charged. Connect it to the charger for at least 30 minutes.
- **Cannot pair with smartphone:** Make sure Bluetooth is enabled on your phone and the watch. Restart both devices and try pairing again through the companion app. Ensure the app has necessary permissions.
- **Inaccurate health readings:** Ensure the watch is worn snugly on your wrist, not too tight or too loose. Clean the sensor area. Note that this device is not a medical instrument and readings are for reference only.
- **Notifications not appearing:** Check notification settings in your phone and the companion app. Ensure the app is running in the background.
- **Short battery life:** Reduce screen brightness, disable unnecessary features, and ensure the watch is fully charged.

8. SPECIFICATIONS

Feature	Specification
Model Name	SWC363
Model Number	116111000470
Display	1.7-inch IPS Full Touch Color Screen
Chipset	Realtek 8762C
Battery Capacity	235 mAh Lithium-ion
Battery Life (Typical Use)	3-5 days
Standby Time	Up to 15 days
Water Resistance Rating	IP67
Connectivity	Bluetooth
Operating System Compatibility	Android, iOS
Sensors	Heart Rate, Blood Pressure, Blood Oxygen
Special Features	Time Display, Blood Pressure Monitor

9. SAFETY INFORMATION

- This device is not a medical instrument. The health data provided is for reference only and should not be used

for medical diagnosis or treatment.

- Consult a medical professional before starting any new exercise regimen or if you have any health concerns.
- Discontinue use if you experience skin irritation or discomfort.
- Keep the device away from extreme temperatures, direct sunlight, and corrosive liquids.
- Do not attempt to disassemble or repair the device yourself. This may void the warranty and cause damage.

10. WARRANTY AND SUPPORT

Information regarding specific warranty terms and availability of spare parts or software updates is not provided in the product details. For support, please refer to the contact information provided with your purchase or visit the official Denver website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question