

## Schütte 80106-A

# SCHÜTTE Black Wooden Toilet Seat with Soft-Close System (Model 80106-A)

User Instruction Manual

## 1. INTRODUCTION

Thank you for choosing the SCHÜTTE Black Wooden Toilet Seat with Soft-Close System. This manual provides essential information for the safe and correct installation, operation, and maintenance of your new toilet seat. Please read these instructions carefully before installation and retain them for future reference. This toilet seat is designed for universal fit on standard ceramic toilets and features a durable Duroplast material with a wooden finish, equipped with a soft-close mechanism for quiet and gentle closing.

## 2. SAFETY INFORMATION

- Ensure all components are present and undamaged before installation.
- Do not stand on the toilet seat or lid. This product is designed for sitting only.
- The maximum load capacity for the toilet seat is 175 kg. Exceeding this limit may cause damage or injury.
- Keep small parts out of reach of children to prevent choking hazards.
- Use appropriate tools for installation and follow all steps carefully.
- Avoid using abrasive cleaners or harsh chemicals, as these can damage the surface finish.

## 3. PACKAGE CONTENTS

Please verify that all the following items are included in your package:

- 1x SCHÜTTE Toilet Seat with Soft-Close System
- 1x Mounting Hardware Set
- 1x Installation Instructions (this manual)

## 4. INSTALLATION INSTRUCTIONS

---

The SCHÜTTE toilet seat is designed for easy installation on all standard ceramic toilets. Follow these steps for a secure fit:

1. **Prepare the Toilet:** Ensure the toilet bowl is clean and dry. Remove any old toilet seat and hardware.
2. **Position the Hinges:** Place the toilet seat on the ceramic bowl, aligning the hinge holes with the mounting holes on the toilet.
3. **Insert Mounting Bolts:** Insert the mounting bolts from the top through the hinge holes and the toilet bowl holes.
4. **Secure with Washers and Nuts:** From underneath the toilet bowl, place the washers onto the bolts, followed by the nuts. Hand-tighten them initially.
5. **Adjust Alignment:** Adjust the position of the toilet seat to ensure it is perfectly centered and aligned with the toilet bowl.
6. **Final Tightening:** Once aligned, firmly tighten the nuts using an appropriate wrench. Be careful not to overtighten, which could damage the ceramic.
7. **Test Soft-Close:** Gently push the seat and lid down to test the soft-close mechanism. It should close slowly and quietly.

*Note: For visual guidance, refer to the video installation instructions if available (check manufacturer's website).*

**No relevant product images were provided in the input data. Therefore, no images can be embedded here.**

**No relevant product videos were provided in the input data. Therefore, no videos can be embedded here.**

## 5. OPERATING THE SOFT-CLOSE SYSTEM

---

Your SCHÜTTE toilet seat is equipped with an integrated soft-close mechanism for both the seat and the lid. This feature ensures a gentle and silent closing, preventing slamming and reducing wear and tear.

- To close the seat or lid, simply push it down gently. The soft-close mechanism will engage and lower it slowly and quietly.
- Do not force the seat or lid down quickly, as this can damage the soft-close mechanism over time. Allow it to close at its own pace.
- The soft-close system has been tested for durability, ensuring reliable performance over many uses (up to 15,000 closing cycles).

## 6. CARE AND MAINTENANCE

---

Proper care will extend the life and maintain the appearance of your toilet seat:

- **Cleaning:** Clean the toilet seat regularly with a mild soap solution and a soft cloth.
- **Avoid Harsh Cleaners:** Do not use abrasive cleaners, scouring pads, strong acids, alkalis, or chlorine-based products, as these can damage the Duroplast material and the wooden finish.
- **Drying:** Always wipe the seat dry after cleaning to prevent water spots and maintain hygiene.
- **Hinge Care:** Periodically check the hinge connections for tightness. If they become loose, gently

retighten the mounting nuts.

## 7. TROUBLESHOOTING

If you encounter any issues with your toilet seat, refer to the following common problems and solutions:

- Problem:** The toilet seat feels loose or wobbly.  
**Solution:** The mounting nuts may have loosened. Re-tighten the nuts underneath the toilet bowl. Ensure they are snug but do not overtighten.
- Problem:** The soft-close mechanism is not working or the seat/lid slams.  
**Solution:** Check if the hinges are obstructed. Ensure no debris is preventing smooth movement. If the mechanism is damaged, contact customer support. Avoid forcing the seat down.
- Problem:** The toilet seat does not align correctly with the bowl.  
**Solution:** Loosen the mounting nuts slightly, adjust the seat's position until it is centered, then re-tighten the nuts.

## 8. SPECIFICATIONS

Feature	Detail
Brand	SCHÜTTE
Model Number	80106-A
Color	Black
Material	Duroplast, Stainless Steel (hinges)
Shape	Oval
Dimensions (L x W x H)	43.5 x 37.5 x 2.51 cm (approx. 17.1 x 14.8 x 1.0 inches)
Item Weight	2.96 kg (approx. 6.5 lbs)
Maximum Load Capacity	175 kg
Soft-Close System	Yes, tested for 15,000 cycles

## 9. WARRANTY AND CUSTOMER SUPPORT

SCHÜTTE, a leading German manufacturer in sanitary products for over 40 years, stands by the quality of its products.

- Spare Parts Availability:** Spare parts are available for 2 years from the date of purchase.
- Contact Support:** For any questions regarding the product, installation, or warranty claims, please contact SCHÜTTE customer service directly.
- Contact Number:** +49 5407-8152903 (Please note this is a German number, international charges may apply).
- Manufacturer:** Franz Joseph Schütte GmbH

