Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Imetec /
- > Imetec Adapto Purity Antibacterial Cotton Double Electric Mattress Pad User Manual

Imetec Adapto Purity Antibacterial Cotton Double

Imetec Adapto Purity Antibacterial Cotton Double Electric Mattress Pad User Manual

Model: Adapto Purity Antibacterial Cotton Double

INTRODUCTION

Thank you for choosing the Imetec Adapto Purity Antibacterial Cotton Double Electric Mattress Pad. This manual provides essential information for the safe and efficient use of your new product. Please read these instructions carefully before use and retain them for future reference.

IMPORTANT SAFETY INFORMATION

Your safety is paramount. This product incorporates advanced safety features to ensure reliable operation.

- **Electro Block Safety System:** Equipped with an advanced electronic control and self-diagnosis function that activates at every power-on, ensuring maximum safety.
- Constant Temperature Control: The system continuously monitors the temperature 25 times per second to prevent overheating and maintain safe operation.
- Always ensure the product is correctly installed and used according to these instructions.
- Do not use if wet or damaged.
- · Keep controls away from liquids.
- Unplug from the mains before cleaning or if not in use for an extended period.

SETUP AND INSTALLATION

- 1. **Unpack:** Carefully remove the electric mattress pad from its packaging.
- 2. **Placement:** Lay the mattress pad flat on your mattress. Ensure the non-slip underside fabric is in direct contact with the mattress surface. The pad is compatible with memory foam mattresses.
- 3. **Connect Controls:** Attach the digital controls to the connectors on the mattress pad. Ensure a secure connection.
- 4. **Power Connection:** Plug the power cord into a standard 220-240V, 50/60Hz mains outlet. The cable length is 2.1m.

5. Covering: Place your fitted sheet or mattress protector over the electric mattress pad.



Image: The Imetec Adapto Purity Antibacterial Cotton Double Electric Mattress Pad, folded, showing the two detachable digital controls. The pad features a quilted pattern with small blue accents.

OPERATING INSTRUCTIONS

The Imetec Adapto Purity features Patented Adapto technology for fast heating and customized comfort.

- 1. Power On/Off: Press the power button on the LED digital control to turn the mattress pad on or off.
- 2. **Temperature Settings:** Use the temperature selection buttons to choose from 6 available temperature levels. The LED display will indicate the selected level.
- 3. **Fast Heating:** The Adapto technology ensures rapid heating to your desired temperature.
- 4. **Timer Function:** Set the automatic shut-off timer for 1, 3, or 9 hours using the timer button. The pad will automatically turn off after the selected duration.
- 5. **LED Light Intensity:** The control features automatic adjustment of the LED light intensity for comfortable viewing in various lighting conditions.
- 6. **Dual Controls:** For double-sized pads, two independent controls are provided, allowing individual temperature and timer settings for each side of the bed.

MAINTENANCE AND CLEANING

Proper care ensures the longevity and hygiene of your electric mattress pad.

- **Disconnect Controls:** Before cleaning, always ensure the mattress pad is unplugged from the mains and the digital controls are removed from the pad. The controls are not washable.
- Washing: The 100% warm antibacterial cotton fabric is suitable for both hand wash and machine wash at 30°C. Use a gentle cycle if machine washing.
- **Drying:** Do not tumble dry. Air dry flat, away from direct sunlight or heat sources. Ensure the pad is completely dry before reattaching controls and using.
- **Storage:** When not in use, store the mattress pad in a cool, dry place, preferably in its original packaging or a breathable bag.
- Purity Treatment: The Purity treatment with zinc ions protects the fabric from bacterial growth, preserving hygiene.

Troubleshooting

If you encounter issues, please refer to the following common solutions:

· Pad Not Heating:

- Ensure the power cord is securely plugged into the mains outlet.
- Verify that the digital control is firmly connected to the mattress pad.
- Check if the power button on the control is pressed and the LED display is active.
- The Electro Block safety system performs a self-diagnosis; if an issue is detected, it may prevent operation. Try unplugging and re-plugging the unit.

• Controls Not Responding:

- Ensure the unit is powered on.
- Check for any visible damage to the control unit or cable.

· Uneven Heating:

- Ensure the mattress pad is laid flat and not bunched or folded.
- Allow sufficient time for the pad to reach the desired temperature, especially on lower settings.

If problems persist, contact customer support.

SPECIFICATIONS

- Model: Adapto Purity Antibacterial Cotton Double
- Size: Double (150 x 160 cm)
- Material: 100% Warm Antibacterial Cotton
- Special Features: Purity technology with zinc ions, Adapto technology, Electro Block security system, Nonslip underside fabric
- Temperature Settings: 6
- Timer: Auto-off after 1, 3, or 9 hours
- Control: LED Digital Control (removable for washing)
- Power: 150 W
- Voltage: 220-240V

Frequency: 50/60HzCable Length: 2.1m

• Weight: Approximately 2.7 kg

• Washing Instructions: Hand wash and machine wash at 30°C

• Compatibility: Compatible with memory foam mattresses

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or visit the official Imetec website. Keep your proof of purchase for warranty claims.

Related Documents - Adapto Purity Antibacterial Cotton Double



IMETEC Scaldaletto: Manuale d'Uso e Sicurezza

Manuale completo per lo scaldaletto IMETEC, che include istruzioni dettagliate per l'uso, la sicurezza, la pulizia, la manutenzione e la risoluzione dei problemi. Copre i modelli R1502, R1503, R1505, R1506, R1508, R1511.

Manuale d'uso IMETEC TYPE R6701 - Termoforo Elettrico

Manuale di istruzioni per l'uso del termoforo IMETEC TYPE R6701. Questo documento fornisce una guida completa per l'utilizzo sicuro ed efficace, inclusi dettagli su specifiche tecniche, istruzioni di sicurezza, uso, pulizia, manutenzione, risoluzione dei problemi e garanzia.



IMETEC MULTISTYLER Type C7003: Manuale d'uso e istruzioni

Scopri come utilizzare al meglio il tuo IMETEC MULTISTYLER Type C7003 con il manuale d'uso completo. Istruzioni dettagliate per uno styling perfetto e sicuro dei capelli.



IMETEC Sistema Stirante S3901: Guida Completa all'Uso e alla Sicurezza

Scopri come utilizzare al meglio il tuo IMETEC Sistema Stirante S3901. Questa guida completa fornisce istruzioni dettagliate, consigli sulla sicurezza e manutenzione per un'esperienza di stiratura ottimale.

