



[Manuals.plus](#) /

> [Oreck](#) /

> Oreck Commercial U2000RB2L-1 LEED-Compliant Upright Vacuum Cleaner User Manual

Oreck U2000RB2L-1

Oreck Commercial U2000RB2L-1 Upright Vacuum Cleaner User Manual

Model: U2000RB2L-1

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your Oreck Commercial U2000RB2L-1 Upright Vacuum Cleaner. Please read this manual thoroughly before using the appliance and retain it for future reference.



Figure 1: Oreck Commercial U2000RB2L-1 Upright Vacuum Cleaner.

2. PRODUCT OVERVIEW

The Oreck Commercial U2000RB2L-1 is a lightweight, powerful upright vacuum designed for commercial and demanding home use. It features robust suction and a durable design for effective cleaning across various floor types.

Key Features:

- **Commercial Cleaning Power:** Engineered to lift deeply embedded dirt from carpets and handle tough messes.
- **Lightweight Efficiency:** Weighs approximately 9 pounds, facilitating easy movement between rooms and up stairways.
- **All Floor Capability:** Features Microsweep technology for seamless transition and effective cleaning on both carpets and hard floors without manual adjustments.
- **Efficient Maintenance:** Equipped with an Endurolife belt for durability and Hall Effect sensor technology to prevent motor jams.
- **Edge Cleaning:** Side edge brushes are integrated to clean along baseboards and in corners.

3. SETUP

Your Oreck Commercial U2000RB2L-1 vacuum cleaner comes largely pre-assembled. Follow these steps for initial setup:

1. **Unpack:** Carefully remove all components from the packaging. Ensure all parts listed in the included components section are present.
2. **Handle Assembly:** Insert the handle into the main body of the vacuum until it clicks securely into place.
3. **Cord Management:** Wrap the power cord around the designated cord hooks on the handle for neat storage. Unwind only the necessary length for operation.
4. **Bag Installation:** Ensure the dust bag is correctly installed and securely fastened within the vacuum's bag compartment. Refer to the 'Maintenance' section for detailed bag replacement instructions.

4. OPERATING INSTRUCTIONS

To ensure optimal cleaning performance and extend the life of your vacuum, follow these operating guidelines:

1. **Power Connection:** Plug the power cord into a suitable electrical outlet.
2. **Power On/Off:** Locate the power switch (typically on the handle or base) and press it to turn the vacuum on. Press again to turn it off.
3. **Floor Type Transition:** The Microsweep feature automatically adjusts for different floor types (carpet, hard floor, tile, hardwood). No manual adjustment is required when moving between surfaces.
4. **Vacuumping Technique:** Push the vacuum forward and pull it back in overlapping passes. For heavily soiled areas, slower passes may be more effective.
5. **Edge Cleaning:** Utilize the side edge brushes by guiding the vacuum along baseboards and furniture edges.
6. **Cord Safety:** Be mindful of the power cord during operation to prevent tripping hazards or damage to the cord. The cord guard helps protect the cord from the brush roll.

5. MAINTENANCE

Regular maintenance is crucial for maintaining the performance and longevity of your Oreck vacuum cleaner.

5.1 Dust Bag Replacement

1. **Power Off:** Always unplug the vacuum cleaner before performing any maintenance.
2. **Access Bag:** Open the bag compartment (refer to your vacuum's specific design for latch location).
3. **Remove Old Bag:** Carefully remove the full dust bag, ensuring the opening is sealed to prevent dust escape. Dispose of the bag according to local regulations.
4. **Install New Bag:** Insert a new Oreck Standard filter bag, ensuring it is properly seated and sealed.
5. **Close Compartment:** Securely close the bag compartment.

5.2 Brush Roll and Belt Inspection

Periodically inspect the brush roll and Endurolife belt for wear or obstructions.

- **Unplug:** Ensure the vacuum is unplugged.
- **Access Brush Roll:** Turn the vacuum over and remove the bottom plate (usually secured by screws).
- **Clean Brush Roll:** Remove any hair, string, or debris wrapped around the brush roll.
- **Inspect Belt:** Check the Endurolife belt for signs of wear, stretching, or damage. Replace if necessary (an extra belt is included).
- **Reassemble:** Reattach the bottom plate securely.

6. TROUBLESHOOTING

If you encounter issues with your Oreck vacuum, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Vacuum does not turn on	No power; loose plug; faulty switch	Check power outlet; ensure plug is secure; contact service if switch is faulty.
Loss of suction	Full dust bag; clogged hose/nozzle; worn belt; brush roll jammed	Replace dust bag; clear obstructions; replace belt; clean brush roll.
Brush roll not spinning	Belt broken or dislodged; brush roll jammed; Hall Effect sensor activated	Replace or re-seat belt; clear brush roll; check for obstructions that triggered the sensor.
Unusual noise	Obstruction in fan/motor; worn bearings; loose parts	Unplug and inspect for obstructions; contact service for internal issues.

If these solutions do not resolve the issue, please contact Oreck customer support.

7. SPECIFICATIONS

Feature	Detail
Brand	Oreck
Model Number	U2000RB2L-1
Form Factor	Upright
Color	Gray/Black
Item Weight	9 pounds
Product Dimensions	12"L x 9"W x 47"H
Power Source	Corded Electric
Wattage	630 watts
Amperage	5.25 Amps
Noise Level	70 Decibels
Filter Type	Standard
Capacity	9 Quarts
Special Features	LEED certified, High efficiency, Sensor technology, Lightweight, Easy cord replacement
Recommended Uses	Carpet, Hard Floor, Tile Floor, Hardwood, Bare Floor

8. WARRANTY & SUPPORT

Your Oreck Commercial U2000RB2L-1 Upright Vacuum Cleaner comes with a **1-year commercial warranty**. This warranty covers defects in materials and workmanship under normal use.

For warranty claims, technical support, or to purchase replacement parts, please contact Oreck customer service.
Keep your proof of purchase for warranty validation.