

SANODESK Q2LB-6340-EU

SANODESK Q2L Height Adjustable L-Shaped Desk User Manual

Model: Q2LB-6340-EU

1. IMPORTANT SAFETY INFORMATION

Please read this manual carefully before assembly and use. Keep these instructions for future reference. Incorrect assembly or operation may cause damage or injury.

- Ensure all components are present and undamaged before assembly.
- Do not allow children to operate the desk without supervision.
- Keep hands and objects clear of moving parts during height adjustment.
- Do not overload the desk. Refer to the specifications for maximum weight capacity.
- Only use the provided power adapter and cables.
- If any unusual noise or movement occurs, discontinue use and consult the troubleshooting section or contact support.

2. SETUP AND ASSEMBLY

The SANODESK Q2L desk requires assembly. Detailed step-by-step instructions are provided in a separate assembly guide included with your product. Please follow those instructions carefully.

Key Assembly Features:

- **Dual Motor System:** This desk is equipped with two powerful motors for stable and smooth height adjustments.
- **L-Shaped Desktop:** The desk features an L-shaped design, providing an expansive work surface.
- **Anti-Collision Feature:** The desk includes an anti-collision sensor to prevent damage by automatically stopping movement if an obstruction is detected.



Image: The SANODESK Q2L desk highlighting its dual motor system and anti-collision functionality. The dual motors ensure stable and powerful height adjustments, while the anti-collision sensor enhances safety by detecting obstacles.



Image: Overhead view of the SANODESK Q2L L-shaped desk, illustrating its generous dimensions of 1600mm by 1000mm, providing ample workspace.

3. OPERATING INSTRUCTIONS

Control Panel Overview:

The desk is operated via a smart control panel, typically located on the front edge of the desktop. This panel allows for precise height adjustments and memory presets.

Smart Control Panel



- ① **LED Screen:** Providing a better operating experience
- ② **Up/Down movement:** Convenient height adjustment
- ③ **4 Height's Memory Presets Buttons**

Image: A close-up view of the SANODESK Smart Control Panel. It features an LED screen for displaying height, up/down arrow buttons for adjustment, and four numbered buttons (1, 2, 3, 4) for saving and recalling preferred height settings.

- **LED Screen:** Displays the current desk height in centimeters.
- **Up/Down Movement Buttons (▲ / ▼):** Press and hold to adjust the desk height upwards or downwards. The desk will move smoothly between 72 cm and 121 cm.
- **Memory Presets (1, 2, 3, 4):**
 1. Adjust the desk to your desired height.
 2. Press the 'M' or 'Set' button (if available, or indicated by an 'i' icon on some models) followed by one of the numbered preset buttons (1, 2, 3, or 4). The screen may flash to confirm the setting is saved.
 3. To recall a saved height, simply press the corresponding numbered button (1, 2, 3, or 4). The desk will automatically move to the saved position.
- **Anti-Collision System:** The desk is equipped with a sensor that detects obstacles in its path during height adjustment. If an object is encountered, the desk will stop and reverse slightly to prevent damage.



Image: The SANODESK Q2L desk demonstrating its height adjustment range from 720mm to 1210mm, accompanied by an icon indicating quiet operation.

Humanized Office Design:

The desk's design includes features like a monitor stand to promote ergonomic posture, helping to keep your head and neck comfortably elevated during extended work periods.



Image: The SANODESK Q2L desk featuring a monitor stand, designed to elevate your screen to an ergonomic height, promoting better posture and reducing strain during work.

4. MAINTENANCE

To ensure the longevity and optimal performance of your SANODESK Q2L desk, follow these maintenance guidelines:

- **Cleaning:** Wipe the desktop and frame with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Cable Management:** Regularly check and organize cables to prevent tangling or interference with the desk's movement.
- **Inspection:** Periodically inspect all screws and connections to ensure they are secure. Tighten if necessary.
- **Weight Distribution:** Distribute weight evenly across the desktop to prevent undue stress on the lifting mechanism.

5. TROUBLESHOOTING

If you encounter issues with your SANODESK Q2L desk, please refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Desk does not move	Power cable disconnected; Overload; Motor error	Check power connections; Reduce weight on desk; Perform a reset (refer to assembly guide for specific reset procedure).
Uneven movement	Uneven weight distribution; Obstruction	Distribute weight evenly; Check for obstructions under the desk.
Anti-collision activates frequently	Sensitive setting; Obstruction	Ensure no objects are near the desk's path; Consult assembly guide for adjusting sensitivity if applicable.
Memory presets not working	Incorrect saving procedure	Re-save the desired heights following the operating instructions.

If the problem persists after attempting these solutions, please contact customer support.

6. SPECIFICATIONS

- **Brand:** SANODESK
- **Model Number:** Q2LB-6340-EU
- **Color:** Black
- **Product Dimensions (L x W x H):** 160 x 100 x 72 cm
- **Height Adjustment Range:** 72 cm to 121 cm
- **Weight Capacity:** 100 kg (without tabletop)
- **Item Weight:** 30 Kilograms
- **Material:** Alloy Steel
- **Special Features:** Height adjustable, Electric, Anti-collision

7. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation provided at the time of purchase or contact your retailer. Specific details regarding spare parts availability are not provided in this manual.

If you require further assistance, have questions about assembly, operation, or troubleshooting that are not covered in this manual, please contact SANODESK customer support or your product retailer.

