

SANODESK E2L

SANODESK Electric Corner L-Shaped Standing Desk (Model E2L) User Manual

Model: E2L | Brand: SANODESK

1. INTRODUCTION

Thank you for choosing the SANODESK Electric Corner L-Shaped Standing Desk. This manual provides essential information for the safe assembly, operation, and maintenance of your new desk. Please read these instructions thoroughly before beginning assembly or use, and retain this manual for future reference.



Figure 1: SANODESK Electric Corner L-Shaped Standing Desk.

2. IMPORTANT SAFETY INFORMATION

WARNING: Failure to follow these safety instructions may result in injury or damage to the product.

- Always ensure the desk is properly assembled and anchored.
- Keep the work area clear of obstacles to prevent the desk from moving unexpectedly during height adjustments.
- Do not attempt to adjust the desk height while it is in motion or if objects are obstructing its path.
- Utilize the provided safety features, such as the anti-collision system, to prevent injury or damage.
- Exercise caution when using power tools during assembly. Always wear appropriate safety gear.
- Follow all manufacturer's instructions for proper use and maintenance.
- This desk is designed for adult use. Keep children and pets away from the desk during operation.

3. PACKAGE CONTENTS

Your SANODESK Electric Corner L-Shaped Standing Desk is shipped in two separate packages to ensure safe delivery. Please verify that all components are present and undamaged before beginning assembly. Refer to the included physical assembly manual for a detailed list of parts.

Typical components include:

- Desktop panels (L-shaped configuration)
- Desk frame components (legs, beams, feet)
- Dual motor lift system
- Control panel with memory presets
- Power adapter and cables
- Assembly hardware (screws, tools)

4. SETUP AND ASSEMBLY

Assembly typically takes 1-2 hours for two people. A power drill is recommended for certain steps, as some pre-drilled holes may not perfectly align due to the flexible beam design accommodating various desktop sizes. Please refer to the detailed step-by-step instructions and diagrams in your physical assembly manual for precise guidance.

4.1 Assembly Options

The L-shaped desktop is reversible, allowing for both left-hand and right-hand configurations to suit your workspace layout.

ULTIMATE STABILITY

Sturdy frame with commercial-grade lifting column connectors



Figure 2: Two assembly options for the L-shaped desk.

4.2 Stability Considerations

Ensure all connections are secure and the desk is placed on a level surface for optimal stability. The industrial-grade steel frame is designed for robust support.



Figure 3: Desk stability demonstration.

5. OPERATING INSTRUCTIONS

Your SANODESK features an intuitive control panel for easy height adjustment and personalized settings.

5.1 Control Panel Overview



Figure 4: Control Panel for height adjustment and memory presets.

- **Up/Down Buttons:** Use the arrow buttons to manually adjust the desk height.
- **Memory Presets (1, 2, 3):** Store and recall your preferred sitting and standing heights.
- **Memory Set Button (M):** Used to save a height setting.
- **Anti-Collision System:** The desk is equipped with an anti-collision feature that stops movement if an obstruction is detected.

5.2 Adjusting Height

Press and hold the up or down arrow buttons to move the desk to your desired height. The dual motor system provides smooth and stable adjustment at 32mm/s.

5.3 Setting Memory Presets

1. Adjust the desk to your desired height using the up/down buttons.
2. Press the "M" button. The display will show "S-".
3. Within 3 seconds, press the desired number button (1, 2, or 3) to save the current height to that preset. The

display will show "S-1", "S-2", or "S-3" to confirm.

To recall a saved height, simply press the corresponding number button (1, 2, or 3). The desk will automatically move to the programmed height.

5.4 Alarm Function

The control panel includes an alarm function to remind you to change positions. Refer to your physical manual for detailed instructions on how to set and activate the alarm.

5.5 Ergonomic Use

Regularly switching between sitting and standing positions can contribute to a healthier work routine. Utilize the memory presets to easily transition throughout your day.



Figure 5: Recommended ergonomic postures for sitting and standing.

Your browser does not support the video tag.

Video 1: Demonstration of the SANODESK L-Shaped Standing Desk's height adjustment and features.

6. MAINTENANCE

- **Cleaning:** Wipe the desk surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the laminated finish.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Cable Management:** Ensure cables are neatly managed and do not interfere with the desk's movement.

7. TROUBLESHOOTING

If you encounter any issues with your SANODESK, please refer to the following common solutions:

- **Desk Not Moving:**
 - Check if the power cable is securely plugged into both the desk and a working power outlet.
 - Ensure no objects are obstructing the desk's movement path. The anti-collision system may have activated.
 - Refer to the physical manual for specific reset procedures for the control panel.
- **Unstable Desk:**
 - Verify that all assembly screws are tightened.
 - Ensure the desk is on a flat, level surface. Adjust the leveling feet if necessary.
- **Pre-drilled Holes Not Aligning During Assembly:**
 - Due to the flexible beam design, some pre-drilled holes may not perfectly match. A power drill is recommended for creating new pilot holes if needed. Proceed with caution.

For further assistance, please contact SANODESK customer service.

8. SPECIFICATIONS

Feature	Detail
Brand	SANODESK
Model Number	E2L
Product Dimensions (D x W x H)	48"D x 71"W x 28.9"H
Height Adjustment Range	28.9" - 48.2"
Adjustment Speed	32mm/s
Weight Capacity	177 lbs (80 kg)
Noise Level	<50db
Motor Type	Dual Motor
Control Panel	Programmable with 3 memory presets
Special Features	Adjustable, Electric, Ergonomic, Reversible, Anti-collision
Top Material Type	Engineered Wood (FSC-Certified)
Base Material	Carbon Steel / Alloy Steel
Color	Black Top, Black Frame
Required Assembly	Yes (Recommended 2 people)

9. WARRANTY AND SUPPORT

9.1 Warranty Information

The SANODESK Electric Corner L-Shaped Standing Desk comes with a Limited Warranty. Please refer to the warranty card included with your product for specific terms, conditions, and duration of coverage.

9.2 Customer Support

If you have any questions, require assistance with assembly, or need troubleshooting support, please do not hesitate to contact SANODESK customer service. Our team can provide detailed instructions and video references to help you.

For contact information, please refer to the SANODESK official website or the contact details provided in your product packaging.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question