



[Manuals.plus](#) /

› [Superun](#) /

› Superun Walking Pad Under Desk Treadmill User Manual

Superun BA06

Superun Walking Pad User Manual

Model: BA06

1. PRODUCT OVERVIEW

The Superun Walking Pad is a versatile 3-in-1 portable treadmill designed for walking and light jogging in both office and home environments. Featuring a powerful yet quiet 2.5 HP motor, it supports users up to 250 lbs. Its compact and space-saving design, coupled with built-in wheels, allows for easy storage under desks, beds, or sofas. The integrated LED display and smart PitPat APP provide real-time fitness data tracking, including calories burned, speed, time, and distance.



Figure 1: SupeRun Walking Pad in typical usage scenarios.

2. SETUP GUIDE

The SupeRun Walking Pad arrives fully assembled, requiring no complex installation. Follow these steps for initial setup:

1. **Unpacking:** Carefully remove the walking pad from its packaging. Ensure all components, including the remote control, lubricating oil, 5# wrench, user manual, and power cord, are present.
2. **Placement:** Place the walking pad on a flat, stable surface. Ensure there is adequate clear space around the unit for safe operation.
3. **Power Connection:** Connect the power cord to the walking pad and then to a standard electrical outlet.
4. **App Activation:** This walking pad requires the PitPat app for activation and full functionality. Download the PitPat app from your device's app store ([App Store](#) / [Google Play](#)). Follow the in-app instructions to connect and activate your device. If you encounter issues, please refer to the troubleshooting section or contact customer support.

SMART TREADMILL WITH PITPAT APP



Figure 2: Walking Pad ready for use under a desk.

Powerful & Silent Motor



Noise:
<45 DB



Motor:
2.5 HP



Weight Capacity:
265 LBS



Speed:
0.6-2.5 MPH



Figure 3: PitPat App integration for smart control and tracking.

3. OPERATING INSTRUCTIONS

The SuperRun Walking Pad is controlled primarily via the included remote control and the PitPat app.

3.1 Remote Control Functions

- **Power On/Off:** Press the power button to turn the unit on or off.
- **Start/Stop:** Press the play/pause button to start or stop the walking belt.
- **Speed Adjustment:** Use the '+' and '-' buttons to increase or decrease the speed. The speed range is 0.6-2.5 MPH.

Shock Absorbing for Smooth Walking

Enjoy the fun of sports



5 High-layer Belt Design



Knees Ankles Protection



Shock-Absorbing Mat



Figure 4: LED Display and Remote Control.

3.2 LED Display

The integrated LED display shows key workout metrics:

- **Speed:** Current walking speed.
- **Calories:** Estimated calories burned.
- **Time:** Duration of your workout.
- **Distance:** Total distance covered.

3.3 PitPat App Integration

The PitPat app enhances your exercise experience with features such as:

- **Performance Tracking:** Detailed tracking of your workout data.
- **Training Programs:** Access to various training routines.
- **Events & Social Features:** Participate in challenges and connect with other users.

- **Entertainment:** Enjoy content while you exercise.

3.4 Safety Guidelines

- Ensure the walking pad is on a level surface before starting.
- Do not exceed the maximum weight capacity of 250 lbs.
- Always step onto the belt after it has started moving at a low speed.
- Keep children and pets away from the walking pad during operation.
- The unit operates quietly (under 40 decibels), making it suitable for shared spaces.

4. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your SupeRun Walking Pad.

4.1 Cleaning

- Disconnect the power cord before cleaning.
- Wipe down the surface of the walking pad with a damp cloth. Avoid using abrasive cleaners or solvents.
- Regularly clean dust and debris from around the motor cover and belt edges.

4.2 Belt Lubrication

To maintain smooth operation and extend belt life, lubricate the running belt every 3-6 months, or after approximately 100 hours of use, using the provided lubricating oil. Consult the detailed instructions in the included user manual for the correct application procedure.

4.3 Belt Adjustment

If the running belt shifts to one side during use, it may need adjustment. Use the provided 5# wrench to make small, incremental adjustments to the rear rollers until the belt is centered. Refer to the user manual for specific instructions on belt centering.

5. TROUBLESHOOTING

If you encounter issues with your SupeRun Walking Pad, please refer to the following common solutions. For problems not listed here, contact customer support.

- **Treadmill Not Starting:**
 - Ensure the power cord is securely plugged into both the unit and the wall outlet.
 - Verify the power switch on the unit is in the 'ON' position.
 - Confirm the PitPat app is downloaded and the device is activated as required.
- **Unusual Noise:**
 - Check for any loose parts or foreign objects under the belt.
 - Ensure the walking pad is on a level surface.
 - The belt may require lubrication (refer to Section 4.2).
- **Belt Slipping or Sticking:**
 - The belt may need lubrication (refer to Section 4.2).
 - The belt tension may need adjustment. Consult the user manual for instructions.
- **Display Not Working:**

- Check power connection.
- Ensure the remote control batteries are not depleted.

6. SPECIFICATIONS

Feature	Detail
Brand	Superun
Model Name	BA06
Color	Black
Product Dimensions	40"D x 20.4"W x 4.8"H
Item Weight	40 Pounds
Material	Alloy Steel
Maximum Speed	2.5 Miles per Hour
Minimum Speed	0.6 Miles per Hour
Maximum Horsepower	2.5 Horsepower
Maximum Weight Recommendation	250 Pounds
Display Type	LED
Connectivity Technology	Bluetooth
Assembly Required	No
Included Components	Remote Control
Folded Size	38.78"H x 20.17"W x 4.17"D inches

7. WARRANTY AND SUPPORT

The Superun Walking Pad comes with a **12-month warranty** from the date of purchase, covering manufacturing defects and significant operational failures under normal use. Please retain your proof of purchase for warranty claims.

7.1 Customer Support

For any questions, technical assistance, or warranty inquiries, our dedicated customer service team is available to assist you. We offer 24-hour email and phone support to ensure you receive prompt and effective help.

- **Email Support:** Refer to your purchase documentation or the official Superun website for contact email.
- **Phone Support:** Refer to your purchase documentation or the official Superun website for contact number.

You can also refer to the official User Manual PDF for more detailed information:[Download User Manual \(PDF\)](#)

