

## Bonnlo BLSB-B

# Bonnlo Massage Tattoo Chair (Model BLSB-B)

Instruction Manual

## 1. PRODUCT OVERVIEW

---

The Bonnlo Massage Tattoo Chair, Model BLSB-B, is a versatile and essential piece of equipment designed for various professional settings, including beauty salons, spas, tattoo parlors, and massage clinics. This chair offers comfort and adaptability for a wide range of services, ensuring both client satisfaction and operational efficiency.

Its robust construction and ergonomic design provide a stable and comfortable experience, supporting a maximum load of 150 kg (330 lbs). The chair features a soft leatherette surface and non-slip feet for enhanced safety and durability.

## Wide Usage



Facial Massage



SPA



Micro-plastic surgery



Foot Massage



Tattoo eyebrow



Tattoo

**Figure 1.1:** The Bonnlo Massage Tattoo Chair is suitable for a variety of professional applications, including facial massage, spa services, micro-plastic surgery, foot massage, eyebrow tattooing, and body tattooing.

## 2. FEATURES

- **Superb Comfort:** Equipped with a padded leatherette seat and backrest for client comfort during extended sessions.
- **Adjustable Design:** Headrest and footrest sections are easily adjustable to achieve comfortable angles for various services such as massages, manicures, and tattoos.
- **Easy Assembly:** Improved craftsmanship ensures a stronger, more stable, and easier connection for quick and straightforward installation.
- **Sturdy Construction:** Frame made of high-quality, heavy-duty steel. PVC leather upholstery is strong, waterproof, scratch-resistant, and easy to clean. High-density foam padding ensures durability and comfort.
- **High Weight Capacity:** Designed to support up to 150 kg (330 pounds), providing reliable service.
- **Versatile 3-Section Design:** Features an adjustable backrest and leg rest, allowing the chair to be laid flat or configured into various seating positions.
- **Integrated Armrests:** Side armrests are included to reduce client stress and enhance comfort.

### 3. SETUP AND ASSEMBLY

---

This section provides general guidelines for assembling your Bonnlo Massage Tattoo Chair. While specific steps may vary slightly, the overall process is designed for ease of installation.

1. **Unpack Components:** Carefully remove all parts from the packaging. Verify that all components listed in the packing list (if provided) are present and undamaged.
2. **Attach Base Frame:** Begin by assembling the main base frame components. Ensure all connections are secure and stable.
3. **Install Seat Section:** Place the main seat section onto the assembled base, aligning any pre-drilled holes or connection points. Secure with provided hardware.
4. **Connect Backrest:** Attach the backrest section to the main seat. Ensure the adjustment mechanism operates smoothly and locks securely into place.
5. **Attach Footrest/Leg Rest:** Connect the footrest/leg rest section to the main seat. Confirm that its adjustment mechanism also functions correctly.
6. **Install Armrests:** Secure the armrests to the designated points on the chair. Ensure they are firmly attached and do not wobble.
7. **Final Inspection:** Once assembled, gently test all adjustable parts and ensure the chair is stable before use. Check all bolts and screws for tightness.

**Safety Note: Always ensure the chair is on a flat, stable surface during assembly and operation. Do not overtighten screws, but ensure they are snug to prevent instability.**



**Figure 3.1:** The chair can be configured into multiple positions, from a flat bed to an upright chair, demonstrating its adaptable design and ease of assembly.

## 4. OPERATING INSTRUCTIONS

---

The Bonnlo Massage Tattoo Chair is designed for easy adjustment to accommodate various client needs and service types.

### 4.1 Adjusting the Backrest

To adjust the backrest, locate the adjustment lever or mechanism, typically found on the side or underneath the backrest section. Engage the mechanism to release the lock, then gently raise or lower the backrest to the desired angle. Once the desired position is achieved, release the mechanism to lock the backrest securely in place. The backrest can be adjusted up to 65 degrees from a flat position.

### 4.2 Adjusting the Footrest/Leg Rest

Similar to the backrest, the footrest/leg rest section has an adjustment mechanism. Engage this mechanism to allow movement, then position the footrest to the required angle for client comfort. Release the mechanism to lock it. The footrest can be adjusted up to 70 degrees from a flat position.

### 4.3 Converting to a Flat Bed

To convert the chair into a flat bed, fully recline the backrest and extend the footrest until both sections are horizontal and aligned with the seat. Ensure all sections are securely locked in their flat positions.

#### 4.4 Using Armrests

The armrests are designed to provide additional comfort and support. They can be positioned to suit the client's preference or removed if necessary for certain procedures (check if removable based on design). Ensure they are securely attached when in use.

## Adjustable Backrest & Footrest



**Figure 4.1:** The chair features an adjustable backrest (up to 65 degrees) and footrest (up to 70 degrees) for optimal client positioning.

## 5. MAINTENANCE

Proper maintenance will extend the life and appearance of your Bonnlo Massage Tattoo Chair.

### 5.1 Cleaning the Upholstery

The PVC leather upholstery is waterproof and scratch-resistant, making it easy to clean.

- For general cleaning, wipe the surface with a soft, damp cloth and mild soap solution.
- Avoid using harsh chemicals, abrasive cleaners, or solvents, as these can damage the material.

- Immediately wipe up any spills to prevent staining.
- Dry the surface thoroughly after cleaning.

## 5.2 Frame and Moving Parts

- Regularly inspect the steel frame for any signs of damage or loose connections.
- Tighten any loose bolts or screws as needed.
- Periodically check the adjustment mechanisms for smooth operation. If they become stiff, a small amount of silicone-based lubricant can be applied to pivot points (avoiding upholstery).
- Ensure the non-slip feet are intact and providing adequate grip.

## 6. TROUBLESHOOTING

---

This section addresses common issues you might encounter with your chair.

### 6.1 Chair Feels Unstable

- **Check Assembly:** Ensure all bolts and screws are securely tightened. Refer to Section 3: Setup and Assembly.
- **Level Surface:** Verify that the chair is placed on a flat, even surface. Uneven flooring can cause instability.
- **Inspect Feet:** Check if the non-slip feet are worn or damaged. Replace if necessary.

### 6.2 Adjustment Mechanisms Are Stiff

- **Clean Mechanisms:** Dust or debris might be obstructing the moving parts. Clean the pivot points and levers.
- **Lubrication:** Apply a small amount of silicone-based lubricant to the pivot points of the backrest and footrest adjustment mechanisms. Operate the mechanism several times to distribute the lubricant.
- **Obstructions:** Ensure no fabric or other objects are caught in the mechanism.

### 6.3 Upholstery Damage

- **Minor Scratches/Scuffs:** For minor surface marks, a specialized PVC leather repair kit may be used. Follow the kit's instructions carefully.
- **Tears/Punctures:** Significant damage may require professional repair or replacement of the affected section. Contact customer support for guidance.

## 7. SPECIFICATIONS

---

Feature	Specification
Model Number	BLSB-B
Color	Black
Material	PVC Leather and Metal Frame
Overall Dimensions (L x W x H)	72.83 x 31.5 x 27.56 inches (185 x 80 x 70 cm)

Feature	Specification
Item Weight	51.7 pounds (23.5 kg)
Weight Capacity	330 pounds (150 kg)
Special Features	Waterproof, Tough, Solid, Stable, Easy to Clean
Assembly Required	Yes



Figure 7.1: Detailed dimensions of the Bonnlo Massage Tattoo Chair in various configurations.

## 8. WARRANTY AND SUPPORT

For information regarding the product warranty, please refer to the documentation provided with your purchase or contact the seller directly. Warranty terms and conditions may vary.

If you require technical assistance, have questions about assembly, operation, or maintenance, or need to report a defect, please contact Bonnlo customer support through their official website or the retailer from

whom you purchased the product. Please have your model number (BLSB-B) and purchase date available when contacting support.

© 2023 Bonnlo. All rights reserved.