

[Manuals.plus](#) /

› [Wooask](#) /

› Wooask W10 Offline Language Translator Device User Manual

Wooask W10OFFLINE

Wooask W10 Offline Language Translator Device User Manual

Model: W10OFFLINE

Brand: Wooask

1. INTRODUCTION

The Wooask W10 Pro translator is an advanced AI translation device designed for seamless communication across various languages. It offers rapid response times and high accuracy for both online and offline translation needs, including voice and photo translation. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your device.



Figure 1: The Wooask W10 Offline Language Translator Device, showcasing its sleek design and user interface.

2. PACKAGE CONTENTS

Upon unboxing your Wooask W10 translator, please ensure all the following items are present:

- Wooask W10 Translator Device
- User Manual (this document)
- USB Type-C Charging Cable

3. SETUP

3.1 Initial Charging

Before first use, fully charge your Wooask W10 device using the provided USB Type-C cable. Connect the cable to the device's Type-C port and a compatible USB power adapter. A full charge typically takes 1-2 hours.

3.2 Powering On/Off

- **To Power On:** Press and hold the power button located on the side of the device until the screen illuminates.
- **To Power Off:** Press and hold the power button until a power-off prompt appears on the screen, then confirm.

3.3 Wi-Fi Connection

For online translation and software updates, connect your device to a Wi-Fi network:

1. From the main screen, tap on 'Settings'.
2. Select 'Wi-Fi' and toggle it on.
3. Choose your desired network from the list and enter the password if prompted.

3.4 Downloading Offline Language Packs

The Wooask W10 supports offline translation for 10 languages. To use this feature, you must download the language packs:

1. Ensure the device is connected to Wi-Fi.
2. From the main screen, tap on 'Offline Translation' or navigate through 'Settings' to 'Offline Download'.
3. Select the languages you wish to download for offline use.

HD Touch Screen

480*854 3.0" retina screen for easy operation and clear display



Figure 2: The device's 3.0-inch TFT(IPS) HD touch-screen, showing the main menu with options like Voice Translation, Sound Recording, Photo Translation, Offline Translation, and Settings.

4. OPERATING INSTRUCTIONS

4.1 Voice Translation

The device offers real-time two-way voice translation with high accuracy and a response time of less than 0.5 seconds.

1. From the main screen, tap on 'Voice Translation'.
2. Select the two languages for translation (e.g., French to English).
3. Hold down the designated button (usually a large central button) and speak clearly into the device's microphone. Release the button when finished speaking.
4. The translated text will appear on the screen and be spoken aloud.

Offline Voice Translation Between 10 Languages




Figure 3: The device supports offline voice translation between 10 languages, including English, Spanish, Mandarin, Japanese, Arabic, Russian, French, German, Korean, and Thai.

Product Parameters



Figure 4: Demonstrates the real-time two-way translation feature, showing conversations translated with 97% accuracy across 144 languages and accents.

4.2 Photo Translation

Translate text from images using the built-in camera:

1. From the main screen, tap on 'Photo Translation'.
2. Position the camera over the text you wish to translate. Ensure good lighting and clear focus.
3. Tap the capture button on the screen. The device will recognize and translate printed and handwritten text in 42 languages.

Photo Translation

Understand the text correspondingly in one shot



Figure 5: The photo translation feature supports 42 languages, allowing users to understand text from signs, menus, and documents instantly.

4.3 Sound Recording

The device includes a sound recording function for capturing audio.

- Tap 'Sound Recording' from the main menu to start or stop recordings.

4.4 Voice Selection

You can switch between male and female voices for the translated output to suit your preference.

- Navigate to 'Settings' and look for 'Voice Settings' or similar options to adjust.

5. MAINTENANCE

5.1 Battery Life & Charging

The Wooask W10 features a 1500mAh battery, providing up to 8 hours of continuous usage and 7 days of standby time. Always use the provided Type-C cable for optimal charging.



Figure 6: The device offers extended battery life with 8 hours of continuous translation and 7 days of long standby, powered by its 1500mAh battery.

5.2 Cleaning the Device

To maintain the device's appearance and functionality, gently wipe the screen and body with a soft, dry, lint-free cloth. Avoid using abrasive cleaners or solvents.

5.3 Software Updates

Periodically check for software updates to ensure optimal performance and access to new features. Connect to Wi-Fi and navigate to 'Settings' > 'Check Update'.

6. TROUBLESHOOTING

If you encounter issues with your Wooask W10 translator, try the following steps:

- **Device not turning on:** Ensure the device is sufficiently charged. Connect it to a power source for at least 30 minutes before attempting to power on again.
- **Inaccurate offline translation:** Verify that the required language packs have been fully downloaded. Offline translation accuracy may vary compared to online translation due to data limitations.
- **Poor voice recognition:** Speak clearly and at a moderate pace. Ensure there is minimal

background noise. Check microphone settings if available.

- **Screen unresponsive:** Try restarting the device. If the issue persists, ensure the battery is not critically low.
- **Connectivity issues:** For Wi-Fi problems, try forgetting the network and reconnecting, or restart your Wi-Fi router.

7. SPECIFICATIONS

Feature	Detail
Model Number	W10OFFLINE
Package Dimensions	6.3 x 3.43 x 1.73 inches
Item Weight	8.8 ounces
Battery	1 Lithium Ion battery (included)
Manufacturer	Wooask Tech.
First Available	July 10, 2023

Realtime Two-way Translation

97% Accuracy

144 Languages

0.5s Rapid Translation

How we have our own model?

Wie haben wir unser eigenes Modell?

...

Come abbiamo il nostro modello?

...

17:04

语言 翻译

我们现在自己的模式。
Now we have our own model

Now we have our own model
Come abbiamo il nostro modello?

我们现在自己的模式。
Now we have our own model

Now we have our own model
Come abbiamo il nostro modello?

Figure 7: An overview of the product's key parameters, including support for 144 languages, photo translation,

8. WARRANTY AND SUPPORT

Wooask products are synonymous with exceptional quality. While specific warranty details are not provided in this manual, please refer to the manufacturer's official website or your point of purchase for comprehensive warranty information and customer support options. For technical assistance or inquiries, contact Wooask Tech. customer service.