

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Fluentalk](#) /

› [Fluentalk T1 Mini Translator Device User Manual](#)

Fluentalk T1 Mini

Fluentalk T1 Mini Translator Device User Manual

Model: T1 Mini

1. INTRODUCTION

This manual provides detailed instructions for the safe and effective use of your Fluentalk T1 Mini Translator Device. Please read this manual thoroughly before operating the device and retain it for future reference.



Excuse me, can you do me a favor? We can talk through this translator.

fluentalk

Image 1: The Fluentalk T1 Mini Translator Device, shown from front and back, displaying a translation on its screen.

2. INITIAL SETUP

2.1 Package Contents

- Fluentalk T1 Mini Translator Device
- USB Type-C Charging Cable
- Lanyard
- User Manual (this document)

2.2 Charging the Device

Before first use, fully charge the device. Connect the provided USB Type-C cable to the device's charging port and a compatible USB power adapter (not included). The battery indicator on the screen will show charging status.

2.3 Powering On/Off

- **Power On:** Press and hold the Power button located on the top of the device until the screen illuminates.
- **Power Off:** Press and hold the Power button, then select 'Power Off' on the screen.

2.4 Initial Configuration

Upon first power-on, follow the on-screen prompts to:

1. Select your preferred system language.
2. Connect to a Wi-Fi network. This is recommended for optimal performance and software updates.
3. The 1-year free global mobile data plan will activate automatically upon device turn-on. No additional setup or SIM card insertion is required for this feature.

1-Year Free Global Mobile Data for 40 Languages



***The 1-Year Free Mobile Data is automatically activated when T1 Mini is turned on**

Image 2: The Fluentalk T1 Mini highlighting its 1-year free global mobile data feature, which activates automatically.

3. OPERATING INSTRUCTIONS

3.1 One-Click Instant Translation

The T1 Mini features a dedicated button for instant two-way translation.

1. On the main screen, select your native language and the target language.
2. Press and hold the side button (often labeled with a microphone icon).
3. Speak clearly into the device's microphone.
4. Release the button. The device will automatically recognize the spoken language and provide a translation in the selected target language, both audibly and on-screen.

Note: Cantonese, certain Arabic accents (Israel, Lebanon, Palestine, Tunisia), and Tamil accents (Singapore, Sri Lanka, Malaysia), Icelandic, Malay, and Urdu do not currently support One-Click translation.

One-Click Instant Translation

Automatic Language Recognition Technology



Simple Operation of 2-way Translation

Image 3: A hand holding the Fluentalk T1 Mini, demonstrating the one-click instant translation feature with automatic language recognition.

3.2 Offline Translation

The device supports offline translation for situations without internet access.

1. Navigate to 'System Settings' > 'Offline Language Package'.
2. Download up to 4 desired offline language packages. Available language pairs include Chinese, English, Japanese, French, Spanish, Korean, Russian, and German.
3. Once downloaded, the device can perform translations for these pairs without an internet connection.

Supporting Offline Translation In 13 Languages Pairs



The image shows an airline attendant in a white uniform and blue scarf leaning over a passenger seated in an airplane cabin. The attendant is pointing at the passenger's smartphone. In the foreground, a smartphone displays the Fluentalk app interface. The screen shows a Spanish-English translation: "Disculpe, ¿puede hacerme un favor? Podemos hablar a través de este traductor." translated to "Excuse me, can you do me a favor? We can talk through this translator." and "Yes. How can I help you?" translated to "Sí. ¿Cómo puedo ayudarle?". The Fluentalk logo is visible at the bottom of the phone screen.

 EN <-> ZH,FR,ES,JA,RU,KO,DE
ZH <-> EN,FR,ES,JA,RU,KO,DE

*You can download a maximum of 4 offline translation packages

Image 4: An airline attendant assisting a passenger, illustrating the use of the Fluentalk T1 Mini for offline translation in various language pairs.

3.3 Photo Translation

The T1 Mini can translate text from images.

1. Swipe right on the main screen to access the Photo Translation feature.
2. Point the device's camera at the text you wish to translate (e.g., menus, road signs).
3. Tap the screen to capture the image.
4. The device will display the translated text on-screen. This feature supports 39 languages.

Instant Photo Translation In 39 Languages



Image 5: Three scenarios demonstrating instant photo translation: translating a menu, signage, and a hotel ticket using the Fluentalk T1 Mini.

3.4 User Interface and Navigation

The T1 Mini features a user-friendly interface with touch-screen navigation.

- **Swiping:** Swipe left or right to access different features and settings.
- **Swiping Down:** Swipe down from the top of the screen to access quick settings like Wi-Fi, Airplane Mode, font size, and screen brightness.
- **Volume Control:** Use the dedicated volume buttons on the side of the device to adjust audio output.

Slide-to-operate Clear Audio and Font



Image 6: A hand interacting with the Fluentalk T1 Mini's touchscreen, illustrating the slide-to-operate functionality and clear font display.

4. MAINTENANCE

4.1 Cleaning the Device

Use a soft, dry, lint-free cloth to clean the device. Avoid using abrasive cleaners, solvents, or aerosol sprays directly on the device.

4.2 Battery Care

- Avoid exposing the device to extreme temperatures.
- Do not fully discharge the battery frequently.
- If storing the device for an extended period, charge it to approximately 50% before storage.

4.3 Software Updates

Periodically check for software updates in the 'System Settings' menu to ensure optimal performance and access to new features. Connect to Wi-Fi for updates.

5. TROUBLESHOOTING

Issue	Possible Cause	Solution
Device does not power on	Low battery; device malfunction	Charge the device for at least 30 minutes. If issue persists, contact support.
Translation lag or inaccuracy	Poor internet connection; unclear speech; unsupported accent/language	Ensure stable Wi-Fi or mobile data connection. Speak clearly and at a moderate pace. Check if the language/accent is fully supported for instant translation.
Offline translation not working	Offline language package not downloaded or corrupted	Verify that the required offline language packages are downloaded and installed correctly in settings.
Photo translation issues	Poor lighting; blurry image; text too small/complex	Ensure adequate lighting. Hold the device steady to avoid blur. Position the device closer to the text if it's small.
Short battery life	High screen brightness; continuous use of mobile data; aging battery	Reduce screen brightness. Limit continuous use of mobile data when not needed. Consider battery replacement if device is old.

6. SPECIFICATIONS

- **Model:** T1 Mini
- **Product Dimensions:** 3.58 x 2.15 x 0.53 inches
- **Item Weight:** 8.1 ounces
- **Battery:** 1 Lithium Ion battery (included)
- **Storage Capacity:** 8GB (for system and speech records)
- **Connectivity:** Wi-Fi, 1-Year Global Mobile Data (included)
- **Online Translation Languages:** 40 languages
- **Offline Translation Languages:** 13 language pairs (from 8 languages: Chinese, English, Japanese, French, Spanish, Korean, Russian, German)
- **Photo Translation Languages:** 39 languages

7. WARRANTY AND SUPPORT

7.1 Warranty Information

For detailed warranty information, please refer to the warranty card included in your product packaging or visit the official Fluentalk website. The warranty typically covers manufacturing defects for a specified period from the date of purchase.

7.2 Customer Support

If you encounter any issues not covered in this manual or require further assistance, please contact Fluentalk customer support. Support is available in English, Spanish, and Chinese.

Online Support: Visit the official Fluentalk website for FAQs, troubleshooting guides, and contact forms.

Email Support: Refer to your product packaging or the official website for the support email address.