

[Manuals.plus](#) /

› [Devia](#) /

› Devia Watch Pro 5 Smartwatch User Manual

Devia Pro 5

Devia Watch Pro 5 Smartwatch User Manual

Model: Pro 5 | Brand: Devia

1. INTRODUCTION

This manual provides essential instructions for the safe and efficient use of your Devia Watch Pro 5 Smartwatch. Please read this manual thoroughly before using the device to ensure proper operation and to understand its features. Keep this manual for future reference.

2. PRODUCT OVERVIEW

The Devia Watch Pro 5 is a feature-rich smartwatch designed to enhance your daily activities with smart notifications, fitness tracking, and Bluetooth call capabilities.



Figure 2.1: Front view of the Devia Watch Pro 5 Smartwatch. This image displays the watch's circular display with a dynamic red and black digital interface, indicating current time, date, heart rate, and step count. The watch features a black silicone strap and a crown button on the right side.

2.1 Components

- **Display:** 1.36-inch circular touchscreen for interaction and information display.
- **Side Button/Crown:** Used for navigation, power on/off, and menu access.
- **Strap:** Interchangeable strap for comfortable wear.
- **Sensors (Rear):** Heart rate sensor and charging contacts located on the back of the watch.



Figure 2.2: Rear view of the Devia Watch Pro 5 Smartwatch. This image highlights the back of the watch, featuring the optical heart rate sensor in the center and four metallic charging contacts. The watch casing is black, and the strap is also black silicone.

3. SETUP

3.1 Unboxing

Upon opening the package, ensure all items are present:

- Devia Watch Pro 5 Smartwatch
- Charging Cable
- User Manual (this document)

3.2 Charging the Device

1. Connect the magnetic charging cable to the charging contacts on the back of the watch. Ensure proper alignment.
2. Connect the USB end of the charging cable to a standard USB power adapter (5V/1A recommended) or a computer's USB port.
3. The watch display will indicate charging status. Allow approximately 2-3 hours for a full charge.

Note: For optimal battery life, fully charge the watch before its first use.

3.3 Power On/Off

- **Power On:** Press and hold the side button/crown for a few seconds until the Devia logo appears.
- **Power Off:** From the watch face, swipe down to access quick settings, or navigate to the settings menu. Select "Power Off" and confirm. Alternatively, press and hold the side button/crown, then select "Power Off" from the options.

3.4 Pairing with a Smartphone

To unlock the full functionality of your Devia Watch Pro 5, pair it with your smartphone via Bluetooth.

1. Ensure your smartphone's Bluetooth is enabled.
2. Download and install the companion application for your Devia Watch Pro 5 from your smartphone's app store. (Specific app name not provided, refer to product packaging or quick start guide for app details).
3. Open the companion application on your smartphone and follow the on-screen instructions to create an account or log in.
4. In the app, select "Add Device" or "Pair New Device" and choose "Devia Watch Pro 5" from the list of available devices.
5. Confirm the pairing request on both your smartphone and the smartwatch.

Tip: Keep your watch and smartphone close during the pairing process.

4. OPERATING THE SMARTWATCH

4.1 Basic Navigation

- **Swipe Up:** Access notifications.
- **Swipe Down:** Access quick settings (e.g., brightness, battery saver, DND).
- **Swipe Left/Right:** Navigate through widgets or main menu screens (e.g., activity tracker, heart rate, weather).
- **Tap:** Select an item or open an application.
- **Press Side Button/Crown:** Return to the watch face, open the app menu, or power on/off.

4.2 Bluetooth Calls

The Devia Watch Pro 5 supports Bluetooth calls, allowing you to make and receive calls directly from your wrist when connected to your smartphone.

- **Making a Call:** Access the dialer or contacts list on your watch. Tap to select a contact or dial a number.
- **Receiving a Call:** When a call comes in, the watch will display the caller ID. Tap the green icon to answer or the red icon to reject.

4.3 Notifications

Receive notifications from your paired smartphone directly on your watch. Swipe up from the watch face to view recent notifications. You can customize which app notifications appear on your watch through the companion application.

4.4 Fitness Tracking

The watch monitors various fitness metrics:

- **Heart Rate:** Continuous or on-demand heart rate monitoring. Access the heart rate widget or app to view

data.

- **Step Count:** Tracks your daily steps.
- **Calories Burned:** Estimates calories burned based on activity.
- **Sleep Monitoring:** Tracks sleep patterns (requires wearing the watch during sleep).



Figure 4.1: Devia Watch Pro 5 displaying fitness and weather data. This watch face shows the current time, date, weather conditions (24°C), step count (20375), calories burned (4258), and heart rate (107 bpm). The background features a cosmic theme.

4.5 Changing Watch Faces

Customize the appearance of your watch by changing the watch face. Long-press on the current watch face, then swipe left or right to browse available options. Tap to select a new watch face. Additional watch faces may be available through the companion application.





Figure 4.2: Examples of customizable watch faces. The left image shows an analog green watch face with a date display. The right image displays a vibrant red digital watch face with a cultural design, indicating time, date, and various health metrics.

5. MAINTENANCE

5.1 Cleaning

Regularly clean your Devia Watch Pro 5 to maintain its appearance and functionality.

- Wipe the screen and casing with a soft, lint-free cloth.
- For stubborn smudges, slightly dampen the cloth with water. Avoid harsh chemicals or abrasive materials.
- Clean the charging contacts periodically with a dry cloth to ensure good connection.

5.2 Water Resistance

While the Devia Watch Pro 5 may offer some resistance to splashes, it is not designed for swimming or prolonged submersion. Avoid exposing the watch to hot water, steam, or high-velocity water. Damage caused by liquid exposure beyond typical daily use may not be covered under warranty.

5.3 Battery Care

- Avoid extreme temperatures, which can degrade battery performance.
- Do not allow the battery to fully discharge frequently.
- If storing the watch for an extended period, charge it to approximately 50% and power it off.

6. TROUBLESHOOTING

If you encounter issues with your Devia Watch Pro 5, refer to the following common problems and solutions:

- **Watch will not power on:**
 - Ensure the watch is fully charged. Connect it to the charger for at least 30 minutes.
 - Press and hold the side button/crown for 10-15 seconds to attempt a forced restart.
- **Cannot pair with smartphone:**
 - Ensure Bluetooth is enabled on your smartphone and the watch.
 - Make sure the watch is within Bluetooth range of your phone.
 - Restart both your watch and smartphone.
 - Try unpairing the device from your phone's Bluetooth settings and re-pairing through the companion app.
- **Inaccurate heart rate readings:**
 - Ensure the watch is worn snugly on your wrist, not too tight or too loose.
 - Clean the heart rate sensor on the back of the watch.
 - Avoid excessive movement during readings.
- **Short battery life:**
 - Reduce screen brightness.
 - Disable unnecessary notifications.
 - Limit continuous heart rate monitoring if not required.
 - Ensure the watch is fully charged.

If problems persist, contact customer support for further assistance.

7. SPECIFICATIONS

Feature	Detail
Brand	Devia
Model	Pro 5
Screen Size	1.36 inches
Battery Capacity	300mAh (Up to 7 Days)
Bluetooth Calls	Supported
Connectivity Technology	Bluetooth
Operating System	Android Wear 2.0
Memory Storage Capacity	1 GB

Feature	Detail
Special Features	Notifications
Item Shape	Square
GPS	No GPS

***Note:** Specifications are subject to change without prior notice. Battery life may vary based on usage and settings.*

8. WARRANTY AND SUPPORT

The Devia Watch Pro 5 comes with a standard manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, including warranty period and coverage details.

For technical support, troubleshooting assistance, or warranty claims, please contact your retailer or the official Devia customer service channels. Contact information can typically be found on the product packaging or the official Devia website.