

[Manuals.plus](#) /

> [Leggett & Platt](#) /

> Leggett & Platt Prodigy PT Adjustable Base User Manual

Leggett & Platt Prodigy PT (4AW635)

Leggett & Platt Prodigy PT Adjustable Base User Manual

1. INTRODUCTION

The Leggett & Platt Prodigy PT Adjustable Base is designed to enhance your sleep experience with advanced technology and comfort features. This manual provides essential information for the safe and effective setup, operation, and maintenance of your adjustable base. It integrates technology and comfort, offering features like anti-snore and zero gravity positions, remote and app control, USB charging, under-bed lighting, and full-body massage.



Image: The Leggett & Platt Prodigy PT Adjustable Base, showcasing its sleek design and integration into a modern bedroom.

2. SAFETY INFORMATION

Please read and understand all safety instructions before assembling or operating your adjustable base. Failure to do so may result in injury or damage to the product.

- Always follow the assembly instructions carefully to prevent instability or injury.
- Do not exceed the maximum weight recommendation of 850 pounds.
- Be cautious of moving parts during use and assembly. Keep hands and feet clear of moving mechanisms.
- Ensure the power cord is not pinched or damaged during setup or operation.
- Keep children and pets away from the adjustable base during operation.

3. SETUP

Follow these steps for initial setup of your Prodigy PT Adjustable Base:

1. **Unpack Components:** Carefully remove all components from the packaging, including the base, legs, remote, and retention bar.
2. **Attach Legs:** Securely screw the adjustable legs into the designated points on the base. Ensure all legs are tightened for stability.
3. **Install Retention Bar:** Attach the mattress retention bar at the foot of the bed to prevent the mattress from sliding during adjustments.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet.
5. **Remote Pairing:** The capacitive-touch wireless remote should be pre-paired. If not, refer to the specific remote pairing instructions included in your product packaging.
6. **App Setup:** Download the Leggett & Platt app from your device's app store (compatible with Apple and Android devices). Follow the in-app instructions to connect your base via Bluetooth.

4. OPERATING INSTRUCTIONS

Your Prodigy PT Adjustable Base offers multiple ways to control its features:

4.1. Wireless Remote Control

The included capacitive-touch wireless remote allows for easy adjustment of your bed. Familiarize yourself with the button layout:

PRODIGY™

PT



Image: The remote control for the Prodigy PT Adjustable Base, showing various function buttons.

- **Head/Foot Articulation:** Use the 'HEAD' and 'FOOT' arrow buttons to raise or lower the head and foot sections independently.
- **Pillow Tilt:** The 'PILLOW' arrow buttons adjust the pillow articulation for optimal head and neck support.
- **Zero Gravity (ZG):** Press the 'ZG' button to activate the Zero Gravity preset position, which elevates your head and feet to promote circulation and relieve pressure.
- **Anti-Snore:** The 'SNORE' button quickly adjusts the head section to a position that may help reduce snoring.
- **Massage:** Use the 'MESSAGE' button to activate the full-body dual massage with wave technology. Adjust intensity and patterns as desired.
- **Programmable Positions:** The 'MEM' (Memory) buttons allow you to save and recall your favorite positions. The base includes reprogrammable anti-snore and zero gravity positions, plus one customizable position.
- **One-Touch Flat:** Press the 'FLAT' button to quickly return the bed to a flat position.
- **Under-Bed Light (UBL):** Activate the under-bed lighting for ambient illumination or as a night light.
- **Flashlight:** The remote includes a convenient flashlight feature.

4.2. App Control

Control your adjustable base directly from your smartphone or tablet using the dedicated app. The app provides all remote functionalities and additional customization options.

4.3. Voice Control (Alexa Integration)

The Prodigy PT base is Bluetooth-enabled and can be integrated with Alexa for voice commands through the LP Comfort Connect skill. This allows for seamless control within your smart home environment.

Your browser does not support the video tag.

Video: Demonstrates the Leggett & Platt LP Comfort Connect system with Alexa integration, showing how voice commands can adjust the bed and interact with other smart home devices.

4.4. Wallhugger Technology

Leggett & Platt's Wallhugger engineering ensures that as you elevate the head section, the bed simultaneously glides back, keeping your nightstand and other bedside items within easy reach.

4.5. USB Charging Ports

The base includes convenient USB-A and USB-C charging ports for your electronic devices.



Image: Close-up view of the integrated USB-A and USB-C charging ports on the Prodigy PT base.

5. MAINTENANCE

To ensure the longevity and optimal performance of your adjustable base, follow these maintenance guidelines:

- **Cleaning:** Wipe the base frame with a damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Check Connections:** Periodically inspect all electrical connections and cables to ensure they are secure and undamaged.
- **Moving Parts:** Do not lubricate any moving parts unless specifically instructed by Leggett & Platt customer service.

6. TROUBLESHOOTING

If you encounter issues with your adjustable base, try the following solutions:

- **No Power:** Ensure the power cord is securely plugged into a working outlet. Check your home's circuit breaker.
- **Remote Not Responding:** Replace the batteries in the wireless remote. If the issue persists, try repairing the remote according to the instructions in your product packaging.
- **Base Not Moving:** Check for any obstructions under the bed that might be preventing movement. Ensure the weight capacity is not exceeded.
- **Unusual Noises:** Minor noises during operation are normal. If you hear loud or persistent grinding/squeaking, discontinue use and contact customer support.
- **App Connectivity Issues:** Ensure Bluetooth is enabled on your device and the base is powered on. Try restarting the app or your device.

For persistent issues, please refer to the Warranty & Support section.

7. SPECIFICATIONS

Feature	Detail
Model Number	4AW635
Size	King (U.S. Standard)
Product Dimensions	80"L x 76"W x 5"H
Special Features	Adjustable, Wireless Remote, Pillow Tilt, Wallhugger, Zero Clearance, Dual Massage with Wave, USB Charging Ports
Color	Black
Material	Metal frame with fabric finish
Included Components	Legs, Remote, Retention Bar
Compatible Mattress Size	Eastern King
Assembly Required	Yes
Ground To Item Distance	1 Inches (adjustable legs)
Item Weight	275 pounds
Weight Capacity	850 pounds

8. WARRANTY

Leggett & Platt has a long-standing reputation for quality and reliability in adjustable bed frames. They maintain a nationwide network of over 600 technicians to handle warranty service efficiently. When purchasing from an authorized dealer like Synergy Health, you benefit from their expertise and assistance in resolving any warranty-related issues, ensuring timely communication and resolution.

Your browser does not support the video tag.

Video: Provides an overview of the Leggett & Platt Prodigy LBR Adjustable Bed, highlighting its features and the brand's commitment to quality and service.

9. SUPPORT

For further assistance, technical support, or warranty claims, please contact your authorized dealer or Leggett & Platt customer service. Ensure you have your model number (4AW635) and proof of purchase available when contacting support.