

[Manuals.plus](#) /

› [SANODESK](#) /

› SANODESK Electric Sit-Stand Desk User Manual

SANODESK 75x160 cm White

SANODESK Electric Sit-Stand Desk User Manual

Model: 75x160 cm White

1. INTRODUCTION

Thank you for choosing the SANODESK Electric Sit-Stand Desk. This manual provides essential information for the safe and efficient operation of your new desk. Please read it thoroughly before assembly and use, and keep it for future reference.



The SANODESK Electric Sit-Stand Desk in a typical office setup, showcasing its spacious white desktop and sturdy white frame, equipped with multiple monitors, a keyboard, mouse, and other office essentials.

2. SAFETY INFORMATION

To ensure safe operation and prevent injury or damage, please adhere to the following safety guidelines:

- **Caution:** Do not use if the desk is damaged or unstable.
- Do not place heavy or sharp objects on the desktop that exceed the recommended load capacity.
- Do not use if power cables are damaged or exposed.
- Do not use if electrical components are wet or damaged.
- Do not overload the desk beyond the recommended load capacity of **70 kg**.
- Use with caution to avoid pinching or crushing injuries during height adjustments. Keep hands and objects clear of moving parts.
- Ensure the desk is placed on a level surface.

3. FEATURES

- **Simplified Design:** The desk's sleek and minimalist design adds a touch of elegance to any workspace. The spacious full-length desktop provides ample space for your work essentials, while clean lines and a smooth finish create a modern and professional ambience.
- **Smart Memory Panel:** The advanced LED control panel offers 2 memory preset keys. Adjust your working or sitting position with the adjustable height ranging from 71 cm to 117 cm.
- **Fall-Resistant and Reliable:** With its solid construction and 70 kg load capacity, this desk offers stability and durability for all your work essentials.
- **Seamless Memory Control:** The user-friendly control panel with memory function allows you to easily customize and save your preferred table height settings. With a simple press of a button, you can effortlessly switch between different heights.
- **Quiet Operation:** Enjoy a quiet and distraction-free work environment thanks to the ultra-quiet motor that operates below 51 dB.

SMOOTH AND QUIET MOVEMENT

operates with minimal noise, ideal for maintaining concentration and productivity



This graph illustrates the quiet operation of the SANODESK desk, demonstrating its noise level is below 51 dB, significantly quieter than typical desk movements (80dB) or other products (60dB), ensuring a peaceful work environment.

SECURE & FASHIONABLE WITH CURVED EDGES

A close-up photograph of the SANODESK desk's corner, showing the smooth, rounded white edge of the desk top and the light-colored wood-grain panel below. A black control panel with several buttons is visible on the left. An orange curved line highlights the rounded corner, with an orange speech bubble containing the text 'Safe round corner design' pointing to it.

Safe round corner design

A close-up view highlighting the secure and fashionable curved edges of the SANODESK desk, along with its CARB and TSCA Title VI certifications, indicating compliance with formaldehyde emission standards for enhanced safety.

4. SETUP AND ASSEMBLY

While specific assembly instructions are provided with your product packaging, here is a general overview of the setup process:

1. **Unpack Components:** Carefully remove all parts from the packaging and verify against the parts list in your included manual.
2. **Assemble Frame:** Attach the lifting columns to the foot supports, ensuring all screws are securely tightened.
3. **Attach Desktop:** Place the desktop upside down on a soft, clean surface. Align the assembled frame with the pre-drilled holes on the desktop and secure it with the provided screws.
4. **Install Control Panel:** Mount the control panel to the underside of the desktop in the designated area.
5. **Connect Cables:** Connect all motor and control panel cables to the control box. Ensure all connections are firm.
6. **Cable Management:** Use the included cable ties or clips to organize and secure all cables, preventing

tangles and damage.

7. **Initial Calibration:** After assembly, plug in the desk. Perform an initial calibration as per the operating instructions to synchronize the motors.

5. OPERATING INSTRUCTIONS

5.1 Control Panel Overview



A detailed view of the SANODESK smart control panel, showing the 'Up Down' arrows for height adjustment, the 'Reset' button, and the 'Sit / Stand' preset buttons for quick height changes.

- **Up/Down Arrows (▲ / ▼):** Press and hold to manually adjust the desk height up or down. Release the button to stop at the desired height.
- **Memory Presets (Sit/Stand Icons):** The control panel features two preset buttons (often depicted as a sitting person and a standing person icon). Press one of these buttons to automatically move the desk to a pre-saved sitting or standing height.
- **Memory Setting:** To save a preferred height, adjust the desk to the desired position using the Up/Down arrows. Then, press and hold one of the memory preset buttons until the display flashes or a beep is heard, indicating the height has been saved.

- **Reset Button (C or R):** If the desk encounters an error or needs recalibration, press and hold the reset button until the desk moves to its lowest position and then slightly rises, indicating a successful reset.

5.2 Height Adjustment Range



This image illustrates the adjustable height range of the SANODESK, showing a minimum height of 71 cm and a maximum height of 116 cm, accommodating various user preferences for sitting and standing positions.

The desk can be adjusted from a minimum height of **71 cm** to a maximum height of **117 cm**.

5.3 Anti-Collision System

The desk is equipped with an anti-collision system. If the desk encounters an obstacle during movement (up or down), it will automatically stop and reverse slightly to prevent damage or injury. Ensure the area around the desk is clear before adjusting height.

6. MAINTENANCE

- **Cleaning:** Wipe the desktop and frame with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals.
- **Cable Check:** Periodically inspect all cables for signs of wear or damage. Ensure they are securely

connected and not pinched.

- **Screw Tightness:** Occasionally check that all assembly screws are tight to maintain stability. Do not overtighten.
- **Motor Care:** The motor is maintenance-free. Avoid disassembling the motor or control box.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Desk does not move.	Power cable disconnected; motor error; overload.	Check power connection. Perform a reset (see Operating Instructions). Reduce weight on desk.
Desk moves unevenly.	Unbalanced load; motor synchronization issue.	Distribute weight evenly. Perform a reset.
Anti-collision system triggers frequently.	Obstruction; sensitivity setting.	Ensure clear path for desk movement. (Consult full manual for sensitivity adjustment if available).
Desk makes unusual noises.	Loose screws; internal motor issue.	Check and tighten all screws. If noise persists, contact customer support.

8. SPECIFICATIONS

Specification	Detail
Brand	SANODESK
Model Number	3
Color	White
Product Dimensions (L x W x H)	160 x 75 x 110 cm
Adjustable Height Range	71 cm to 117 cm
Load Capacity	70 kg
Noise Level	Below 51 dB
Base Material	Wood, Engineered Wood, Metal
Special Feature	Adjustable, Electric

| 60KG LOAD CAPACITY

Material 25% more robust than alternatives,
ensuring unparalleled stability



This image highlights the robust construction of the SANODESK, indicating a load capacity of 60kg, which is described as 25% more robust than alternatives, ensuring unparalleled stability for your workspace equipment.

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your product or contact SANODESK directly through their official channels. Keep your purchase receipt as proof of purchase for any warranty claims.

SANODESK Contact Information: Please visit the SANODESK brand store on Amazon or their official website for the most up-to-date contact details and support resources.