

[Manuals.plus](#) /

› [XBllcyiv](#) /

› XBllcyiv Mini Wireless Handheld Vacuum Cleaner Instruction Manual

XBllcyiv 365411

XBllcyiv Mini Wireless Handheld Vacuum Cleaner

Model: 365411

INTRODUCTION

This manual provides essential information for the safe and efficient operation and maintenance of your XBllcyiv Mini Wireless Handheld Vacuum Cleaner. Designed for versatility, this 2-in-1 device offers powerful vacuuming and blowing capabilities, making it ideal for cleaning car interiors, keyboards, and various areas within your home or office. Please read this manual thoroughly before first use and retain it for future reference.



Image: The XBlincy Mini Wireless Handheld Vacuum Cleaner shown with its included accessories, including the crevice tool and brush attachment.

SETUP

Before using your vacuum cleaner, ensure all components are present and the device is fully charged.

Package Contents

- Mini Wireless Handheld Vacuum Cleaner (Main Unit)
- Crevice Tool
- Brush Attachment
- USB Charging Cable (Type-C)
- User Manual

STRONG POWER FAST SUCTION DUST



**120 WATTS
OF POWER**



4200RPM



8000PA



Image: A detailed view of the vacuum cleaner's main components, including the filter, switch button, dust collection box, and Type-C charging port.

Initial Charging

Connect the provided USB charging cable to the Type-C port on the vacuum cleaner and plug the other end into a compatible USB power adapter (not included). The device features a 4000mAh lithium-ion battery. A full charge from empty typically takes approximately 3-4 hours. Ensure the device is fully charged before its first use to maximize battery life and performance.

Attaching Accessories

To attach the crevice tool or brush attachment, simply align the accessory with the suction nozzle and push firmly until it clicks into place. Ensure a secure fit for optimal performance.

OPERATING INSTRUCTIONS

Powering On/Off

Press the power button located on the handle to turn the vacuum cleaner on. Press the button again to turn it off.

Using Vacuum Mode

For vacuuming, attach the desired nozzle (crevice tool for tight spaces, brush for surfaces like keyboards or car seats). Direct the nozzle towards the area to be cleaned. The powerful 6000PA suction will effectively pick up dust, crumbs, pet hair, and other small debris.

WASHABLE AND REUSABLE FILTER ELEMENTS



1. Rotate clockwise to remove the dust collector to take out the filter



2. Take out the filter from the dust bin



3. Empty the dust bin



4. Dust bin and filter can be washed together repeatedly

Image: The wireless vacuum cleaner being used to clean a car interior, demonstrating its portability and effectiveness in automotive applications.

Using Blower Mode

The vacuum cleaner also functions as a blower. To use this feature, remove any attachments from the front nozzle. The air outlet is located at the rear of the device. Direct the rear of the vacuum towards the area where you wish to blow air, such as clearing dust from computer keyboards or hard-to-reach crevices.

LED Light Function

The built-in LED light automatically illuminates when the vacuum is powered on. This feature provides enhanced visibility in dark or dimly lit areas, such as under car seats or in tight corners, ensuring thorough cleaning.

LED LIGHT



Equipped with LED lights to illuminate every dark corner



Image: The vacuum cleaner in operation, highlighting its integrated LED light that illuminates the cleaning path for improved visibility in dark spaces.

MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

Emptying the Dust Collection Box

1. Rotate the dust collection box clockwise to detach it from the main unit.
2. Carefully remove the filter from inside the dust collection box.
3. Empty the collected debris into a waste bin.

Cleaning the Filter

The filter is washable and reusable. After emptying the dust collection box:

1. Rinse the filter under running water until it is clean.
2. Allow the filter to air dry completely before reinserting it into the dust collection box. Ensure it is fully dry to prevent damage

to the motor.

3. Once dry, place the filter back into the dust collection box and reattach the box to the main unit by rotating it counter-clockwise until secure.



Image: A visual guide demonstrating the process of disassembling the dust collection box, removing the filter, emptying debris, and washing the filter for reuse.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Low Suction Power	Dust collection box is full; Filter is clogged; Battery is low.	Empty the dust collection box; Clean or replace the filter; Recharge the battery.
Device Not Turning On	Battery is depleted; Power button malfunction.	Charge the device fully; If problem persists, contact customer support.

Problem	Possible Cause	Solution
Charging Issues	Faulty charging cable or adapter; Charging port damage.	Try a different USB charging cable and adapter; Ensure charging port is clean and undamaged.

SPECIFICATIONS

- Brand:** XBllyiv
- Model Name:** Mini Vacuum Cleaner for Car (Model: 365411)
- Power:** 120 Watts
- Suction Power:** Up to 6000PA
- Battery Capacity:** 4000mAh (2 x 2000mAh lithium-ion battery packs)
- Runtime:** Approximately 20 minutes (may vary with cleaning load)
- Charging Time:** 3-4 hours (from empty)
- Filter Type:** Washable and Reusable
- Form Factor:** Handheld
- Product Dimensions:** 3.2"L x 1.26"W x 1.1"H
- Item Weight:** 4.8 ounces
- Special Features:** Built-in LED light, 2-in-1 Vacuum/Blower function

Wireless Car Vacuum Cleaner

Greater suction, easy suction
Easily remove dust, debris,
soot, pet hair, etc. from the car interior,
giving the entire vehicle a new look



Image: The compact size of the vacuum cleaner is illustrated by comparing it to a standard smartphone, emphasizing its portability.

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your product packaging or contact the manufacturer directly. Keep your purchase receipt as proof of purchase for any warranty claims.