

Brabrety Queen Size Murphy Bed Wall Bed

Brabrety Queen Size Murphy Bed Wall Bed Instruction Manual

Model: Queen Size Murphy Bed Wall Bed

INTRODUCTION

This manual provides essential instructions for the safe assembly, operation, and maintenance of your Brabrety Queen Size Murphy Bed Wall Bed. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

SAFETY INFORMATION

- **Weight Limit:** Do not exceed the maximum weight limit of 750 lbs (340 kg) for the bed frame.
- **Moving Parts:** Exercise caution around all moving parts, hinges, and folding mechanisms to prevent pinch injuries. Keep hands and fingers clear during operation.
- **Assembly:** Ensure the bed frame is properly assembled and securely fastened according to all instructions. Incorrect assembly can lead to instability or collapse, posing a risk of injury.
- **Wall Anchoring:** This Murphy bed **must be securely anchored to a wall stud** to prevent tipping. Failure to properly anchor the unit can result in serious injury or death.
- **Mattress Compatibility:** Use a mattress with a maximum thickness of 8 inches (20 cm). Thicker mattresses may prevent proper folding or damage the mechanism.
- **Modification:** Do not modify the bed frame or its components. Unauthorized modifications may compromise safety and void any warranty.

SETUP AND ASSEMBLY

Assembly of this Murphy bed requires careful attention to detail and may require two or more adults. Organize all parts and hardware before beginning. Tools for assembly are included.

LED lights may not be included and might need to be sourced separately.

Visual Reference for Assembly

Below are images illustrating the product in its folded and unfolded states, as well as key components.



Figure 2: Bed in folded cabinet configuration. The bed is concealed, and the unit functions as a cabinet with shelves and drawers.



Figure 3: Bed in unfolded configuration, ready for use. The bed frame is extended from the cabinet.



Figure 4: Gas spring mechanism. This component assists in the smooth and controlled movement of the bed.



Figure 5: Integrated drawers. These provide additional storage space within the unit.

OPERATING INSTRUCTIONS

Folding the Bed into a Cabinet

1. Remove all bedding and the mattress from the bed frame.
2. Lift the bed frame from the foot end. The gas springs will assist in the upward movement.
3. Guide the bed frame smoothly into the cabinet opening until it is fully vertical and secured. Ensure the support legs are folded away.

Unfolding the Bed from a Cabinet

1. Gently pull the handles on the cabinet front to release the bed frame.
2. Slowly lower the bed frame towards the floor. The gas springs will provide resistance for a controlled descent.
3. Extend the support legs at the foot of the bed to ensure stability.
4. Place your mattress and bedding onto the bed frame.

Using Shelves and Drawers

The integrated shelves and drawers can be used for storing various items. Ensure that items placed on shelves or in drawers do not obstruct the bed's folding or unfolding mechanism.

LED Lights Operation

The LED lights located at the top of the unit provide ambient lighting. If a power supply was not included, you will need to connect one to activate the lights. Consult the specific wiring instructions for the LED light components.



Figure 6: Integrated LED lights. These lights provide illumination when the bed is in use or folded.

MAINTENANCE

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Hardware Check:** Periodically inspect all screws, bolts, and fasteners to ensure they are tight. Retighten as necessary.
- **Mechanism Inspection:** Regularly check the gas springs and pivot points for smooth operation. Apply a silicone-based lubricant if any squeaking or stiffness occurs. Do not use oil-based lubricants.
- **Mattress Support:** Inspect the flexible slats for any signs of wear or damage. Replace any broken slats to maintain proper mattress support.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Difficulty during assembly	Confusing instructions, poorly labeled parts, misaligned holes.	Review instructions carefully, organize hardware, and ensure correct orientation of parts. If holes are misaligned, contact customer support.
Bed difficult to lift/lower (gas springs)	Gas springs not properly installed or too stiff.	Ensure gas springs are correctly attached. If they are too stiff, it may require significant force and assistance to connect them. Refer to the assembly guide for specific instructions.
Bed sags in the middle	Insufficient mattress support or damaged slats.	Verify that all mattress support slats are correctly installed and undamaged. Ensure the mattress thickness does not exceed 8 inches. If sagging persists, inspect the frame for structural issues.
LED lights not working	No power supply connected or faulty wiring.	Ensure a compatible power supply is connected to the LED lights. Check all wiring connections. If issues persist, contact customer support.
Unit feels unstable after assembly	Improper wall anchoring.	Re-check wall anchoring. Ensure the unit is securely fastened to at least two wall studs using appropriate hardware. Do not use the bed until it is fully stable.

SPECIFICATIONS

Feature	Detail
Size	Queen
Material	Engineered Wood
Product Dimensions (Bed Unfolded)	82.5"L x 103.7"W x 88.5"H
Product Dimensions (Cabinet Folded)	68.3"L x 15.2"W x 88.5"H
Style	Modern
Special Feature	Foldable, Integrated Shelves, Drawers, LED Lights
Included Components	Shelves, Drawers, Flexible Slats, Hardware Components, Assembly Instructions
Compatible Mattress Size	Up to 8 inches thick
Maximum Weight Recommendation	750 Pounds
Item Weight	286.23 Pounds
Required Assembly	Yes

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or contact the seller directly through the platform where the product was purchased. Keep your purchase receipt and product model number handy when contacting support.