



Manuals.plus /

› BASETBL /

› BASETBL Ergonomic Office Chair User Manual

BASETBL F051G

BASETBL Ergonomic Office Chair User Manual

Model: F051G

PRODUCT OVERVIEW

The BASETBL Ergonomic Office Chair is designed to provide superior comfort and support for extended periods of sitting. Featuring a wide seat with spring padding, adjustable headrest, lumbar support, and a multi-functional footrest, this chair is built to meet high standards of ergonomics and durability. It is certified EN12520 and has a maximum weight capacity of 200 kg.



Image: BASETBL Ergonomic Office Chair, highlighting its 200 kg weight capacity and EN12520 certification.

SAFETY INFORMATION

Please read all safety instructions before assembly and use to prevent injury or damage.

- Ensure all screws and bolts are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not stand on the chair or use it as a step stool.
- Do not exceed the maximum weight capacity of 200 kg.
- Keep hands and fingers clear of moving parts during adjustment.
- Use the chair on a flat, stable surface to prevent tipping.
- Keep children and pets away from the chair during assembly.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly:

- Backrest
- Seat Cushion with Spring Padding
- Headrest
- Armrests (2)
- Gas Lift Cylinder
- Base (5-star)
- Casters (5)
- Footrest (retractable)
- Lumbar Support Pillow
- Assembly Hardware (screws, washers, Allen key)
- Instruction Manual

SETUP AND ASSEMBLY

Assembly typically takes 15-20 minutes. Follow these steps carefully:

1. **Attach Casters to Base:** Insert each of the five casters into the holes at the end of each leg of the 5-star base until they click securely into place.
2. **Insert Gas Lift:** Place the gas lift cylinder into the center hole of the 5-star base.
3. **Attach Armrests to Seat:** Secure the armrests to the underside of the seat cushion using the provided screws. Ensure they are oriented correctly (left and right).
4. **Attach Backrest to Seat:** Align the backrest with the mounting points on the seat cushion and secure it with the remaining screws. Ensure the three screws connecting the backrest are securely tightened to prevent misalignment.
5. **Place Assembled Top onto Gas Lift:** Carefully place the assembled seat and backrest onto the gas lift cylinder, ensuring it is centered and stable.
6. **Attach Headrest:** Slide the headrest into the designated slot at the top of the backrest.
7. **Attach Footrest:** Slide the footrest into its designated slot under the seat.

BASETBL F051



Stellen Sie sicher, dass die drei Schrauben hier sicher angezogen sind, um eine Fehlstellung der Rückenlehne des Stuhls zu verhindern.

Image: A diagram illustrating the dimensions and key assembly points of the BASETBL office chair.

Vergrößert und verbreitert Design



Image: An enlarged view detailing the chair's design, including synchronizable adjustable armrests, independent lumbar support, and the hidden footrest.

OPERATING INSTRUCTIONS

Adjust your chair for optimal comfort and ergonomic support:

- **Height Adjustment:** To raise the seat, lift the lever on the right side of the chair while taking your weight off the seat. To lower, lift the lever while seated. The height is adjustable from 45 cm to 55 cm.
- **Tilt Lock and Recline:** The backrest can recline between 90 and 120 degrees. Pull the lever on the left side of the chair to unlock the tilt mechanism. Lean back to your desired angle and push the lever back in to lock the position.
- **Headrest Adjustment:** The headrest can be adjusted vertically by 9 cm to provide optimal neck and head support for various user heights. Simply push or pull the headrest to adjust its position.
- **Footrest Operation:** Pull the footrest out from under the seat to extend it. Push it back in to retract it when not in use. This feature helps relieve leg pressure during long sitting periods.

- **Armrest Adjustment:** The armrests are synchronizable and can be adjusted to provide comfortable support for your arms.

Geeignet für verschiedene Bevölkerungsgruppen

200 KG



Image: Two individuals demonstrating the chair's comfort and adaptability, emphasizing its 200 kg weight capacity and suitability for various users.

Hochelastischer Schaumstoff für bequemes Sitzen über längere Zeit



Technische Stoffe sind weich und atmungsaktiv



Dreidimensionaler räumlicher Schaumstoff

Image: Close-up views of the chair's armrest and seat, illustrating the high-elastic foam for comfort and the soft, breathable technical fabric.

MAINTENANCE AND CARE

Proper care will extend the life of your BASETBL office chair:

- **Cleaning:** For the synthetic leather upholstery, wipe with a soft, damp cloth. For stubborn stains, use a mild soap solution and wipe dry immediately. Avoid harsh chemicals or abrasive cleaners.
- **Casters:** Periodically clean the casters to remove dust, hair, and debris that can impede smooth movement. The polyurethane casters are designed for quiet and smooth gliding on various floor types.
- **Hardware:** Regularly check all screws and bolts to ensure they remain tight. Re-tighten as needed to maintain stability and safety.
- **Storage:** Store the chair in a dry environment, away from direct sunlight and extreme temperatures.

HOCHDICHTER SCHAUM ZEIGT HERVORRAGENDE HALTBARKEIT UND LANGLEBIGKEIT

Dieses Kissen kann seine Form auch nach langfristiger Nutzung beibehalten, was es für größere Personen geeignet macht.

**HAUTFREUNDLICHER,
WEICHER STOFF**

NATURSCHWAMM

FEDERKERNPOLSTER

NATURHOLZPLATTE



360° GLEICHMÄßIG DRUCKVERTEILENDES KISSEN

Hüftumwicklung

Druckentlastungszone

Druckentlastung
für die Oberschenkel



FEDERKISSEN

18,6 KPA 
AUFGEBRACHTER DRUCK



NICHT-FEDERKISSEN

34,13 KPA 
AUFGEBRACHTER DRUCK



Image: An internal diagram of the chair's cushion, highlighting layers of skin-friendly fabric, natural sponge, spring core padding, and a natural wood board, ensuring durability and even pressure distribution.

TROUBLESHOOTING

Common issues and their solutions:

- **Chair feels wobbly:** Check all assembly screws, especially those connecting the backrest to the seat and the base to the gas lift. Tighten any loose connections.
- **Chair does not adjust height:** Ensure the gas lift lever is fully engaged. If the issue persists, the gas lift cylinder may need replacement.
- **Casters not rolling smoothly:** Clean any debris (hair, lint) from the caster wheels. Ensure the casters are fully inserted into the base.
- **Backrest misalignment:** Verify that the three screws securing the backrest to the seat are tightened evenly and correctly. If a manufacturing defect is suspected, contact customer support.

SPECIFICATIONS

Brand	BASETBL
Model Number	F051G
Color	Grey Footrest
Product Dimensions (L x W x H)	78 x 38 x 66 cm (packaged); 66P x 70I x 120H cm (assembled)
Item Weight	22.5 Kilograms
Special Features	Ergonomic, Footrest, Reclinable, Armrest, Adjustable Headrest
Seat Material Type	Polyester (Synthetic Leather)
Recommended Uses	Reading, Relaxing, Sleeping, Gaming, Office Work
Maximum Weight Recommendation	200 Kilograms
Certification	EN12520

WARRANTY AND SUPPORT

BASETBL offers a 3-year warranty on this ergonomic office chair, exceeding industry standards. This warranty covers manufacturing defects and material failures under normal use.

For any questions, concerns, or warranty claims, please contact BASETBL customer support. Our professional customer service team is committed to responding to inquiries within 24 hours to ensure your satisfaction.

Please visit our official website or refer to your purchase documentation for specific contact details.