

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [AaoLin](#) /
- › [AaoLin Rechargeable Hand Warmers User Manual](#)

AaoLin 716

AaoLin Rechargeable Hand Warmers User Manual

Model: 716 | Brand: AaoLin

INTRODUCTION

The AaoLin Rechargeable Hand Warmers (Model 716) provide portable and long-lasting warmth for various outdoor activities and daily use. This 2-pack set offers versatile heating options, allowing you to use them individually or combined for enhanced warmth. Designed with safety and convenience in mind, these hand warmers are an ideal companion for cold weather.

PRODUCT FEATURES

- **2-Pack Design:** Can be used as a combined unit for all-round warmth or separated to warm both hands simultaneously.
- **Extended Heating Duration:** Each 3000mAh hand warmer provides up to 20 hours of continuous warmth, totaling 40 hours for the pair.
- **Adjustable Heat Levels:** Features 3 heating levels, reaching up to 130°F in approximately 2 seconds.
- **Safety Certified:** Equipped with 6 Safety Protection Technologies and certified by UL, CE, MSDS, and FCC, ensuring safe operation.
- **Ergonomic & Compact:** Designed to fit comfortably in hand, with a slim profile (0.7 inches thick) and light weight (72g each), making them easy to carry in pockets or purses.
- **Efficient Charging:** Includes a 2-in-1 USB-C charging cable, allowing both units to be charged simultaneously. Full charge in approximately 4 hours.
- **Versatile Use:** Suitable for office work, classes, camping, hunting, hiking, golf, and other outdoor activities in cold conditions.

SETUP

Initial Charging

Before first use, fully charge both hand warmers. Use the provided 2-in-1 USB-C charging cable to connect both units to a 5V2A power adapter (not included). The charging time is approximately 4 hours.



Image: The AoLin Rechargeable Hand Warmers, showing their compact and distinct panda design.

OPERATING INSTRUCTIONS

Power On/Off and Heat Level Adjustment

- **To Turn On/Off:** Long press the power button (located on the panda's nose area) for 3 seconds. A red light will illuminate, indicating the unit is on and heating.
- **To Change Heat Levels:** Once powered on, short press the power button once to cycle through the 3 available heating levels. The indicator light may change or flash to denote the selected level.
- **To Check Battery:** Double press the power button to display the remaining battery level.

Enjoy Warmth Enjoy Safety

Security Technology Upgrade
Authoritative Certification



Image: Visual guide on how to operate the hand warmer using the power button for turning on/off, changing heat levels, and checking battery.

3 Levels of Heating

Instant Heat | Long-lasting



95-104°F



104-118°F



118-131°F

Image: Illustration of the three heating levels, indicating temperature ranges from 95-104°F, 104-118°F, and 118-131°F.

Combining and Separating Units

The two hand warmer units can be magnetically combined to form a single, larger heating surface or separated for individual use. This allows for flexible application depending on your needs.



Image: The hand warmers demonstrating their convenient snap-in design for combining or separating.

Your browser does not support the video tag.

Video: An official product video demonstrating the features and usage of the AaoLin Panda Hand Warmers, including their rechargeable nature and dual-pack functionality.

MAINTENANCE

- **Cleaning:** Wipe the surface of the hand warmers with a soft, dry cloth. Do not use abrasive cleaners or immerse in water.
- **Storage:** Store the hand warmers in a cool, dry place when not in use. Ensure they are fully charged before long-term storage to maintain battery health.
- **Battery Care:** To prolong battery life, avoid completely draining the battery frequently. Recharge when the battery indicator is low.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Hand warmer not turning on.	Low battery; power button not pressed correctly.	Charge the hand warmer fully. Long press the power button for 3 seconds.
Hand warmer not heating sufficiently.	Incorrect heat level selected; low battery.	Short press the power button to cycle to a higher heat level. Recharge the unit.
Units not combining magnetically.	Incorrect alignment.	Ensure the units are aligned correctly for the magnets to engage.

SPECIFICATIONS

Feature	Detail
Brand	AaoLin
Model Name	716

Feature	Detail
Color	2 Pack Purple Panda
Material	Polyethylene, Aluminum
Battery Capacity	3000 mAh * 2
Charging Time	Approximately 4 Hours
Heating Duration	Up to 20 Hours * 2
Upper Temperature Rating	130°F (54°C)
Power Source	Battery Powered
Item Package Dimensions	3.98 x 2.36 x 2.24 inches
Package Weight	0.19 Kilograms
Certifications	UL, CE, MSDS, FCC
Included Components	Hand Warmer*2, Manual, USB Cable

SAFETY INFORMATION

The AoLin Hand Warmers are designed with multiple safety features. Always ensure the product is used according to the instructions. Do not attempt to disassemble or modify the device. Keep away from flammable materials and direct heat sources. If the device shows any signs of damage or malfunction, discontinue use immediately.

Safe·Stable·Reliable

UL, CE, FCC certified to ensure safety.



Image: The hand warmer highlighting its safety certifications (UL, CE, FCC) for reliable and secure operation.

WARRANTY AND SUPPORT

AaoLin provides a **2-year warranty** for this product. For any inquiries, technical support, or warranty claims, please contact AaoLin customer service. AaoLin is committed to providing high-quality, safe, and durable hand warmers, with a dedicated team specializing in their research and development.

For further assistance, please refer to the contact information provided in your product packaging or visit the official

AaoLin store on Amazon.

© 2024 AaoLin. All rights reserved.