

[Manuals.plus](#) /

› [SANODESK](#) /

› SANODESK Ergonomic Mesh Office Chair User Manual

SANODESK B0CYFVJ8TD

SANODESK Ergonomic Mesh Office Chair User Manual

Model: B0CYFVJ8TD

1. INTRODUCTION

Thank you for purchasing the SANODESK Ergonomic Mesh Office Chair. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure you get the most out of your new chair. Please read this manual thoroughly before assembly and use, and keep it for future reference.

2. SAFETY INSTRUCTIONS

- Ensure all parts are present and undamaged before assembly. Do not use if any parts are missing or broken.
- Assemble the chair on a soft, clean surface to prevent scratches.
- Tighten all screws firmly, but do not overtighten. Re-tighten screws periodically to ensure stability.
- Do not stand on the chair or use it as a step stool.
- Do not sit on the armrests.
- Keep children away from small parts during assembly.
- This chair is designed for single-person use.
- Maximum weight capacity: 300 lbs.

3. PACKAGE CONTENTS

Please verify that all components listed below are included in your package:

A. Backrest Assembly: 1 unit

B. Seat Cushion: 1 unit

C. Armrests (Left & Right): 1 pair

D. Gas Lift Cylinder: 1 unit

E. Star Base: 1 unit

F. Casters: 5 units

G. Mechanism Plate: 1 unit

H. Headrest: 1 unit

I. Hardware Pack: Screws, washers, Allen wrench



Image: Overview of the SANODESK Ergonomic Mesh Office Chair, showing its main components and design from two angles.

4. ASSEMBLY INSTRUCTIONS

Follow these steps carefully to assemble your SANODESK office chair.

1. **Attach Casters to Base:** Insert the five casters (F) into the holes at the end of each leg of the star base (E). Push firmly until they click into place.
2. **Insert Gas Lift:** Place the gas lift cylinder (D) into the center hole of the assembled star base (E).
3. **Attach Mechanism Plate to Seat:** Align the mechanism plate (G) with the screw holes on the underside of the seat cushion (B). Ensure the front of the mechanism faces the front of the seat. Secure with screws from the hardware pack (I).
4. **Attach Armrests to Seat:** Attach the armrests (C) to the sides of the seat cushion (B) using the provided screws. Ensure they are oriented correctly (left and right).
5. **Attach Backrest to Seat:** Connect the backrest assembly (A) to the seat cushion (B) using the designated screw holes. Secure firmly.
6. **Attach Headrest:** Insert the headrest (H) into the top of the backrest assembly (A) and secure it.
7. **Connect Seat Assembly to Gas Lift:** Carefully place the assembled seat and backrest onto the gas lift cylinder (D) that is already inserted into the star base. Press down firmly to secure the connection.



Image: Rear view of the SANODESK Ergonomic Mesh Office Chair, highlighting the ergonomic design of the lumbar support and backrest.

5. OPERATING INSTRUCTIONS (ADJUSTMENTS)

Your SANODESK office chair offers several adjustment features for personalized comfort.

- **Seat Height Adjustment:** Locate the lever on the right side under the seat.
 - To raise the seat: Lift the lever while taking your weight off the seat.
 - To lower the seat: Lift the lever while remaining seated.
- **Rocking Function (Tilt Lock/Unlock):** The same lever used for height adjustment can also control the rocking function.
 - To unlock tilt: Pull the lever outwards. The chair will now rock freely between 90-120 degrees.
 - To lock tilt: Push the lever inwards. The chair will lock in its upright position.
- **Rocking Pressure Adjustment:** A round knob is located under the front of the seat mechanism.
 - Turn clockwise to increase tension (requires more force to recline).
 - Turn counter-clockwise to decrease tension (allows easier recline).
- **Flip-up Armrests:** The armrests can be flipped up to save space or allow the chair to be pushed closer to a desk. Simply lift the armrests upwards until they lock into the vertical position. To lower, pull them down.
- **3D Adjustable Lumbar Support:** The lumbar support can be adjusted for height and depth to fit your back curve. Gently push or pull the lumbar support to adjust its position.

- **Adjustable Headrest:** The headrest can be adjusted for height and angle to provide optimal neck and head support.



Image: Illustration of the SANODESK Ergonomic Mesh Office Chair's adjustable features, including rocking function, seat height adjustment, and rocking pressure adjustment knob.

6. MAINTENANCE AND CARE

Proper care will extend the life of your office chair.

- **Cleaning:**
 - For mesh and fabric parts, use a soft cloth dampened with mild soap and water. Blot gently; do not rub vigorously.
 - For plastic and metal parts, wipe with a clean, damp cloth.
 - Avoid harsh chemicals or abrasive cleaners.
- **Inspection:** Periodically check all screws and bolts to ensure they are tight. Re-tighten as necessary.

- **Casters:** Clean casters regularly to remove dust and debris that may hinder smooth rolling.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading of fabric and degradation of plastic components.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Chair wobbles or feels unstable.	Loose screws or uneven assembly.	Check and tighten all screws. Ensure the chair is assembled on a flat surface.
Chair does not adjust height.	Gas lift cylinder malfunction or lever issue.	Ensure the height adjustment lever is fully engaged. If the issue persists, the gas lift may need replacement. Contact customer support.
Casters do not roll smoothly.	Debris caught in casters or damaged casters.	Clean any hair or debris from the casters. If damaged, replace them.
Backrest does not recline or lock.	Tilt lock mechanism engaged or rocking tension too high.	Ensure the tilt lock lever is disengaged (pulled out). Adjust the rocking pressure knob counter-clockwise to loosen tension.

8. SPECIFICATIONS

Feature	Detail
Model Number	B0CYFVJ8TD
Brand	SANODESK
Dimensions (Overall)	26 Inch D x 26 Inch W x 48 Inch H (approximate, adjustable height)
Weight Capacity	300 lbs
Back Style	Solid Back (Mesh)
Special Features	3D Adjustable Lumbar Support, Flip-up Arms, Space Saving, Adjustable Headrest
Movement	Swivel, Tilting (90-120 degrees)
UPC	810072857842



Image: Detailed dimensions of the SANODESK Ergonomic Mesh Office Chair, including seat height range, seat width, backrest height, and overall chair dimensions, along with the 300 lbs weight capacity.

9. WARRANTY AND SUPPORT

SANODESK provides a limited warranty for this product against defects in material and workmanship under normal use. Please refer to the warranty card included in your package for specific terms and conditions, including warranty period and coverage details.

For technical support, missing parts, or warranty claims, please contact SANODESK customer service through the following channels:

- **Email:** support@sanodesk.com
- **Website:** Visit the official SANODESK website for FAQs and contact forms. [SANODESK Store on Amazon](#)

When contacting support, please have your model number (B0CYFVJ8TD) and purchase date ready.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CYFVJ8TD>

More documents and user manuals: <https://manuals.plus/>