



[Manuals.plus](#) /

› [Motion Essentials](#) /

› Motion Essentials 2-Piece Conversion Kit for Serta Motion Essentials 1st Gen Adjustable Bed

## Motion Essentials 1st Gen Essentials (Model 00850040156201)

# Motion Essentials 2-Piece Conversion Kit

## INSTRUCTION MANUAL FOR SERTA MOTION ESSENTIALS 1ST GEN ADJUSTABLE BED

### Introduction

---

This manual provides comprehensive instructions for the Motion Essentials 2-Piece Conversion Kit. This kit is designed to replace the original wired remote control for Serta Motion Essentials 1st Generation adjustable bed bases. It converts your existing wired system to a new wireless remote control system, ensuring continued functionality for your adjustable bed.

Please read these instructions carefully before installation and operation to ensure proper use and to avoid any potential issues. This kit is compatible exclusively with Serta Motion Essentials I Bases.

### Package Contents

---

Verify that all components listed below are included in your package:

- 1 x Wireless Remote Control (New White)
- 1 x Control Box
- 1 x Power Cable (attached to control box)



The image displays the complete 2-piece conversion kit, including the black control box with various ports, the white wireless remote control with illuminated buttons, and the attached power cable. This kit replaces the original wired remote system.

## Setup Instructions

Follow these steps to install your new wireless conversion kit:

1. **Disconnect Power:** Unplug your Serta Motion Essentials 1st Gen adjustable bed base from the wall outlet. Ensure no power is supplied to the bed before proceeding.
2. **Locate Existing Control Box:** Identify the original control box on your adjustable bed base. Disconnect any wired remote or power cables from this box.
3. **Connect New Control Box:** Connect the new control box to your adjustable bed base. The new control box is designed to interface with the existing motor connections. Ensure all connections are secure.
4. **Connect Power:** Use your existing power plug and AC adapter to connect the new control box to a wall outlet. If you require a new power plug or AC adapter, these must be acquired separately.
5. **Pair Remote Control:** The wireless remote control should be pre-paired with the control box. If the remote does not respond, locate the 'LEARN' or 'PROGRAM' button on the new control box (typically a small button on the side or bottom). Press and hold this button for approximately 3-5 seconds until an indicator light on the control box flashes. Immediately press any button on the wireless remote control. The indicator light should stop flashing, confirming successful pairing.
6. **Test Functionality:** After pairing, test all functions of the remote control to ensure the bed responds correctly.

## Operating Instructions

The wireless remote control provides intuitive operation of your adjustable bed base:

- **Head Up/Down Buttons:** Press and hold the respective buttons to raise or lower the head section of the bed. Release the button when the desired position is reached.
- **Foot Up/Down Buttons:** Press and hold the respective buttons to raise or lower the foot section of the bed. Release the button when the desired position is reached.
- **FLAT Button:** Press this button to return the bed to a completely flat position.
- **Flashlight Button:** The remote includes a flashlight function. Press the dedicated flashlight button to activate or deactivate the light.
- **Backlit Buttons:** The remote control buttons are backlit for easy visibility in low-light conditions.

The maximum operating range for the wireless remote control is approximately 30 feet from the control box.

## Maintenance

To ensure the longevity and proper functioning of your conversion kit, follow these maintenance guidelines:

- **Battery Replacement:** The wireless remote control uses Alkaline batteries. When the remote's performance degrades or the backlight dims, replace the batteries with new ones of the same type. Refer to the battery compartment cover for specific battery size and orientation.
- **Cleaning:** Clean the remote control and control box with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as these can damage the components.
- **Environmental Conditions:** Keep the control box and remote control away from excessive moisture, heat, and direct sunlight.

## Troubleshooting

If you encounter issues with your conversion kit, refer to the following troubleshooting steps:

Problem	Possible Cause	Solution
Remote not responding / Bed not moving	No power to control box Remote batteries are low or dead Remote not paired with control box Loose connections	Ensure the bed is plugged into a working outlet. Replace remote batteries. Re-pair the remote control with the control box (refer to Setup Instructions). Check all cable connections between the control box and the bed base.
Bed moves only in one direction	Motor connection issue	Verify that the motor cables are securely connected to the control box.
Remote backlight not working	Low remote batteries	Replace remote batteries.

If the issue persists after attempting these solutions, please contact customer support.

## Specifications

- **Brand:** Motion Essentials

- **Model Name:** 1st Gen Essentials
- **Model Number:** 00850040156201
- **Connectivity Technology:** Wireless (Serta Remote - Must match picture)
- **Controller Type:** Button Control
- **Maximum Range:** 30 Feet
- **Battery Type (Remote):** Alkaline
- **Item Dimensions (Control Box):** Approximately 4"L x 1"W x 6"H
- **Maximum Number of Supported Devices:** 1 (adjustable bed base)
- **Compatible Devices:** Serta Motion Essentials 1st Gen Wired Bed Remote (replacement kit)

## Warranty and Support

---

**Warranty Description:** This Motion Essentials conversion kit comes with a 1-year limited warranty from the manufacturer. Please retain your proof of purchase for warranty claims.

**Manufacturer:** Motion Essentials

For technical support, warranty inquiries, or replacement parts, please contact the manufacturer directly. Refer to your purchase documentation for specific contact information.