

LITFAD LT1190088XJ

LITFAD Modern Stone Wall Mounted Bathroom Vanity with Ceramic Sink and Smart Medicine Cabinet

Model: LT1190088XJ

1. INTRODUCTION

Thank you for choosing the LITFAD Modern Stone Wall Mounted Bathroom Vanity with Ceramic Sink and Smart Medicine Cabinet. This manual provides essential information for the safe installation, operation, and maintenance of your new bathroom fixture. Please read these instructions thoroughly before assembly and use, and retain them for future reference.



Figure 1: Overview of the LITFAD Modern Stone Wall Mounted Bathroom Vanity with Ceramic Sink and Smart Medicine Cabinet. This image displays the complete unit, including the wall-mounted vanity with a gray slate countertop, integrated ceramic sink, and the smart medicine cabinet with LED lighting and mirrored doors.

2. SAFETY INFORMATION

WARNING: Improper installation, operation, or maintenance can result in serious injury or property damage. Always follow these safety guidelines.

- Read all instructions before assembly and installation.
- Ensure all local plumbing and electrical codes are met. Professional installation by a licensed plumber and electrician is highly recommended.
- Verify that the wall structure is capable of supporting the weight of the vanity and medicine cabinet. Use appropriate wall anchors for your wall type.
- Disconnect power at the circuit breaker before performing any electrical work on the smart medicine cabinet.
- Handle ceramic and stone components with care to prevent chipping or breakage.
- Keep small parts and packaging materials away from children.

3. PACKAGE CONTENTS

Please inspect the package contents carefully to ensure all parts are present and undamaged. If any items are missing or damaged, contact customer support immediately.

- Wall Mounted Vanity Unit (Stone/Wood)
- Integrated Ceramic Sink
- Faucet
- Drain Assembly
- Smart Medicine Cabinet with Mirror and LED Lighting
- Assembly Tools
- Instruction Manual (this document)

4. SPECIFICATIONS

Feature	Detail
Brand	LITFAD
Model Name	LT1190088XJ
Vanity Dimensions (L x W x H)	31.5" (800mm) x 19.5" (500mm) x 6" (150mm)
Medicine Cabinet Dimensions (W x H)	31" (780mm) x 25.5" (650mm)
Lower Shelf Dimensions (L x W x H)	31.5" (800mm) x 19" (480mm) x 3" (80mm)
Materials	Stone (Countertop), Ceramic (Sink), Wood (Cabinet Structure), Slate (Frame)
Mounting Type	Wall Mount
Features	Scratch Resistant, Faucet Included, Drain Assembly Included, LED Mirror, Time/Temperature Display
Assembly Required	Yes



Figure 2: Detailed dimensions of the vanity unit, ceramic sink, and smart medicine cabinet. This diagram provides measurements in both inches and millimeters for accurate planning and installation.

5. SETUP AND INSTALLATION

This vanity and medicine cabinet set requires wall-mounted installation. Due to the complexity involving plumbing and electrical connections, professional installation is strongly recommended.

5.1 Pre-Installation Checklist

- Confirm all parts are present and undamaged.
- Ensure the wall is structurally sound and capable of supporting the unit's weight.
- Turn off the main water supply and electrical power to the installation area.
- Gather necessary tools (e.g., drill, level, tape measure, screwdriver, sealant).

5.2 Vanity Installation

1. Determine the desired height for the vanity. Use a level to mark the mounting points on the wall according to the vanity's pre-drilled holes.
2. Drill pilot holes and insert appropriate wall anchors suitable for your wall type (e.g., concrete, drywall with studs).
3. Carefully lift the vanity unit and align it with the wall anchors. Secure the vanity to the wall using the provided screws.
4. Connect the faucet to the water supply lines and the drain assembly to the plumbing system. Ensure all connections are tight and leak-free.
5. Apply a bead of silicone sealant around the edges where the vanity meets the wall for a watertight seal.

5.3 Smart Medicine Cabinet Installation

1. Measure and mark the desired position for the medicine cabinet above the vanity, ensuring it is level.
2. Drill pilot holes and install wall anchors.
3. Mount the medicine cabinet to the wall, securing it firmly.
4. Connect the electrical wiring for the LED lighting and smart features according to local electrical codes. This step requires a qualified electrician.

6. OPERATING INSTRUCTIONS

6.1 Faucet Operation

The included faucet operates with a single lever for controlling both water temperature and flow. Lift the lever to increase water flow and move it left or right to adjust temperature. Ensure the water supply is turned on after installation.



Figure 3: The ceramic sink basin designed for efficient water drainage. The arrows illustrate the direction of water flow towards the drain, indicating the sink's functional design.

6.2 Smart Medicine Cabinet

The smart medicine cabinet features an integrated LED light, time display, and temperature display.

- **LED Light:** The LED light can be activated by touching the designated switch on the mirror surface. Touch again to turn off.
- **Time and Temperature Display:** These features are automatically displayed once the cabinet is powered. Refer to the specific instructions provided with the medicine cabinet for setting time or adjusting units if applicable.

7. MAINTENANCE

Regular cleaning and proper care will ensure the longevity and appearance of your vanity and medicine cabinet.

7.1 Cleaning the Ceramic Sink and Slate Countertop

- Use a soft cloth and mild, non-abrasive cleaner for daily cleaning.
- Avoid harsh chemicals, abrasive pads, or acidic cleaners, as these can damage the ceramic glaze and slate surface.
- Wipe spills immediately, especially on the slate countertop, to prevent staining.
- For stubborn stains on the ceramic sink, a baking soda paste can be used, followed by thorough rinsing.



Figure 4: A hand gently wiping the slate countertop of the vanity with a soft cloth. This demonstrates the recommended method for cleaning the surface to maintain its finish.

7.2 Medicine Cabinet and Mirror Care

- Clean the mirror surface with a glass cleaner and a soft, lint-free cloth. Spray cleaner onto the cloth, not directly onto the mirror, to prevent liquid from seeping into electrical components.
- Wipe down the cabinet exterior with a damp cloth and mild soap, then dry thoroughly.

8. TROUBLESHOOTING

This section addresses common issues you might encounter.

8.1 Water Leaks

- **Issue:** Water leaking from faucet connections.
Solution: Ensure all plumbing connections are tightened properly. Check for worn washers or seals and replace if necessary.
- **Issue:** Water leaking from drain assembly.
Solution: Verify the drain assembly is correctly seated and sealed with plumber's putty or silicone. Tighten all

nuts.

8.2 Smart Medicine Cabinet Issues

- Issue:** LED light not turning on.
Solution: Check the electrical connection to the cabinet. Ensure the circuit breaker is on. If the issue persists, consult a qualified electrician.
- Issue:** Time/temperature display not working.
Solution: Verify power supply. If the display remains off, contact customer support.

9. WARRANTY AND SUPPORT

For warranty information or technical assistance, please contact LITFAD customer support. Details for contacting support are typically found on the product packaging or the manufacturer's official website. Please have your model number (LT1190088XJ) and purchase date available when contacting support.

© 2024 LITFAD. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question