

[Manuals.plus](#) /

› [Jugeman](#) /

› Jugeman Smart Watch Y66 User Manual

Jugeman Y66

Jugeman Smart Watch User Manual

Model: Y66

Smart Watch (Answer/Make Calls), 100+ Sport Modes, Fitness Watch

INTRODUCTION

Thank you for choosing the Jugeman Smart Watch. This device is designed to enhance your daily life by providing convenient communication features, comprehensive fitness tracking, and health monitoring capabilities. Please read this manual carefully to understand the functions and proper usage of your new smart watch.



Image: The Jugeman Smart Watch, featuring a square display showing time, step count, heart rate, and weather information. The watch has a gray strap and a silver-colored casing.

SAFETY INFORMATION AND WARNINGS

WARNING:

- Do not make the device disassemble, strike or throw into the fire.
- Please do not place the device in high temperature or deep water environment.
- Please must be connected to a power source in 5V/1A while charging device.
- Smart watch data cannot be used for medical purposes.
- The removable battery is for environmentally friendly disposal.
- If you need medical help, please contact a professional doctor.



Image: The back of the product packaging, displaying detailed specifications and important safety warnings for the Jugeman Smart Watch.

WHAT'S IN THE BOX

Upon opening your Jugeman Smart Watch package, you should find the following items:

- Jugeman Smart Watch (Model Y66)
- Charging Cable
- User Manual (this document)



Image: The front of the Jugeman Smart Watch packaging, featuring an image of the smartwatch and the text "SMART WATCH Your Fitness Tracker".

SETUP

1. Charging the Smart Watch

Before first use, fully charge your smart watch. Connect the provided charging cable to the charging port on the back of the watch and plug the USB end into a 5V/1A power adapter (not included) or a computer USB port. The watch display will indicate charging status.

2. App Installation and Pairing

To unlock the full potential of your Jugeman Smart Watch, download the companion application on your smartphone. The app is compatible with iOS 9.0 and Android 4.4 and above.

1. Scan the QR code in the manual or on the watch screen (if available) to download the app, or search for the app name (usually indicated on the box or in a quick start guide) in your phone's app store.
2. Ensure Bluetooth is enabled on your smartphone.
3. Open the installed app and follow the on-screen instructions to create an account and pair your smart watch. The watch will appear as "Y66" or similar in the Bluetooth device list.
4. Confirm the pairing request on both your phone and the watch.

Once paired, the watch will synchronize time and data with your smartphone.

OPERATING INSTRUCTIONS

Basic Navigation

- **Touch Screen:** Swipe left/right, up/down to navigate through menus and functions. Tap to select.
- **Side Button:** Typically used to wake the screen, return to the home screen, or access the main menu.

Making and Answering Calls

The Jugeman Smart Watch allows you to make and answer calls directly from your wrist when connected to your smartphone via Bluetooth.

- **Answering Calls:** When an incoming call rings, tap the green phone icon on the watch screen to answer.
- **Making Calls:** Access the dial pad or contact list on your watch (after syncing contacts via the app) to initiate a call.

Jugeman



SMART WATCH

Your Fitness Tracker

Image: The Jugeman Smart Watch screen showing a phone call interface with a dial pad, demonstrating its call-making capability.

Sport Modes

The watch supports over 100 sport modes to accurately track your workouts. Select your desired activity from the sports menu to begin tracking metrics such as duration, calories burned, and heart rate.



Image: The Jugeman Smart Watch screen displaying a selection of sport modes, including outdoor run, outdoor cycle, skipping, and swimming.

Health Monitoring

Monitor your health with integrated sensors for heart rate, sleep, and step counting (pedometer).

- **Heart Rate:** Access the heart rate function to measure your current heart rate.
- **Sleep Monitor:** Wear the watch to bed to track your sleep patterns and quality.
- **Pedometer:** The watch automatically counts your steps throughout the day.



Image: The Jugeman Smart Watch screen showing health data, including heart rate, blood oxygen levels, and sleep tracking information.

Notifications

Receive notifications from your smartphone directly on your watch. Ensure notification permissions are enabled in the companion app.

FCC ID: 2AXPW-MC009
MADE IN CHINA

UK CE FC RoHS



COMPLIANCE



Image: The Jugeman Smart Watch screen displaying a list of recent notifications, such as messages and app alerts.

Customization

Personalize your watch face through the companion app. You can choose from a variety of pre-installed faces or upload your own images.





Image: The Jugeman Smart Watch screen showing various customizable watch faces, allowing users to personalize the display.

MAINTENANCE

- **Cleaning:** Wipe the watch and strap regularly with a soft, damp cloth. Avoid using harsh chemicals.
- **Water Resistance:** The watch is IP68 waterproof, meaning it can withstand dust, dirt, and sand, and is resistant to submersion up to a maximum depth of 1.5m for up to 30 minutes. It is suitable for daily use and light water activities, but not for diving or high-pressure water activities.
- **Battery Care:** To prolong battery life, avoid fully discharging the watch frequently. Charge it when the battery level is low.

TROUBLESHOOTING

Problem	Possible Solution
Watch does not turn on.	Ensure the watch is fully charged. Connect it to the charger for at least 30 minutes.
Cannot pair with smartphone.	<ul style="list-style-type: none">◦ Ensure Bluetooth is enabled on your phone and the watch.◦ Make sure the watch is within range of your phone.◦ Restart both the watch and your phone.◦ Forget the device in your phone's Bluetooth settings and try pairing again.◦ Ensure the companion app is installed and running.
Notifications not received.	<ul style="list-style-type: none">◦ Check notification permissions in the companion app and your phone's settings.◦ Ensure the watch is connected via Bluetooth.
Inaccurate health data.	Ensure the watch is worn snugly on your wrist. Clean the sensors regularly. Remember, data is for reference only and not for medical diagnosis.

SPECIFICATIONS

Feature	Detail
Model	Y66
Device Type	Color TFT-LCD Smart Bracelet
Display Size	1.96 inches
Sensors	Three-axis sensor / Green light rate sensor
Waterproof Rating	IP68
Compatible Systems	iOS 9.0 Above / Android 4.4 Above
Connectivity Technology	Bluetooth
Battery Cell Composition	Lithium Polymer
Battery Capacity	200 mAh
Item Weight	2.89 ounces
Item Shape	Square

MANUFACTURER AND SUPPORT INFORMATION

Manufacturer: Jugeman
Producer Name: Mobai Acoustic Technology Co., Ltd
Address: 2nd Floor, Building D, Fenggang Industrial Park, Fenggang Town, Dongguan City, Guangdong Province, China
E-Mail: michiu5271@gmail.com

For further assistance or warranty inquiries, please contact the manufacturer directly using the provided contact information.

© 2024 Jugeman. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question