

[Manuals.plus](#) /

› [Jugeman](#) /

› Jugeman P99 Smart Watch User Manual

Jugeman P99

Jugeman P99 Smart Watch User Manual

Model: P99

INTRODUCTION

Welcome to the Jugeman P99 Smart Watch user manual. This guide provides detailed instructions on how to set up, operate, and maintain your new smartwatch. The Jugeman P99 is designed to enhance your daily life with features like Bluetooth calling, comprehensive health monitoring, and a wide range of sports tracking capabilities. Please read this manual thoroughly to ensure optimal performance and longevity of your device.

WHAT'S IN THE BOX

Upon unboxing your Jugeman P99 Smart Watch, please verify that all components are present:

- 1 x Jugeman P99 Smart Watch
- 1 x USB Charging Cable (Proprietary)
- 1 x User Manual (This document)



Image: The Jugeman P99 Smart Watch with its orange band and the included charging cable.

SETUP GUIDE

1. Charging the Smart Watch

Before first use, fully charge your Jugeman P99 Smart Watch. Connect the proprietary USB charging cable to the charging contacts on the back of the watch and plug the USB end into a standard USB power adapter (not included) or a computer's USB port.

- The watch display will show a charging indicator.

- A full charge typically takes approximately 2 hours.
- Ensure the charging contacts are clean and dry before charging to prevent corrosion.

2. Installing the "GloryFit" App

The Jugeman P99 Smart Watch requires the "GloryFit" application for full functionality and data synchronization. You can download the app from your smartphone's app store:

- For Android devices: Search for "GloryFit" on the Google Play Store.
- For iOS devices: Search for "GloryFit" on the Apple App Store.
- Alternatively, scan the QR code provided in the quick start guide (if applicable) to directly download the app.

Follow the on-screen instructions to create an account and set up your personal profile within the app.

3. Pairing with Your Smartphone (Bluetooth 5.3)

To pair your watch with the "GloryFit" app:

1. Ensure your phone's Bluetooth is enabled.
2. Open the "GloryFit" app on your smartphone.
3. Navigate to the "Device" or "My Device" section within the app.
4. Tap on "Add Device" or "Bind Device".
5. The app will search for available devices. Select "P99" or the corresponding device name from the list.
6. Confirm the pairing request on both your phone and the watch if prompted.

Once successfully paired, the watch will synchronize time and data with your phone.

OPERATING INSTRUCTIONS

Basic Navigation

The Jugeman P99 features a 1.96" HD touch screen for intuitive navigation:

- **Swipe Up:** Access quick settings or notifications.
- **Swipe Down:** View notifications or quick settings.
- **Swipe Left/Right:** Scroll through different widgets or main functions (e.g., activity, heart rate, weather).
- **Press Side Button:** Wake up the screen, return to the main watch face, or access the app menu.
- **Tap:** Select an item or confirm an action.



Image: Close-up of the Jugeman P99 Smart Watch display, showing the time, date, weather, steps, heart rate, and calories burned.

Bluetooth Call and Message Reminder

With its built-in microphone and Hi-Fi speaker, the P99 allows you to manage calls directly from your wrist.

- **Making Calls:** Access the dial pad or contacts through the watch interface to initiate a call.
- **Answering Calls:** When a call comes in, tap the green answer icon on the watch screen.
- **Message Notifications:** Enable notifications for apps like Facebook, WhatsApp, Instagram, and SMS in the "GloryFit" app. Messages will appear on your watch screen.

Your browser does not support the video tag.

Video: Demonstrates the call answering and notification features of the Jugeman P99 Smart Watch, highlighting its 1.96" HD display and

113+ Sports Modes

The P99 Smart Watch supports over 113 sports modes to accurately track your workouts. To access and use sports modes:

1. From the main watch face, swipe to the "Exercise" or "Sports" menu.
2. Select your desired activity (e.g., Outdoor Run, Indoor Run, Outdoor Walk, Skipping, Swimming, Basketball, Football, Yoga).
3. Tap to start the activity. The watch will begin tracking relevant metrics such as duration, calories burned, distance, and heart rate.
4. To pause or end an activity, swipe or press the side button as indicated on the screen.



Image: A woman running outdoors, wearing the Jugeman P99 Smart Watch on her wrist, demonstrating its use during physical activity.

All-day Health Monitoring

The P99 Smart Watch provides continuous health monitoring through its advanced optical sensor:

- **Heart Rate Monitoring:** Tracks your heart rate 24/7. View real-time data on the watch or detailed graphs in the "GloryFit" app.
- **SpO2 Measurement:** Measures your blood oxygen saturation levels.
- **Sleep Quality Detection:** Monitors your sleep patterns, including deep sleep, light sleep, and awake time. Access detailed sleep analysis in the "GloryFit" app to understand your sleep health.
- **Pedometer & Calories:** Automatically tracks your steps taken and calories burned throughout the day.

For accurate readings, ensure the watch is worn snugly on your wrist, about one finger's width from your wrist bone.

Personalized Watch Faces

Customize your watch face with over 250 personalized options or set your own picture as the background.

- **Changing Watch Face on Watch:** Long-press the current watch face on the screen, then swipe left or right to browse available options and tap to select.
- **Changing Watch Face via App:** Open the "GloryFit" app, go to the "Device" section, and find "Dial Settings" or

"Watch Face Market" to explore more options and upload custom images.

MAINTENANCE

Cleaning Your Smart Watch

- Regularly clean the watch body and strap with a soft, damp cloth.
- For the charging contacts, use a dry cotton swab to gently wipe away any dust or debris.
- Avoid using harsh chemicals, abrasive cleaners, or solvents, as these can damage the watch's finish and components.

Water Resistance (IP68)

The Jugeman P99 Smart Watch is IP68 waterproof, meaning it is resistant to dust and can withstand immersion in water up to 1.5 meters for up to 30 minutes. This makes it suitable for daily use, hand washing, and light rain.

- **Do NOT** use the watch in hot water, saunas, or steam rooms.
- **Do NOT** press any buttons underwater.
- After exposure to water, especially saltwater, rinse the watch with fresh water and dry it thoroughly before charging or further use.

Battery Care

- Avoid extreme temperatures, both hot and cold, as they can affect battery life.
- Charge the watch regularly, ideally before the battery completely drains.
- If storing the watch for an extended period, charge it to about 50% to prevent deep discharge.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Watch not turning on	Low battery; device frozen.	Charge the watch for at least 10 minutes. If still unresponsive, perform a forced restart (refer to app for specific instructions if available, or long-press side button).
Cannot pair with phone	Bluetooth off; app not open; watch not discoverable; interference.	Ensure phone Bluetooth is on. Open "GloryFit" app. Restart both watch and phone. Forget previous Bluetooth connections on phone. Ensure watch is close to phone.
Notifications not received	App permissions not granted; notifications disabled in app/phone settings.	Check "GloryFit" app notification settings. Verify phone's system notification permissions for "GloryFit". Ensure watch is connected.
Inaccurate health data	Watch worn too loosely/tightly; sensor dirty; movement during measurement.	Ensure watch is worn snugly but comfortably. Clean the optical sensor on the back of the watch. Remain still during measurements.
Charging issues	Charging cable not properly connected; dirty contacts; faulty cable/adapter.	Ensure cable is securely connected. Clean charging contacts. Try a different USB port or power adapter.

SPECIFICATIONS

Feature	Detail
Model Name	P99
Brand	Jugeman
Screen Size	1.96 Inches HD TFT Color Display
Resolution	320*385
Connectivity	Bluetooth 5.3
Water Resistance	IP68
Health Monitoring	24-hour Heart Rate, SpO2, Sleep Quality, Pedometer, Calories
Sports Modes	113+
Battery Type	Lithium Polymer (1 A battery included)
Compatibility	Android, iOS
Item Weight	3.17 ounces
Package Dimensions	6.42 x 3.74 x 0.75 inches

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included with your product or visit the official Jugeman website. If you encounter any issues not covered in this manual, please contact Jugeman customer service for assistance.

[Visit the Jugeman Store for more information](#)

© 2024 Jugeman. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question