



Manuals.plus /

› Mimoglad /

› Mimoglad Drafting Chair Mimo-5188D User Manual

## Mimoglad Mimo-5188D

# Mimoglad Drafting Chair Mimo-5188D User Manual

Model: Mimo-5188D

## INTRODUCTION

---

Thank you for choosing the Mimoglad Drafting Chair Mimo-5188D. This manual provides essential information for the safe assembly, operation, maintenance, and troubleshooting of your new chair. Please read these instructions carefully before use and retain them for future reference.

## SAFETY INFORMATION

---

**WARNING:** This product has a maximum weight recommendation of 300 pounds. Proper assembly is required to ensure safe use. Refer to the assembly instructions provided.

- Ensure all screws and bolts are securely tightened before use.
- Do not stand on the chair.
- Avoid exposing the chair to direct sunlight or extreme temperatures.
- Keep children away from moving parts during adjustment.

## PACKAGE CONTENTS

---

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, contact customer support.

- Chair Backrest
- Seat Cushion
- Armrests (2)
- Gas Lift Cylinder
- Chair Base with Casters
- Footrest Ring
- Assembly Hardware (screws, washers, Allen wrench)
- Instruction Manual

## ASSEMBLY INSTRUCTIONS

---

Follow these steps to assemble your Mimoglad Drafting Chair. It is recommended to assemble the chair on a soft, clean surface to prevent damage.

1. **Attach Casters to Base:** Insert the five casters into the holes at the end of each leg of the chair base. Push firmly until they click into place.
2. **Install Gas Lift and Footrest:** Place the gas lift cylinder into the center hole of the chair base. Slide the footrest ring over the gas lift cylinder and secure it at your desired height using the adjustment knob.
3. **Attach Seat to Mechanism:** Align the seat plate mechanism (pre-attached to the seat cushion) with the top of the gas lift cylinder and press down firmly.
4. **Connect Backrest to Seat:** Secure the backrest to the seat cushion using the provided screws and Allen wrench. Ensure a snug fit.
5. **Attach Armrests:** Fasten the armrests to the sides of the seat and backrest using the designated screws.
6. **Final Check:** Verify that all connections are secure and the chair is stable before use.



Image: Detailed dimensions of the Mimoglad Drafting Chair, illustrating various measurements for proper fit and setup.

## OPERATING INSTRUCTIONS

Your Mimoglad Drafting Chair features several adjustable components to customize your seating experience.

- **Seat Height Adjustment:** Locate the lever under the right side of the seat. To raise the seat, lift the lever while taking your weight off the seat. To lower the seat, lift the lever while seated. The pneumatic height adjustment mechanism

allows for an 8-inch seat height adjustment (from 23.6" to 29.5" from seat to floor).



Image: Illustration of the chair's seat height adjustment mechanism, demonstrating how to raise and lower the seat.

- **Lumbar Support Adjustment:** The adjustable lumbar support can be moved up and down by 1.57 inches to provide precise support for your lower back. Gently push or pull the lumbar support pad on the backrest to adjust its vertical position.

## LUMBAR SUPPORT ADJUST

1.57" up and down



Image: Close-up of the adjustable lumbar support, highlighting its vertical movement for personalized comfort.

- **Footrest Ring Height Adjustment:** Loosen the knob on the side of the footrest ring to adjust its height. Once at the desired position, tighten the knob to secure it. The footrest ring offers a 6-inch height adjustment range.



Image: Demonstration of the footrest ring height adjustment, showing the knob used to secure it in place.

- **Flip-Up Armrests:** The armrests can be flipped up by rotating them upwards, allowing the chair to be pushed closer to a desk or for easier entry/exit.



Image: Visual guide to the flip-up armrests, demonstrating their functionality for space-saving and versatility.

Your browser does not support the video tag.

Video: An official product video demonstrating the features and versatility of the Mimoglad Drafting Chair, showcasing its ergonomic design and various adjustments.

## MAINTENANCE

To ensure the longevity and optimal performance of your Mimoglad Drafting Chair, follow these maintenance guidelines:

- **Cleaning:** Wipe clean with a damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the material.
- **Regular Checks:** Periodically check all screws and bolts to ensure they remain tight. Re-tighten if necessary.
- **Caster Care:** Keep casters free of debris (hair, dust) to ensure smooth rolling.

## TROUBLESHOOTING

If you encounter any issues with your Mimoglad Drafting Chair, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Chair does not adjust height	Gas lift cylinder malfunction or lever not engaged.	Ensure the height adjustment lever is fully engaged. If the issue persists, contact customer support for a replacement gas lift.
Chair wobbles	Loose screws or uneven floor.	Check and tighten all assembly screws. Ensure the chair is on a flat, even surface.
Casters do not roll smoothly	Debris caught in casters.	Remove any hair or debris from the caster wheels.

## SPECIFICATIONS

<b>Brand</b>	Mimoglad
<b>Model Name</b>	Office Chair
<b>Item Model Number</b>	Mimo-5188D
<b>Color</b>	Grayish White
<b>Product Dimensions</b>	19.6"D x 23.6"W x 44.29"H
<b>Maximum Weight Recommendation</b>	300 Pounds
<b>Material</b>	Nylon (Mesh back), Foam (Seat)
<b>Back Style</b>	Ergonomic backrest
<b>Arm Style</b>	Armless (Flip-up armrests)
<b>Tilting</b>	No
<b>Furniture Base Movement</b>	Swivel
<b>Item Weight</b>	30 pounds

## WARRANTY AND SUPPORT

Mimoglad is committed to providing high-quality products and excellent customer service.

- **5-Year Warranty:** We offer a 5-year free fix warranty that covers repairs and replacements for missing parts, damaged packages, or failed functions.
- **Dedicated Support:** For any inquiries or assistance, please contact Mimoglad customer support. Our team is ready to assist you within 24 hours.



Image: Overview of Mimoglad's quality assurance, 5-year warranty, and dedicated customer support services.