

Manuals.plus /

- › FANYE /
- › FANYE Electric Power Lift Recliner Chair Sofa Instruction Manual

## FANYE Electric Power Lift Recliner Chair Sofa

# FANYE Electric Power Lift Recliner Chair Sofa Instruction Manual

Model: Electric Power Lift Recliner Chair Sofa

## 1. INTRODUCTION

---

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your FANYE Electric Power Lift Recliner Chair Sofa. Please read this manual thoroughly before use to ensure safe and proper operation of the product.



Image 1.1: The FANYE Electric Power Lift Recliner Chair Sofa in a partially reclined position, showcasing its design and side pocket with controls.

## 2. SAFETY INFORMATION

---

Please observe the following safety precautions to prevent injury or damage to the product:

- **Consult a Doctor:** If you have any health concerns, consult your doctor before using this product, especially regarding the massage and heat functions.
- **Maximum Reclining Angle:** The maximum reclining angle for this chair is 160 degrees. Do not attempt to force the chair beyond this limit.
- **Weight Capacity:** The estimated maximum weight capacity for this recliner is 350 pounds. Do not exceed this weight limit.
- **Clearance:** Ensure there is adequate clearance (approximately 4-6 inches) from any wall or obstruction behind the chair to allow for full reclining motion.
- **Children and Pets:** Keep children and pets away from the moving parts of the chair, especially during operation.
- **Power Cord:** Ensure the power cord is not pinched, tangled, or placed in a high-traffic area where it could be tripped over or damaged.
- **Unplug When Not in Use:** Unplug the chair from the power outlet when not in use or before cleaning and maintenance.
- **Indoor Use Only:** This product is designed for indoor use only. Do not expose it to moisture or extreme temperatures.

## 3. PACKAGE CONTENTS

---

The FANYE Electric Power Lift Recliner Chair Sofa is shipped in one box. Please verify that all components are present before beginning assembly.

- Recliner Chair Base (with motor and frame)
- Backrest Section
- Power Adapter and Cord
- Wired Hand Controller

*Note:* Small components like the hand controller may be found in the side pockets or within the packaging of the main chair sections.

## 4. SETUP AND ASSEMBLY

---

Assembly of the FANYE Electric Power Lift Recliner Chair Sofa is designed to be straightforward and typically takes approximately 10 minutes. No special tools are required.

1. **Unpack Components:** Carefully remove all parts from the packaging. Place them on a soft, clean surface to prevent damage.
2. **Attach Backrest:** Align the metal brackets on the backrest section with the corresponding slots on the chair base. Slide the backrest down firmly until it clicks securely into place. The KD (Knock-Down) back construction allows for easy attachment and detachment.
3. **Connect Wiring:** Locate the power cables extending from the chair base and the backrest. Connect them securely. Ensure all connections are snug.
4. **Connect Hand Controller:** Plug the wired hand controller into the designated port, usually located near the power connections.
5. **Connect Power:** Plug the power adapter into the chair's power input, then plug the adapter into a standard electrical outlet.
6. **Test Functions:** Before final placement, test all functions of the chair (lift, recline, massage, heat) using the

hand controller to ensure proper operation.



Image 4.1: The recliner in its upright, slightly lifted position, demonstrating the power lift mechanism.

## 5. OPERATING INSTRUCTIONS

---

Your FANYE Electric Power Lift Recliner Chair Sofa is equipped with a wired hand controller to manage its various functions.

### 5.1. Power Lift and Recline Functions

The chair features a dual OKIN motor system, allowing independent adjustment of the backrest and footrest. The counter-balanced lift mechanism assists users in standing up easily.

- **To Recline:** Press and hold the appropriate button on the hand controller to smoothly recline the backrest and extend the footrest to your desired position (between 60° and 160°).
- **To Lift/Stand:** Press and hold the lift button on the hand controller. The chair will gently tilt forward and lift, assisting you to a standing position without stress on your back or knees.
- **To Return to Upright:** Press and hold the upright button to bring the chair back to its standard seated position.



Image 5.1: Close-up of the side pocket, showing the wired hand controller for operating the chair's functions.



Image 5.2: The recliner with its footrest fully extended, demonstrating the reclining capability.

## 5.2. Massage and Heat Functions

The chair includes 8 vibrating points for full-body vibration and 1 lumbar heating point for added comfort. These functions are controlled via the wired hand controller.

- **Activate Massage:** Use the hand controller to select various massage modes and intensity levels.
- **Activate Heat:** Use the hand controller to turn on the lumbar heating function.
- **Timer Function:** Both massage and heat functions can be set to automatically turn off after 10, 20, or 30 minutes. Refer to the hand controller's specific buttons for timer settings.
- *Note:* The heating function operates independently of the vibration function.

## 6. MAINTENANCE AND CARE

---

Proper care will extend the life and appearance of your recliner.

- **Cleaning Upholstery:** The high-quality microfiber upholstery is designed for easy cleaning. Simply wipe with a damp cloth to remove spills or dirt. Avoid harsh chemicals or abrasive cleaners.
- **Regular Dusting:** Dust the chair regularly with a soft, dry cloth.
- **Vacuuuming:** Use a vacuum cleaner with a soft brush attachment to remove crumbs and debris from crevices.
- **Mechanism Check:** Periodically inspect the metal frame and moving parts for any loose connections or signs of wear. Do not lubricate the mechanism unless specifically instructed by the manufacturer.
- **Power Cord Inspection:** Regularly check the power cord and plug for any damage. If damaged, discontinue use and contact customer support.

## 7. TROUBLESHOOTING

---

If you encounter issues with your recliner, refer to the following common troubleshooting steps:

<b>Problem</b>	<b>Possible Cause</b>	<b>Solution</b>
Chair does not recline or lift.	Not plugged in. Loose power connection. Power outlet issue. Hand controller not connected.	Ensure power cord is securely plugged into the wall outlet and the chair. Check all cable connections between chair components. Test the outlet with another appliance. Verify the hand controller is firmly plugged into its port.
Massage or heat function not working.	Function not activated on controller. Timer setting expired.	Ensure the specific massage/heat button is pressed. Check timer settings and reactivate if necessary.
Unusual noises during operation.	Loose hardware. Obstruction in mechanism.	Inspect all visible bolts and connections for tightness. Check under and around the chair for any objects obstructing the mechanism.

If the problem persists after attempting these solutions, please contact FANYE customer support for further assistance.

## 8. SPECIFICATIONS

---

Feature	Detail
Brand	FANYE
Model Name	New High Quality Electric Power Lift Recliner Chair Sofa for Elderly with Massage and Heat, 3 Positions Adjustable ,2 Side Pockets
Product Dimensions (D x W x H)	37.5"D x 39"W x 41.5"H
Seat Height (Floor to Seat)	19.5"
Seat Depth (Front to Back)	21.5"
Seat Width (Side to Side)	22"
Back Height (Seat to Top of Back)	25"
Upholstery Material	High Quality Microfiber
Frame Material	Metal + Wood (Composite Wood)
Seat Construction	Foam + Pocket Spring
Leg Material	Metal
Reclining Positions	Infinite (between 60° and 160°)
Weight Capacity	350 Lbs
Assembly Required	Yes (approx. 10 minutes, no tools)
Special Features	Power Lift, Full-body Vibration Massage (8 points), Lumbar Heating (1 point), Wired Controller, 2 Side Pockets, 2 Cup Holders
Color	Brown (also available in Light Brown, Charcoal Gray)
UPC	728725938636



Image 8.1: Detailed dimensions of the recliner in both upright and fully reclined positions.

## 9. WARRANTY AND SUPPORT

**Product Warranty:** This FANYE Electric Power Lift Recliner Chair Sofa comes with a 1-year product warranty from the date of purchase.

**Customer Support:** If you have any questions, concerns, or require assistance with your product, please do not hesitate to contact FANYE customer support. You can expect to receive a reply within 12 hours.

For the most up-to-date contact information, please refer to the product packaging or the retailer's website where you purchased the item.