

[Manuals.plus](#) /

› [LtYioe](#) /

› LtYioe MF06 4-in-1 Electric Milk Frother User Manual

## LtYioe MF06

# LtYioe MF06 4-in-1 Electric Milk Frother User Manual

Model: MF06

### IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using this appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Do not immerse the frother base, power cord, or plug in water or other liquids.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Always operate the appliance on a flat, stable, heat-resistant surface.
- Do not fill the milk frother beyond the maximum fill line to prevent overflow.
- Ensure the lid is securely in place during operation.
- Unplug the frother from the outlet when not in use and before cleaning. Allow it to cool before handling any parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Use only attachments recommended or sold by the manufacturer.
- This appliance is for household use only. Do not use outdoors.

### PRODUCT OVERVIEW

The LtYioe MF06 Electric Milk Frother is designed to create various milk-based beverages with ease. It features a 4-in-1 function for hot dense foam, thermal airy foam, cold foam, and heating milk. Its quiet operation and automatic shut-off ensure convenience and safety.

### Components

- Frother Jug (with non-stick interior)
- Transparent Lid
- Frothing Whisk / Stirring Paddle

- Power Base
- Cleaning Brush



Image: The LtYioe MF06 Electric Milk Frother, showcasing its sleek black design and main components.



Image: Key features of the frother, including automatic shut-off, precise temperature control, and quiet operation.

SPECIFICATIONS

|                           |                                                                            |
|---------------------------|----------------------------------------------------------------------------|
| Brand                     | LtYioe                                                                     |
| Model Name                | MF06                                                                       |
| Color                     | Black                                                                      |
| Material                  | Stainless Steel                                                            |
| Capacity                  | 350 Milliliters (11.8oz) for heating, 160 Milliliters (5.6oz) for frothing |
| Wattage                   | 500 watts                                                                  |
| Special Feature           | Auto Shut-Off                                                              |
| Power Source              | Corded Electric                                                            |
| Product Care Instructions | Hand Wash Only                                                             |

SETUP

## 1. Unpacking

Carefully remove all components from the packaging. Retain packaging for future storage or transport if needed. Check for any damage during transit.

## 2. Initial Cleaning

Before first use, wash the frother jug interior, lid, and whisk with warm soapy water. Rinse thoroughly and dry. Wipe the exterior of the frother jug and the power base with a damp cloth. Do not immerse the power base in water.

## 3. Placement

Place the power base on a dry, flat, and stable surface away from water sources. Ensure the power cord is not dangling or in contact with hot surfaces.

## OPERATING INSTRUCTIONS

The LtYioe MF06 frother offers four distinct functions controlled by a single button. Ensure the frothing whisk is correctly inserted at the bottom of the jug for frothing functions, or use the stirring paddle for heating without foam.

### 1. Fill Milk

Pour fresh milk into the frother jug. Observe the internal MAX and MIN fill lines. Do not exceed the MAX line for heating (350ml) or frothing (160ml) to prevent overflow. For best results, use cold milk.



Image: Internal markings indicating maximum capacity for heating (350ml) and frothing (160ml), and minimum capacity for frothing (110ml).

## 2. Select Function

Place the lid on the jug and place the jug onto the power base. Press the control button to cycle through the desired modes:

- **Hot Dense Milk Foam:** Press the button once. The indicator light will illuminate. Ideal for cappuccinos.
- **Thermal Airy Foam:** Press the button twice. The indicator light will illuminate. Suitable for lattes.
- **Cold Foam (Normal Temperature):** Press the button three times. The indicator light will illuminate. Perfect for iced coffees.
- **Heating Milk (No Foam):** Press the button four times. The indicator light will illuminate. For hot chocolate or warm milk.



Image: Visual representation of the four operating modes and the single-button control interface.

## 3. Operation

The frother will begin operation automatically after selecting a mode. It will automatically shut off once the process is complete (approximately 2 minutes for frothing, 3 minutes for heating). The milk will be heated to approximately 65°C (149°F) for hot functions.



Image: Illustrates the smooth and tasty milk foam produced by the frother, ready to be added to coffee.

#### 4. Serving

Carefully remove the frother jug from the base and pour the frothed or heated milk into your beverage. The jug handle remains cool to the touch.

### MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the life of your milk frother.

#### 1. After Each Use

Immediately after each use, rinse the interior of the frother jug, the whisk, and the lid with warm water. This prevents milk residue from drying and sticking.

#### 2. Deep Cleaning

For a more thorough clean, use warm soapy water and the included cleaning brush to gently scrub the non-stick interior. The non-stick coating allows for easy cleaning. Rinse thoroughly and dry all parts.



Image: Demonstrates the easy cleaning process of the frother's non-stick interior using the provided cleaning brush under running water.

### Important Notes:

- Do not use abrasive cleaners, metal scouring pads, or harsh chemicals, as these can damage the non-stick coating.
- Never immerse the power base or the exterior of the frother jug in water. Wipe clean with a damp cloth only.
- Ensure all parts are completely dry before storing or next use.

### TROUBLESHOOTING

| Problem                               | Possible Cause                                                                           | Solution                                                                                                                                                                        |
|---------------------------------------|------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Frother does not start.               | Not plugged in; Frother jug not correctly placed on base; Power outage.                  | Ensure the frother is securely plugged into a working outlet. Check that the jug is properly seated on the power base. Verify power supply.                                     |
| Milk is not frothing or foam is poor. | Milk level too high or too low; Incorrect milk type; Whisk not installed; Milk too warm. | Ensure milk is between MIN and MAX frothing lines. Use fresh, cold milk (dairy or barista-style plant-based milk recommended). Verify the frothing whisk is correctly inserted. |
| Milk is not heating.                  | Incorrect mode selected; Frother jug not correctly placed on base.                       | Ensure the 'Heating Milk' mode is selected. Check that the jug is properly seated on the power base.                                                                            |

|                 |                              |                                                                                 |
|-----------------|------------------------------|---------------------------------------------------------------------------------|
| Milk overflows. | Milk level exceeds MAX line. | Always ensure milk does not exceed the MAX fill line for the selected function. |
|-----------------|------------------------------|---------------------------------------------------------------------------------|

## WARRANTY AND SUPPORT

This product is designed for reliable performance. If you encounter any issues or have questions regarding your LtYioe MF06 Electric Milk Frother, please refer to the retailer's return policy or contact customer service for assistance. Please have your purchase information readily available.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

#### Name

#### Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

#### Question

#### Details

Submit question