



Manuals.plus /

- › Fisca /
- › Fisca Baby Bottle Sterilizer and Dryer User Manual

Fisca DG-3168-3

Fisca Baby Bottle Sterilizer and Dryer User Manual

Model: DG-3168-3

1. PRODUCT OVERVIEW

The Fisca 5-in-1 Baby Bottle Sterilizer and Dryer is an essential appliance designed to simplify the process of sterilizing and drying baby bottles, pacifiers, pump parts, and other accessories. This versatile unit offers multiple functions including sterilization, drying, milk warming, food heating, and a combined sterilization and drying cycle, ensuring a hygienic environment for your baby's feeding items.



Figure 1.1: Fisca Baby Bottle Sterilizer and Dryer main unit.



Figure 1.2: The Fisca 5-in-1 Baby Bottle Sterilizer and Dryer in a home setting.

2. KEY FEATURES

- **5-in-1 Multifunctionality:** Offers Sterilization, Drying, Sterilization+Drying, Warm Milk, and Hot Food functions.
- **Fast & Efficient Sterilization:** Utilizes 360° high-temperature steam technology combined with hot air drying for 3D sterilization, eliminating 99.9% of harmful bacteria.
- **Large Capacity & 3 Combinations:** Features a 2-layer design with adjustable stacking options to accommodate various items, from small pacifiers to multiple bottles and accessories.
- **Easy-to-Use Touch Control Panel:** Intuitive LCD control panel for simple operation and adjustable timer settings.
- **Safe & Reliable:** Made of high-quality materials, includes an auto-off function for safety and energy efficiency, and a low-noise design.
- **12-Hour Constant Milk Warming:** Maintains milk at a perfect temperature for extended periods.



Figure 2.1: Overview of the 5-in-1 multi-functions.

Fast and Efficient Sterilizer

360° Steam Sterilization & 3D Surround Wind

99.9%



Ensures a Thorough and Rapid Elimination of 99.9% of Harmful Bacteria From your Baby's Stuffs



Figure 2.2: Depiction of the fast and efficient sterilization process.

Large Capacity Interior, Adjustable Design



Figure 2.3: Modular design for large capacity and flexible combinations.

3. SETUP GUIDE

Before first use, please ensure all components are clean and dry. Refer to the "Maintenance and Cleaning" section for initial cleaning instructions.

3.1 Component Identification

The unit consists of the following main parts:

1. Base Unit with Control Panel and Heating Plate
2. Lower Basket (for bottles)
3. Upper Basket (for smaller items like pacifiers, nipples)
4. Lid with Handle

3.2 Assembly

1. Place the Base Unit on a stable, flat, heat-resistant surface.

2. Pour the recommended amount of distilled water (approximately 100ml for sterilization) onto the stainless steel heating plate in the Base Unit. Do not overfill.
3. Place the Lower Basket onto the Base Unit. Arrange bottles upside down on the pegs.
4. If using, place the Upper Basket on top of the Lower Basket. Arrange smaller items like pacifiers, nipples, or pump parts.
5. Place the Lid securely on top of the assembled baskets.
6. Plug the power cord into a suitable electrical outlet.



Figure 3.1: Key components and design features.

4. OPERATING INSTRUCTIONS

The Fisca Sterilizer and Dryer features an intuitive touch LCD control panel. Ensure the unit is properly assembled and plugged in before operation.



Figure 4.1: The touch control panel.

4.1 General Operation

1. Press the **On/Off** button to power on the unit. The display will illuminate.
2. Press the **Function** button repeatedly to cycle through the available modes: Disinfection (Sterilization), Drying, Hot Food, Warm Milk, and Disinfection+Drying.
3. Use the **+** and **-** buttons to adjust the time or temperature settings for the selected function.
4. Once settings are confirmed, the unit will automatically begin the cycle.
5. The unit will automatically shut off when the cycle is complete.
6. To cancel a cycle at any time, press the **Cancel (X)** button.

4.2 Specific Functions

4.2.1 Disinfection (Sterilization)

This mode uses high-temperature steam to sterilize items. Ensure 100ml of distilled water is in the heating plate.

- Select "Disinfection" mode using the Function button.

- The default time is typically 40 minutes. Adjust if necessary.
- Press On/Off to start.

4.2.2 Drying

This mode uses hot air to dry items after washing or sterilization.

- Select "Drying" mode.
- Adjust drying time as needed (e.g., 30-60 minutes depending on load).
- Press On/Off to start.

4.2.3 Disinfection + Drying

A combined cycle for complete sterilization and drying. Ensure 100ml of distilled water is in the heating plate.

- Select "Disinfection+Drying" mode.
- The unit will automatically perform both cycles.
- Press On/Off to start.

4.2.4 Warm Milk

This function gently warms milk to a desired temperature and can maintain it for up to 12 hours. Place the bottle directly into the base unit's water reservoir, ensuring the water level is below the bottle's rim.

- Select "Warm Milk" mode.
- Adjust the target temperature (e.g., 40°C for optimal milk temperature).
- Press On/Off to start.

Easy-To-Use Control Panel

make setup in one click



Figure 4.2: Keeping milk warm at 40°C.

4.2.5 Hot Food

This function can heat baby food. Place the food container into the base unit's water reservoir.

- Select "Hot Food" mode.
- Adjust the heating time as needed.
- Press On/Off to start.

5. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and hygiene of your Fisca Sterilizer and Dryer.

5.1 Daily Cleaning

- Always unplug the unit and allow it to cool completely before cleaning.
- Wipe the exterior of the base unit with a damp cloth. Do not immerse the base unit in water.
- Wash the baskets and lid with warm soapy water, rinse thoroughly, and air dry or wipe dry.

5.2 Descaling the Heating Plate

Mineral deposits (limescale) may build up on the heating plate over time, especially in areas with hard water. Descale regularly to maintain efficiency.

1. Ensure the unit is unplugged and cool.
2. Mix 50ml of white vinegar with 100ml of distilled water.
3. Pour the mixture onto the heating plate.
4. Let it soak for 30 minutes to an hour, or until the deposits loosen. For stubborn deposits, you can gently scrub with a soft brush or sponge.
5. Pour out the mixture and rinse the heating plate thoroughly with clean water. Wipe dry.
6. Do not use abrasive cleaners or scouring pads, as they can damage the heating plate.

6. TROUBLESHOOTING

If you encounter any issues with your Fisca Sterilizer and Dryer, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Unit does not power on.	Not plugged in; power outlet issue; unit malfunction.	Ensure power cord is securely plugged in. Test the outlet with another appliance. If still no power, contact customer support.
Sterilization cycle not effective / items not clean.	Insufficient water; items not pre-cleaned; improper loading.	Ensure 100ml of distilled water is used. Always pre-clean items before sterilizing. Do not overload the baskets; ensure steam can circulate.
Items are still wet after drying cycle.	Drying time too short; overloaded unit; poor air circulation.	Increase drying time. Reduce the number of items in the unit. Ensure items are spaced to allow air circulation.
White/brown residue on heating plate.	Mineral deposits from water (limescale).	Perform descaling as described in Section 5.2. Use distilled water to minimize buildup.
Unusual odor during operation.	New unit odor; residue on heating plate; plastic burning.	Initial use may have a slight odor, which should dissipate. Clean heating plate. If odor persists or smells like burning plastic, immediately unplug and contact support.

7. SPECIFICATIONS

Feature	Detail
Model Number	DG-3168-3
Dimensions (Package)	12.71 x 11.42 x 7.91 inches
Item Weight	3.91 pounds
Material Type	Plastic
Power of Sterilizing	350W
Power of Drying	180W
Frequency	60Hz
Country/Region of Origin	China

8. WARRANTY AND SUPPORT

For detailed warranty information, please refer to the warranty card or documentation included with your purchase. If you require technical support, have questions about product operation, or need to inquire about repairs, please contact Fisca customer service.

You can often find contact information on the official Fisca website or through the retailer where you purchased the product. For general inquiries, you may also visit the Fisca Store on Amazon.



Figure 8.1: Fisca products are designed with safety and reliability in mind.