

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [NutriBullet](#) /
- › [Nutribullet Flip Portable Blender User Manual](#)

NutriBullet NBPB50350AK

nutribullet Flip Portable Blender Instruction Manual

MODEL: NBPB50350AK | BRAND: NUTRIBULLET

Introduction to Your nutribullet Flip

The nutribullet® Flip is an innovative combination of a portable blender and an insulated tumbler, designed for convenience and efficiency. It allows you to blend your favorite smoothies and drinks on the go, keeping them cold for extended periods.



Image: The Nutribullet Flip portable blender with its various components laid out.

Key Features:

- **Portable Design:** Travel-friendly size with a convenient carry handle.
- **Insulated Tumbler:** Keeps blends cold for up to 24 hours.
- **Powerful Motor:** Equipped with an 11.1V high-torque motor capable of blending ice and frozen fruits.
- **Rechargeable Battery:** USB-C charging port provides 14+ 30-second blending cycles per full charge.
- **Self-Cleaning:** Easy cleaning by blending with dish soap and water.

Included Components

Your nutribullet Flip package includes the following:

- Motor Base and Blade
- 20 oz Insulated Cup (Black)
- Charging Block and Charging Cable (USB-C)
- Blade Cover
- Dual To Go Lid with Handle
- Stainless Steel Straws
- Cleaning Brush
- User Guide
- Recipe Guide

8 piece set includes:



Hybrid Motor
Base, Blade,
& Lid



Straw



Blade Cover



Cleaning
Brush



To-Go Lid



Charging
Block



Blending
Cup



USB-C
Charging
Cable

nutribullet.

Image: Visual representation of all 8 pieces included in the set.

Setup Guide

1. **Charge the Blender:** Before first use, fully charge the motor base using the provided USB-C charging cable and block. The indicator light will show charging status.
2. **Prepare Ingredients:** Add your desired ingredients (fruits, vegetables, protein powder) into the 20 oz insulated cup. Ensure liquid is added before blending. Do not overfill; make sure ingredients and liquid do not exceed the MAX line (16 oz / 450 ml).
3. **Attach Blade:** Screw the motor base with the blade securely onto the top of the insulated cup. Ensure it is tightly sealed to prevent leaks and activate the blending function. The indicator light on the motor base will turn purple when properly attached and ready to blend.

Fill & twist.



nutribullet.

Flip & blend.



Flip & sip.



Image: Visual guide for filling, twisting the blade, blending, and sipping.

Operating Instructions

Blending Your Drink

1. After preparing ingredients and attaching the blade (as per Setup), flip the blender upside down so the motor base is at the bottom.
2. Press the power button once to activate the blending cycle. The blender is designed for 30-second blending cycles.
3. For full control over ingredients, you can press the button again to stop the blending cycle or use the pulse function.
4. Do not blend for more than 1 minute continuously. Allow the motor to cool down if multiple cycles are needed.

Your browser does not support the video tag.

Video: Official Nutribullet video demonstrating the Flip's blending capabilities and ease of use.

Charging the Battery

The nutribullet Flip features a USB-C charging port for convenient power. A full charge provides 14+ 30-second blending cycles. Connect the provided USB-C cable to the motor base and the charging block to a power outlet. The indicator light will show charging status.

Rechargeable.

A USB-C charging port
powers your battery
with 14+ 30-second
blending cycles*.



*New unit tested, fully charged, with back-to-back blending cycles using 12oz water, 2 scoops protein powder, and 1oz regular ice cubes. Results may vary depending on ingredients.

nutribullet.



Image: Close-up view of the USB-C charging port on the Nutribullet Flip motor base.

Using the To-Go Lid

For no-stress transportation after blending, you can replace the motor base with the dual To Go Lid. This lid features a convenient flip-top for sipping and a handle for easy carrying.

Travel Lid.

Twist-on to-go lid,
for no-stress
transportation.



nutribullet.



Image: The Nutribullet Flip with its travel-friendly To Go Lid, designed for easy transport.

Maintenance and Care

Self-Cleaning Function

Cleaning your nutribullet Flip is quick and easy. Simply add a drop of dish soap and water into the insulated cup, attach the motor base, and blend for one 30-second cycle. Rinse thoroughly afterward.

Self-cleaning.
Simply add dish
soap and water and
blend for one cycle.



nutribullet.



Image: Illustration of the self-cleaning process for the Nutribullet Flip.

General Care

- Do not submerge the motor base in water. Wipe clean with a damp cloth.
- The insulated cup and To Go Lid are dishwasher-safe.
- Store the blender in a dry place when not in use.

Troubleshooting

If you encounter issues with your nutribullet Flip, please refer to the common problems and solutions below:

- **Blender not turning on:**
 - Ensure the motor base is fully charged.
 - Verify that the motor base is securely screwed onto the cup and the indicator light is purple.

- **Ingredients not blending properly:**
 - Add more liquid to help ingredients move freely.
 - Do not overfill the cup; ensure ingredients are below the MAX line.
 - For frozen ingredients, ensure they are cut into smaller pieces.
 - Try pulsing the blender a few times to dislodge stuck ingredients.
- **Blender is leaking:**
 - Ensure the motor base or To Go Lid is screwed on tightly and correctly aligned with the cup.

Product Specifications

Feature	Detail
Brand	NutriBullet
Model Number	NBPB50350AK
Color	Black
Special Feature	Cordless
Capacity	20 oz (1.3 Pounds)
Product Dimensions	3.87"D x 4.25"W x 9.12"H
Power Source	Battery Powered
Voltage	11.1 Volts
Item Weight	4.55 pounds
UPC	810097975378

Warranty and Support

Your nutribullet Flip Portable Blender comes with a**Limited Warranty**. For detailed terms and conditions, please refer to the User Guide included in your package.

For any support needs, including troubleshooting not covered in this manual, replacement parts, or warranty claims, please visit the official NutriBullet website or contact their customer service directly.

Note: Product built to North American & Canadian Electrical Standards.