

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [SANODESK](#) /
- › [SANODESK Electric Standing Desk EN2 Instruction Manual](#)

SANODESK EN2

SANODESK Electric Standing Desk EN2 Instruction Manual

Model: EN2 (55"x28" White Frame + Rustic Brown Top)

1. INTRODUCTION AND OVERVIEW

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your SANODESK Electric Standing Desk EN2. This desk is designed to offer a versatile and ergonomic workspace, allowing seamless transitions between sitting and standing positions.

Key features include a spacious whole-piece desktop, an electric height adjustment system with memory presets, an integrated desk clamp power strip, and an under-desk cable management tray.



Figure 1: SANODESK Electric Standing Desk, 55x28 inches, White Frame with Rustic Brown Top.

2. SETUP AND ASSEMBLY

The SANODESK Electric Standing Desk requires assembly. Please follow the detailed installation manual provided with your product. An accurate video guide is also available to assist with the process. The desk features embedded screw hole locations for easier assembly. Note that a drill may be required for certain steps, but it is not included in the package.

SANODESK

My Best Coworkers



Figure 2: SANODESK standing desk in a home office environment, illustrating the assembled product.

3. OPERATING INSTRUCTIONS

3.1. Height Adjustment

The desk features an electric height adjustable system controlled by a 6-button digital controller. The height can be smoothly adjusted from 28.1 inches to 45.7 inches at a speed of 0.6 inches per second, operating quietly under 50 dB.

Use the up and down arrows on the control panel to manually adjust the desk height. The digital display will show the current height.

Standing desk equipped with a power outlet



Figure 3: Digital control panel for height adjustment, located under the desktop.

3.2. Memory Presets

The digital controller includes 4 programmable memory presets. To save a desired height:

1. Adjust the desk to your preferred sitting or standing height using the up/down arrows.
2. Press the 'M' or 'Set' button (if available, otherwise refer to specific manual for your controller) followed by one of the numbered preset buttons (1, 2, 3, or 4). The height is now saved to that preset.
3. To recall a saved height, simply press the corresponding numbered preset button.

Organize cords with SANODESK cable management tray to save space and declutter your desk



Figure 4: LED memory control panel with preset buttons.

3.3. Integrated Power Outlet

The desk is equipped with a portable power outlet that clamps to the desk surface. This power strip includes 3 AC power outlets (125V/1500W) and 2 USB-A ports (5V/2A), allowing you to power and charge multiple devices conveniently.

Desk Clamp Power Strip with Power Outlets & USB Ports



Figure 5: Close-up view of the desk clamp power strip.

3.4. Cable Management

An under-desk cable management tray is included to help keep your workspace tidy and organized. This tray reduces visible cable clutter and is spacious enough to hold multiple cables, power strips, and transformers.

BEFORE

Messy and unorganized desk with cable clutter



AFTER

Tidy, clean, safe and organized desk space

Figure 6: Before and after comparison demonstrating the effectiveness of the cable management tray.

3.5. Product Videos

Video: SANODESK Standing Desk Demo

This video provides a detailed demonstration of the SANODESK Electric Standing Desk, highlighting its features and smooth height adjustment capabilities.

Video: Durable, Noiseless Standing Desk Operation

This video showcases the durable and quiet operation of the standing desk, emphasizing its stability and ease of use for height adjustments.

Video: Adjustable Standing Desk for Home Office

This video illustrates the benefits of the adjustable standing desk for a home office setup, demonstrating its versatility and contribution to a dynamic work environment.

4. MAINTENANCE

To ensure the longevity and optimal performance of your SANODESK Electric Standing Desk, regular maintenance is recommended:

- **Cleaning:** Wipe the desktop and frame with a soft, damp cloth. For stubborn marks, use a mild, non-abrasive cleaner. Avoid harsh chemicals that may damage the surface.
- **Component Check:** Periodically check all screws and bolts to ensure they are tight. Re-tighten if necessary to maintain stability.
- **Cable Inspection:** Ensure all power cables and connections are secure and free from damage. Keep cables organized within the management tray to prevent strain or entanglement.

5. TROUBLESHOOTING

If you encounter any issues with your SANODESK Electric Standing Desk, please refer to the following common troubleshooting tips:

- **Desk Not Moving:** Check if the power cord is securely plugged into both the desk and a working wall outlet. Ensure no objects are obstructing the desk's movement.
- **Uneven Height:** If the desk appears uneven, perform a reset procedure (refer to the specific manual for your control panel model, usually involves holding down certain buttons).
- **Error Codes:** If an error code appears on the digital display, consult the detailed manual for the specific meaning and recommended solution. Often, a simple power cycle or reset can resolve minor errors.
- **Noise:** While the desk operates quietly, unusual or excessive noise may indicate an issue. Ensure all components are securely fastened.

For persistent issues or complex problems, please contact SANODESK customer support.

6. SPECIFICATIONS

Feature	Detail
Brand	SANODESK
Model Number	EN2
Desktop Dimensions	55"W x 28"D
Height Range	28.1" to 45.7"
Height Adjustment Speed	0.6" per second
Noise Level	Under 50 dB
Weight Capacity	Up to 176 lbs
Frame Material	Industrial-grade Carbon Steel
Top Material	Engineered Wood
Power Strip Outlets	3 AC (125V/1500W), 2 USB-A (5V/2A)

Feature	Detail
Control Panel	6-button digital controller with 4 memory presets
Assembly Required	Yes

7. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your product or contact SANODESK customer service directly. Ensure you have your model number (EN2) and purchase details available when seeking support.