
[Manuals.plus](#) /

› [Superun](#) /

› Superun Walking Pad BA06 Instruction Manual

Superun BA06

Superun Walking Pad BA06 Instruction Manual

Model: BA06

1. INTRODUCTION

The Superun Walking Pad BA06 is a compact and portable treadmill designed to integrate exercise into your daily routine, whether at home or in the office. This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your device. Please read this manual thoroughly before first use and retain it for future reference.




Image: The Superun Walking Pad BA06, showcasing its compact design and suitability for use with a standing desk. A person is shown walking on the pad, highlighting its functionality for active work environments.

2. SAFETY INFORMATION

To ensure safe operation and prevent injury, please adhere to the following safety guidelines:

- **Maximum Weight Capacity:** Do not exceed the maximum user weight of 250 pounds (113 kg).
- **Placement:** Place the walking pad on a flat, stable surface. Ensure there is adequate clear space around the device (at least 2 feet on all sides) for safe operation and emergency dismount.
- **Power Connection:** Use only the provided power cord and connect to a grounded outlet. Do not use extension cords.
- **Children and Pets:** Keep children and pets away from the walking pad during operation.
- **Footwear:** Always wear appropriate athletic footwear when using the walking pad.
- **Health Conditions:** Consult a physician before starting any new exercise program, especially if you have pre-existing health conditions.

- **Emergency Stop:** Familiarize yourself with the emergency stop procedure.
- **Belt Alignment:** Regularly check the walking belt for proper alignment. Misaligned belts can cause damage to the unit and pose a safety risk. Refer to the maintenance section for adjustment instructions.

3. PACKAGE CONTENTS

Upon unpacking, please verify that all the following components are included:

- Superun Walking Pad BA06 Unit
- Remote Control (x1)
- Lubricant (x1)
- Tool Kit (includes wrench and screwdriver) (x1)
- User Manual (x1)




Image: A visual representation of the items included in the Superun Walking Pad BA06 package, ensuring users can confirm they have all necessary components.

4. SETUP

The Superun Walking Pad BA06 requires no assembly and is ready for use directly out of the box.

4.1 Initial Placement

- Unpack the walking pad from its packaging.
- Place the unit on a firm, level surface. Ensure the area is free from obstructions.
- Verify that the power cord is easily accessible and not pinched or tangled.

4.2 Power Connection

- Plug the power cord into the walking pad's power input.
- Insert the other end of the power cord into a standard, grounded electrical outlet.

4.3 Storage

The compact design and built-in wheels allow for easy storage. After use, the walking pad can be moved and stored under

a desk, bed, or sofa.



Image: Demonstrates the ease of moving and storing the Superun Walking Pad BA06, highlighting its portability and space-saving design for home or office environments.

5. OPERATING INSTRUCTIONS

5.1 Basic Operation

- **Power On:** Press the power button on the unit or the remote control. The LED display will illuminate.
- **Start/Stop:** Press the Start/Stop button on the remote control to begin or end your workout.
- **Speed Adjustment:** Use the '+' and '-' buttons on the remote control to increase or decrease the walking speed. The speed range is from 0.6 MPH to 2.5 MPH.
- **LED Display:** The integrated LED display shows real-time data including Time, Distance, Speed, and Calories Burned.

LED DISPLAY & REMOTE CONTROL

users to view real-time progress displays during motion.



Image: A detailed view of the Superun Walking Pad BA06's LED display, showing workout metrics, and the accompanying remote control for easy speed adjustments.

5.2 Remote Control

The remote control allows for convenient adjustment of the walking pad's functions without needing to bend down. It is used to power on/off, start/stop, and adjust speed.

5.3 Pitpat App Integration

Enhance your workout experience by connecting your Superun Walking Pad BA06 to the Pitpat App via Bluetooth.

- **Connectivity:** Ensure Bluetooth is enabled on your mobile device and follow the app's instructions to pair with the walking pad.
- **Features:** The Pitpat App offers various features including fitness training videos, immersive running scenarios, exercise reports, and real-time heart rate monitoring (if compatible accessories are used).

EXERCISE VIA THE APP OF PitPat




Image: Illustrates the integration of the Superun Walking Pad BA06 with the Pitpat App, showing a user engaging with virtual running scenarios and fitness tracking features.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your Superun Walking Pad BA06.

6.1 Lubrication

The walking belt requires periodic lubrication to reduce friction and wear. Use the provided lubricant.

- **Frequency:** Lubricate the belt every 3-6 months, or after approximately 50 hours of use, depending on usage frequency.
- **Procedure:** Turn off and unplug the walking pad. Lift the edge of the walking belt and apply a small amount of lubricant evenly to the center of the deck beneath the belt. Run the walking pad at a low speed for a few minutes to distribute the lubricant.



Image: The lubricant bottle provided for maintaining the walking belt of the Superun Walking Pad BA06.

6.2 Walking Belt Adjustment

If the walking belt shifts to one side or feels loose, it may require adjustment. This is crucial for safe operation and to prevent damage to the belt and motor.

- **Tools:** Use the included wrench from the tool kit.
- **Procedure:** Turn off and unplug the walking pad. Locate the adjustment bolts at the rear of the unit.
- If the belt is shifting to the left, turn the right adjustment bolt clockwise a quarter turn.
- If the belt is shifting to the right, turn the left adjustment bolt clockwise a quarter turn.
- If the belt is too loose (slipping), turn both bolts clockwise equally, a quarter turn at a time.
- Plug in the unit and run it at a low speed (e.g., 1 MPH) for a few minutes to check alignment. Repeat adjustments as necessary, making small turns.



Image: The wrench from the Superun Walking Pad BA06 tool kit, used for belt adjustments.

7. TROUBLESHOOTING

This section addresses common issues you might encounter with your Superun Walking Pad BA06.

Problem	Possible Cause	Solution
Walking belt shifts to one side	Uneven belt tension or improper alignment.	Refer to Section 6.2 for detailed belt adjustment instructions. Make small, incremental adjustments.
Walking pad does not power on	Power cord not properly connected; outlet issue.	Ensure the power cord is securely plugged into both the unit and a working electrical outlet. Test the outlet with another device.
Remote control not responding	Remote battery low or depleted; remote not paired.	Replace the remote control battery. If the issue persists, refer to the full user manual for remote pairing instructions.

Problem	Possible Cause	Solution
Unusual noise during operation	Lack of lubrication; loose components.	Lubricate the walking belt as per Section 6.1. Check for any loose screws or components and tighten them if necessary.

8. SPECIFICATIONS

Feature	Specification
Brand	Superun
Model Name	BA06
Product Dimensions (LxWxH)	38.5"D x 20.24"W x 4.13"H
Item Weight	37.9 Pounds
Material	Alloy Steel
Maximum Speed	2.5 Miles per Hour
Minimum Speed	0.6 Miles per Hour
Maximum Weight Recommendation	250 Pounds
Maximum Horsepower	2.2 Horsepower
Display Type	LED
Power Source	Corded Electric
Connectivity Technology	Bluetooth
Metrics Measured	Calories Burned, Distance, Speed, Time
UPC	717331441234

9. WARRANTY AND SUPPORT

9.1 Product Warranty

The Superun Walking Pad BA06 comes with a 1-year limited warranty from the date of purchase. This warranty covers manufacturing defects under normal use. Please retain your proof of purchase for warranty claims.

9.2 Customer Support

For technical assistance, warranty inquiries, or any questions regarding your Superun Walking Pad BA06, please contact Superun customer support. Refer to the contact information provided on the Superun official website or your purchase documentation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question