

[Manuals.plus](#) /

› [ALLJOY](#) /

› ALLJOY Collapsible Foot Spa Bath Massager with Heat, Bubble, Remote Control Shiatsu Foot Massage Soak Tub User Manual

ALLJOY 744316625044

ALLJOY Collapsible Foot Spa Bath Massager User Manual

Model: 744316625044 | Brand: ALLJOY

IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using the ALLJOY Collapsible Foot Spa Bath Massager. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always add water to the foot spa before plugging it in or turning it on.
- Do not operate the foot spa if the power cord or plug is damaged.
- Keep the appliance away from children and pets.
- Do not stand in the foot spa. Sit comfortably while using.
- Unplug the foot spa from the power outlet when not in use and before cleaning.
- Do not immerse the main unit in water or other liquids.
- Consult a doctor before use if you have any medical conditions, including diabetes, heart conditions, or skin conditions.
- Do not use the foot spa for more than 60 minutes at a time. Allow the unit to cool down before next use.
- Ensure the remote control signal light is directed towards the indicator on the tub for proper function.

PRODUCT OVERVIEW

The ALLJOY Collapsible Foot Spa Bath Massager is designed to provide a relaxing and therapeutic foot massage experience. It integrates heating, massage, oxygen bubbles, and vibration functions to soothe tired feet.



Image: The ALLJOY Collapsible Foot Spa Bath Massager in its open, ready-to-use state, showcasing its blue and white design, control panel, and internal massage rollers.

Key Features:

- **Heating Function:** Maintains water temperature between 105°F-118°F (41°C-48°C).
- **Shiatsu Massage:** Features non-automatic massage rollers and acupressure points.
- **Oxygen Bubbles:** Generates bubbles to stimulate foot acupoints and accelerate water circulation.
- **Vibration Function:** Provides additional soothing relief.
- **Remote Control:** Allows for convenient adjustment of settings without bending.
- **Intelligent Timer:** Adjustable from 10 to 60 minutes.
- **Collapsible Design:** Folds down to 5.5 inches thick for easy storage.

Overview of Details

A new way of foot spa



Image: Detailed diagram of the foot spa components, including the heating element, shiatsu massage nodes, temperature light indicator, massage rollers, bubble holes, and the removable control remote.

PACKAGE CONTENTS

Please check the package contents upon unboxing to ensure all items are present:

- ALLJOY Collapsible Foot Spa Bath Massager Unit

- Remote Control
- Power Cord
- User Manual

SETUP

Initial Setup:

1. Place the foot spa on a flat, stable, and dry surface.
2. Unfold the foot spa by gently pulling up the sides until it locks into place.
3. Fill the foot spa with warm or cold water to the indicated maximum fill line. Do not overfill.
4. Plug the power cord into a standard electrical outlet.

OPERATION

Controls Overview:

The foot spa can be operated using the integrated control panel or the included remote control.

Removable Remote Control

No need to bend over to operate



Image: Close-up of the remote control for the ALLJOY Foot Spa, showing buttons for bubble option, power, timer (20/30 mins), low temperature, medium temperature, and high temperature.

Using the Foot Spa:

1. Press the Power button on the control panel or remote to turn on the unit.
2. Adjust the temperature to your preference (105°F-118°F / 41°C-48°C) using the temperature control buttons (Low,

Medium, High) on the remote. The unit will automatically heat and maintain the selected temperature.

Temperature Adjustment

Rejuvenate stressed feet and mind after a long day of work.



105°F-118°F
(41°C-48°C)



Leakage
protection



Automatic
power off



Help blood
circulation



Image: A person's feet soaking in the foot spa, illustrating the temperature adjustment feature with icons for temperature range, leakage protection, automatic power off, and improved blood circulation.

3. Activate the Oxygen Bubble function by pressing the Bubble button on the remote.



Bubbles Massage

can continuously stimulate
the foot acupoints



Bubble Holes

Bubble oxygen can generate
oxygen in the water, accelerate
the water circulation

Image: Two panels showing the bubbles massage feature. The top panel shows water bubbling vigorously, and the bottom panel highlights the bubble holes, explaining that bubble oxygen generates oxygen in the water and accelerates circulation.

4. Place your feet into the foot spa. Utilize the non-automatic massage rollers by moving your feet back and forth over them to target specific areas of discomfort.

Non-Automatic Massage Rollers

6 removable shiatsu massage rollers help relieve foot fatigue



Image: Close-up of the blue non-automatic massage rollers within the foot spa, with arrows indicating the direction of foot movement for massage. Below are three smaller images showing hands massaging different parts of the foot to relieve pain.

5. Set the desired session duration using the Timer button on the remote (10 to 60 minutes).
6. Enjoy your foot spa experience. The maximum recommended foot size is 11.5M.

Massage to Care for Your Feet



Max Foot Size
11.5M



Image: A person relaxing on a sofa with their feet in the ALLJOY Foot Spa, holding a cup, demonstrating a typical use scenario. The maximum foot size of 11.5M is indicated.

7. To use the removable medicine box, open its lid, place bath salts or other foot care products inside, and close it. The removable pumice stone can be used for exfoliation.

MAINTENANCE

Cleaning:

1. After each use, unplug the foot spa and drain the water.
2. Wipe the interior and exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or harsh chemicals.
3. Ensure all components are completely dry before storing.
4. The removable medicine box and pumice stone can be rinsed under running water.



Removable Medicine Box, Bath salts, etc, can be placed (For display only, not included)



Removable pumice stone for easy foot care

Image: Two panels showing maintenance features. The top panel shows a hand opening the removable medicine box, which contains bath salts (for display only). The bottom panel shows a hand holding a removable pumice stone over the foot spa for easy foot care.

Storage:

1. Once clean and dry, collapse the foot spa by pressing the side buttons and folding it down.
2. Store the collapsed unit in a cool, dry place, such as under a sofa, in a closet, or on a shelf.



Collapsible Foot Spa

Folded easily in two seconds with no tool required,
can be stowed under the bed or sofa, and on a closet shelf

Image: Hands collapsing the ALLJOY Foot Spa to its flat storage position, demonstrating how it can be stowed under a bed or sofa.

Problem	Possible Cause	Solution
Unit does not turn on.	Not plugged in; Power outlet issue; Unit damaged.	Ensure power cord is securely plugged in. Test outlet with another device. Contact customer support if unit is damaged.
Remote control not working.	Remote batteries low/dead; Signal not directed correctly.	Replace remote batteries. Ensure the remote's signal light is pointed towards the indicator on the foot spa.
Water not heating.	Heating function not activated; Temperature setting too low.	Ensure heating function is turned on. Adjust temperature to a higher setting.
Bubbles/Vibration not working.	Function not activated.	Press the respective button on the control panel or remote to activate.

SPECIFICATIONS

Feature	Detail
Brand	ALLJOY
Model Number	744316625044
Product Dimensions (Unfolded)	12.5 x 43 x 35 cm
Item Weight	1.2 Kilograms
Material	Polyethylene (PE)
Power Source	Corded Electric
Temperature Range	105°F-118°F (41°C-48°C)
Timer Settings	10 to 60 minutes
Special Features	Heat, Bubble, Remote Control, Shiatsu Massage, Collapsible Design
Max Foot Size	11.5M

WARRANTY AND SUPPORT

ALLJOY products are manufactured with quality and care. For warranty information or technical support, please refer to the contact details provided with your purchase documentation or visit the official ALLJOY website. Please retain your proof of purchase for any warranty claims.

Legal Disclaimer: Actual product packaging and materials may contain more and different information than what is shown on our website. We recommend that you do not rely solely on the information presented and that you always read labels, warnings, and directions before using or consuming a product.

© 2024 ALLJOY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question