

[Manuals.plus](#) /

› [Cumrige](#) /

› Cumrige M2 Power Adapter User Manual

Cumrige M2 Power Adpater

Cumrige M2 Power Adapter User Manual

For Self Cleaning Litter Box

1. INTRODUCTION

This manual provides essential information for the safe and effective use of your Cumrige M2 Power Adapter. Please read this manual thoroughly before using the product and retain it for future reference.

The Cumrige M2 Power Adapter is specifically designed to provide the necessary power supply for the Cumrige Self Cleaning Litter Box M2 model, ensuring its optimal performance and functionality.

2. IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, or injury, please observe the following safety precautions:

- **Read all instructions:** Before using the power adapter, read all safety and operating instructions.
- **Indoor use only:** This power adapter is designed for indoor use in dry locations only. Do not expose to water or moisture.
- **Proper voltage:** Ensure the power outlet voltage matches the adapter's input requirements (100-240V~).
- **Avoid damage:** Do not use the adapter if the cord or plug is damaged. Do not modify or disassemble the adapter.
- **Unplug when not in use:** Disconnect the adapter from the power outlet when not in use for extended periods or during electrical storms.
- **Keep away from children:** This is not a toy. Keep out of reach of children and pets.
- **Ventilation:** Ensure adequate ventilation around the adapter during operation. Do not cover it.

3. PACKAGE CONTENTS

Verify that all items are present and in good condition upon opening the package:

- Cumrige M2 Power Adapter (Model No: GQ24-120200-CU)

4. SETUP INSTRUCTIONS

Follow these steps to properly set up your Cumrige M2 Power Adapter:

1. **Unpack:** Carefully remove the power adapter from its packaging.
2. **Inspect:** Check the adapter and its cable for any visible damage. If damaged, do not use.
3. **Connect to Litter Box:** Locate the power input port on your Cumrige Self Cleaning Litter Box M2. Insert the barrel connector end of the power adapter cable firmly into this port.
4. **Connect to Power Outlet:** Plug the two-prong plug of the power adapter into a standard electrical wall outlet (100-240V~, 50/60Hz).
5. **Verify Connection:** Ensure both connections are secure. The litter box should now receive power and indicate its status according to its own user manual.



Figure 4.1: The Cumrige M2 Power Adapter. This image shows the white power adapter with its two-prong US plug, the attached white cable, and the barrel connector. The adapter body displays product specifications and various certification marks, including UL Listed and FC.

5. OPERATING THE POWER ADAPTER

The Cumrige M2 Power Adapter operates automatically once connected to a power source and the litter box. It

provides continuous power to the litter box, allowing it to perform its self-cleaning functions as designed.

- **Always On:** The adapter is designed to be continuously plugged in to power the litter box.
- **Power Indicator:** The adapter itself does not have an indicator light. Refer to your Cumrige Self Cleaning Litter Box M2 manual for its power status indicators.

6. CARE AND MAINTENANCE

Proper care ensures the longevity and safe operation of your power adapter:

- **Cleaning:** Disconnect the adapter from the power outlet before cleaning. Wipe the adapter and cable with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Storage:** If storing the adapter for an extended period, unplug it and coil the cable neatly. Store in a cool, dry place away from direct sunlight.
- **Inspection:** Periodically inspect the adapter and cable for any signs of wear, cuts, or damage. If damage is found, discontinue use immediately and replace the adapter.
- **Avoid Stress:** Do not bend the cable sharply or place heavy objects on it, as this can damage the internal wires.

7. TROUBLESHOOTING

If you encounter issues with your power adapter, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Litter box not receiving power.	Adapter not plugged in securely.	Ensure the adapter is fully plugged into both the wall outlet and the litter box.
	Power outlet is not active.	Test the outlet with another device. Check your home's circuit breaker.
	Damaged adapter or cable.	Inspect for visible damage. If damaged, discontinue use and replace the adapter.
Litter box functions intermittently.	Loose connection.	Ensure all connections are tight and secure.
	Overheating.	Ensure the adapter has adequate ventilation and is not covered. Unplug and allow to cool.

If the problem persists after trying these solutions, please contact Cumrige customer support.

8. PRODUCT SPECIFICATIONS

Feature	Detail
Model Number	GQ24-120200-CU
Input Voltage	100-240V~

Feature	Detail
Input Frequency	50/60Hz
Input Current (Max)	1.0A
Output Voltage	12.0V
Output Current	2.0A
Manufacturer	DONGGUAN GANGQI ELECTRONIC CO LTD
Certifications	cULus Listed (E336751), FC, VI (Efficiency Level)
Item Weight	3.53 ounces (100 Grams)
Product Dimensions	2 x 1 x 1 inches

9. WARRANTY INFORMATION

Cumrige products are manufactured to high-quality standards. While specific warranty details are not provided in this manual, most Cumrige products come with a limited warranty covering defects in materials and workmanship under normal use. Please retain your purchase receipt as proof of purchase.

For detailed warranty terms and conditions, please refer to the warranty card included with your original Cumrige Self Cleaning Litter Box M2 or visit the official Cumrige website.

10. CUSTOMER SUPPORT

If you have any questions, require technical assistance, or need to report an issue with your Cumrige M2 Power Adapter, please contact Cumrige customer support.

- **Online Support:** Visit the official Cumrige website for FAQs, troubleshooting guides, and contact forms.
- **Email Support:** Refer to your product packaging or the Cumrige website for the customer service email address.
- **Phone Support:** Check the Cumrige website for available phone support numbers and operating hours.

When contacting support, please have your product model number (M2 Power Adapter) and purchase information ready.

