

[Manuals.plus](#) /

› [Zerodis](#) /

› Zerodis USB Rechargeable Electric Shaker Bottle Model Ze89g7ztwohk-12 User Manual

Zerodis Ze89g7ztwohk-12

Zerodis USB Rechargeable Electric Shaker Bottle User Manual

Model: Ze89g7ztwohk-12

1. PRODUCT OVERVIEW

The Zerodis USB Rechargeable Electric Shaker Bottle is designed for efficient mixing of protein powders, coffee powders, and other beverages. It features a powerful motor for smooth blending and a detachable charging base for convenience.

Key Features:

- **Powerful Motor:** Equipped with a 6500 RPM motor to ensure uniform mixing and prevent lumps.
- **Detachable Charging Base:** Features a 700mAh lithium battery with a detachable base for easy USB charging.
- **Safe Materials:** Constructed from Tritan, PP, ABS, and silicone, ensuring no harmful substances, environmental friendliness, and lightweight design.
- **Large Capacity:** 800mL capacity allows for mixing protein powder, coffee powder, and water thoroughly, suitable for multiple servings.





Image 1: Front view of the Zerodis Electric Shaker Bottle, showing the pink lid, clear body with measurement markings, and the power button on the base.

2. SAFETY INFORMATION

- Do not immerse the motor base in water or other liquids.
- Keep out of reach of children.
- Ensure the lid is securely fastened before operating.

- Do not use with hot liquids above 60°C (140°F) as pressure buildup may cause the lid to open unexpectedly.
- Only use the provided USB cable for charging.
- Avoid disassembling the motor unit.
- This product is made from safe, non-toxic materials (Tritan, PP, ABS, Silicone).

3. COMPONENTS

The Zerodis Electric Shaker Bottle consists of the following main components:

1. Lid with flip-top cap
2. Shaker bottle body (clear with measurement markings)
3. Motor base with power button and charging port
4. USB charging cable (not explicitly mentioned but implied for "USB rechargeable")





Image 2: Close-up view of the shaker bottle's lid and upper body, highlighting the design.

4. SETUP

4.1 Initial Charge

Before first use, fully charge the shaker bottle. The motor base contains a 700mAh lithium battery.

- Gently twist to detach the motor base from the bottle body.
- Connect the USB charging cable to the charging port on the motor base and to a suitable USB power source.
- The indicator light on the base will show charging status (e.g., red for charging, blue/green for fully charged).
- Once fully charged, disconnect the cable.





Image 3: The shaker bottle with its detachable base, illustrating how it separates for charging or cleaning.

4.2 Assembly

After charging, reattach the motor base to the bottle body by aligning and twisting until secure.

5. OPERATING INSTRUCTIONS

1. **Add Liquid:** Pour the desired amount of liquid (e.g., water, milk) into the shaker bottle.
2. **Add Powder:** Add your protein powder, coffee powder, or other supplements.
3. **Secure Lid:** Ensure the lid is tightly closed and the flip-top cap is sealed.
4. **Activate Mixing:** Press the power button on the motor base to start the mixing process. The motor will operate at 6500 RPM for smooth blending.
5. **Mix Thoroughly:** Allow the bottle to mix until the powder is fully dissolved and no lumps remain. This typically takes a few seconds.
6. **Stop Mixing:** Press the power button again to stop the mixing.
7. **Enjoy:** Open the flip-top cap and enjoy your perfectly mixed beverage.





Image 4: Close-up of the motor base, highlighting the power button with its universal power symbol.

6. MAINTENANCE AND CLEANING

Regular cleaning ensures hygiene and extends the product's lifespan.

1. **Detach Base:** Gently twist to separate the motor base from the bottle body.
2. **Clean Bottle and Lid:** Wash the bottle body and lid with warm soapy water. A bottle brush may be used for thorough cleaning. Rinse thoroughly.
3. **Clean Motor Base:** Wipe the exterior of the motor base with a damp cloth. *Do not immerse the motor base in water.*
4. **Dry Components:** Allow all components to air dry completely before reassembling or storing.





Image 5: The shaker bottle disassembled into its main parts (lid, bottle, base) for easy cleaning.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Shaker does not turn on.	Battery is low or depleted.	Charge the motor base using the USB cable.

Problem	Possible Cause	Solution
Mixing is inefficient or lumpy.	Too much powder or insufficient liquid.	Reduce powder quantity or add more liquid. Ensure powder is added after liquid.
Lid leaks during mixing.	Lid not securely fastened or cap not sealed.	Ensure the lid is twisted on tightly and the flip-top cap is pressed down firmly.
Motor makes unusual noise.	Obstruction in the mixing area or motor malfunction.	Turn off immediately. Check for obstructions. If problem persists, contact customer support.

8. SPECIFICATIONS

Model Number	Ze89g7ztwohk-12
Brand	Zerodis
Material	Tritan, PP, ABS, Silicone
Capacity	800 mL
Motor Speed	6500 RPM
Battery	3.7V 700mAh Lithium Polymer (built-in)
Product Height	Approx. 255mm / 10 inches
Product Diameter	Approx. 130mm / 5.1 inches
Weight	Approx. 488g / 17.2 oz

9. WARRANTY AND SUPPORT

Specific warranty information is not provided in the product details. For warranty claims or technical support, please contact your retailer or the manufacturer directly. Please refer to the contact information provided with your purchase or visit the official Zerodis website.

For further assistance, you may visit the Zerodis store on Amazon:[Zerodis Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question