

Wooask M9

Wooask M9 Translation Earbuds User Manual

Model: M9

1. INTRODUCTION

The Wooask M9 Translation Earbuds are an advanced language translation device designed to facilitate seamless communication across language barriers. Featuring high accuracy and rapid translation, these open-ear earbuds support a wide range of languages and accents, making them ideal for travel, business, and multicultural interactions.

2. PRODUCT OVERVIEW

The Wooask M9 earbuds combine innovative design with powerful translation technology. Key features include:

- **High Accuracy Instant Translation:** 98% accuracy with 0.5-second response time across 144 languages and accents.
- **Premium Sound Quality:** Ensures clear and understandable audio for all conversations.
- **Versatile Translation Modes:** Five adaptable modes including Speaker, Free Talk, Touch, Offline, and Photo translation.
- **Extended Battery Life:** Up to 15 hours of usage with the charging case and 5 hours of continuous translation.
- **Innovative Open-Ear Design:** Comfortable hang-on-ear design for hygiene and security, minimizing fall risk.



Figure 2.1: Wooask M9 Translation Earbuds and Charging Case. The image displays the two open-ear earbuds and their compact charging

case, highlighting their design.

74 Language and 74 Accents

Hear the World, Speak with Ease!



98%
High Accuracy

1S
Rapid Translation

Figure 2.2: Wooask M9 Language and Accent Support. This image illustrates the global reach of the M9 earbuds, supporting 74 languages and 74 accents with 98% high accuracy and 1-second rapid translation, overlaid on a world map background.

3. SETUP

3.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. Connect the provided USB-C cable to the charging case and a power source. The indicator light on the case will show charging status.

EXTREMELY LONG BATTERY LIFE

 **9hrs**
Continuous translation

 **36hrs**
Battery life with charging case

 **90mins**
Fully charged over Type C port



Figure 3.1: Wooask M9 Earbuds Battery Life and Charging. This image highlights the extended battery life: 9 hours continuous translation, 36 hours battery life with charging case, and 90 minutes for a full charge via Type-C port.

3.2 Pairing with Your Device

1. Ensure the earbuds are charged and in the charging case.
2. Open the charging case. The earbuds will automatically enter pairing mode.
3. On your smartphone or tablet, go to Bluetooth settings and search for "Wooask M9".
4. Select "Wooask M9" to connect. A voice prompt will confirm successful pairing.

3.3 App Installation

To utilize all translation features, download the official Wooask app from your device's app store (iOS App Store or Google Play Store). Follow the in-app instructions to complete setup and language selection.

4. OPERATING MODES

The Wooask M9 offers several translation modes to suit different communication scenarios:

Fluent Translations Across Different Situations



Figure 4.1: Wooask M9 Translation Modes. This image visually represents the five fluent translation modes: Touch Mode, Free Talk Mode, Speaker Mode, and Photo Translation, illustrating their use in different situations.

4.1 Touch Mode

In Touch Mode, each earbud acts as a microphone. One person speaks into their earbud, and the translation is played through the other person's earbud. This mode is ideal for one-on-one conversations.

4.2 Free Talk Mode

Free Talk Mode allows for continuous, natural conversation. Both parties can speak freely, and the earbuds will automatically detect and translate speech in real-time. This mode is suitable for dynamic group discussions.

4.3 Speaker Mode

In Speaker Mode, one person speaks into an earbud, and the translation is broadcast through your smartphone's speaker. This is useful for addressing a small group or when you want others to hear the translation without needing their own

earbuds.

4.4 Offline Translation (If applicable to your model)

For models with offline package support, this mode allows translation without an internet connection. Ensure the necessary language packs are downloaded via the app beforehand. **Note: This specific product (B0DHZFLJDB) does not include an offline package.**

4.5 Photo Translation

Use the Wooask app to take a picture of text (e.g., signs, menus). The app will translate the text displayed in the image. This feature requires an internet connection.

5. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your Wooask M9 earbuds.

- **Cleaning:** Gently wipe the earbuds and charging case with a soft, dry, lint-free cloth. Do not use abrasive cleaners or immerse in water.
- **Storage:** Store the earbuds in their charging case when not in use to protect them and keep them charged.
- **Battery Care:** Avoid fully discharging the battery frequently. Charge regularly to maintain battery health.
- **Environmental Conditions:** Keep the device away from extreme temperatures, humidity, and direct sunlight.

Why Choose Open-ear Design?

Non in ear wearing

- Comfortable
- Snug fit
- More hygienic
- No fall easily



- Share earbuds and unhygienic
- Easy to fall off



Figure 5.1: Wooask M9 Open-Ear Design Benefits. This image highlights the advantages of the open-ear design, emphasizing comfort, snug fit, improved hygiene, and reduced risk of falling, contrasting it with traditional in-ear designs.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Earbuds not turning on	Low battery; Earbuds not properly seated in case	Charge the earbuds and case fully. Ensure earbuds are correctly placed in the charging case.
Cannot pair with device	Bluetooth off; Earbuds not in pairing mode; Interference	Ensure Bluetooth is enabled on your device. Open the charging case to enter pairing mode. Move closer to your device and away from other wireless devices.

Problem	Possible Cause	Solution
Translation accuracy is low	Poor internet connection; Background noise; Unclear speech	Ensure a stable internet connection. Speak clearly and reduce background noise. Update the Wooask app to the latest version.
No sound from earbuds	Volume too low; Earbuds not connected; App settings	Adjust volume on your device and in the app. Reconnect the earbuds. Check audio output settings in the Wooask app.

7. SPECIFICATIONS

- Brand:** Wooask
- Model:** M9
- Part Number:** WOOSK-M9
- Translation Accuracy:** Up to 98%
- Translation Speed:** Approximately 0.5 - 1 second
- Supported Languages:** 144+ languages and accents
- Battery Life (Earbuds):** Up to 5 hours continuous translation
- Battery Life (with Charging Case):** Up to 15 hours total usage
- Charging Port:** USB Type-C
- Battery Type:** Lithium Ion (3 required, included)
- Design:** Open-Ear, Hang-on-ear
- Dimensions (Parcel):** 17.4 x 12.29 x 4.39 cm
- Weight (Parcel):** 231 g

Cutting-Edge Technology for Precise Translation

Powered by a Quad-Core Processor



**High-Quality
Sound**

**Stable
Performance**

**Low Power
Consumption**

Figure 7.1: Wooask M9 Cutting-Edge Technology. This image illustrates the internal components of the earbud, highlighting its quad-core processor, Bluetooth 5.3, and emphasizing high-quality sound, stable performance, and low power consumption.

8. WARRANTY AND SUPPORT

Wooask products come with a standard manufacturer's warranty. For detailed warranty information, technical support, or service inquiries, please visit the official Wooask website or contact their customer service. Keep your purchase receipt for warranty claims.

Wooask Official Store: [Visit Wooask Store on Amazon](#)

© 2024 Wooask. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question