

Xtrike Me GM-217

Xtrike Me Wired Gaming Mouse GM-217 User Manual

Model: GM-217

1. PRODUCT OVERVIEW

The Xtrike Me GM-217 Wired Gaming Mouse is designed to enhance your gaming experience with its responsive optical sensor and customizable features. It features 7 different flowing light colors to create a vibrant gaming atmosphere. The 3D non-slip rubber material design ensures a reliable grip for both gaming and web browsing. Weighing approximately 68 grams, its slim and durable casing allows for flexible movement during intense gaming sessions.

Key features include:

- 7 different flowing mouse light colors for a vibrant gaming environment.
- 3D non-slip rubber material design for reliable grip during gaming and web browsing.
- Slim and durable structure for flexible movement in intense gaming.
- Optical sensor with 6 programmable buttons.
- Adjustable DPI settings: 1200-1800-2400-3600.
- Switch lifespan of 3 million clicks.
- 125 Hz polling rate.



Figure 1: Overall view of the Xtrike Me GM-217 Wired Gaming Mouse.

2. SETUP INSTRUCTIONS

The Xtrike Me GM-217 mouse is a plug-and-play device, requiring no additional drivers for basic functionality on supported operating systems.

1. Unpack the mouse from its packaging.
2. Locate an available USB 2.0 port on your computer (PC, laptop, or tablet).
3. Insert the USB connector of the mouse into the USB port.
4. Your operating system should automatically detect and install the necessary drivers. The mouse will be ready for use within a few seconds.



Figure 2: Front view of the mouse, highlighting the USB cable connection.

3. OPERATING YOUR MOUSE

The GM-217 mouse features 6 buttons and adjustable DPI settings for precise control.

Button Functions:

- **Left Click Button:** Standard primary action.
- **Right Click Button:** Standard secondary action (context menu).
- **Scroll Wheel:** Scrolls up and down. Can also be pressed for a middle-click function.
- **DPI Button:** Cycles through DPI settings (1200/1800/2400/3600).
- **Forward Button:** Navigates forward in web browsers or applications.
- **Backward Button:** Navigates backward in web browsers or applications.

DPI Adjustment:

Press the DPI button (usually located behind the scroll wheel) to cycle through the available DPI settings: 1200, 1800, 2400, and 3600 DPI. Each press will change the sensitivity, allowing you to adapt to different gaming or work scenarios.

LED Lighting:

The mouse features 7 different flowing LED light colors that automatically cycle, adding aesthetic appeal to your setup. There is no manual control for changing or turning off the LED colors; they operate automatically when the mouse is powered.



Figure 3: Top-down view illustrating the mouse buttons and scroll wheel.



Figure 4: Side view showing the conveniently placed thumb buttons.

4. CARE AND MAINTENANCE

To ensure the longevity and optimal performance of your Xstrike Me GM-217 mouse, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the mouse. For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Avoid using harsh chemicals or abrasive materials.
- **Sensor Care:** Keep the optical sensor on the underside of the mouse clean and free from dust or debris. Use a cotton swab or compressed air if necessary.
- **Cable Management:** Avoid sharp bends or excessive pulling on the USB cable to prevent damage.
- **Storage:** When not in use, store the mouse in a clean, dry environment away from extreme temperatures.

5. TROUBLESHOOTING

If you encounter issues with your Xtrike Me GM-217 mouse, refer to the following common troubleshooting steps:

- **Mouse Not Responding:**
 - Ensure the USB cable is securely plugged into a working USB port on your computer.
 - Try plugging the mouse into a different USB port.
 - Restart your computer.
- **Erratic Cursor Movement:**
 - Clean the optical sensor on the underside of the mouse.
 - Ensure you are using the mouse on a clean, non-reflective, and uniform surface. Mouse pads are recommended.
 - Check for any software conflicts or outdated drivers on your operating system.
- **Buttons Not Working:**
 - Verify that no debris is lodged under the buttons.
 - Test the mouse on another computer to rule out system-specific issues.
- **LED Lights Not On:**
 - Ensure the mouse is properly connected to a powered USB port.
 - The LED lights are automatic and should illuminate upon connection. If not, try a different USB port or computer.

6. TECHNICAL SPECIFICATIONS

Feature	Specification
Brand	Xtrike Me
Model Number	XT-GM-217
Color	Black
Connectivity Technology	USB 2.0 (Wired)
Movement Detection Technology	Optical
Number of Buttons	6
DPI Settings	1200 / 1800 / 2400 / 3600
Switch Rating	3 million clicks
Polling Rate	125 Hz
Backlight	7 flowing colors (automatic)
Operating Voltage	5V
Operating Current	50 mA

Feature	Specification
Cable Length	1.5 meters (approx. 5 ft)
Compatible Devices	PC, Tablet, Laptop
Operating Systems	Windows XP or newer
Material	Plastic, Rubber
Included Components	USB Cable
Batteries Required	No
Country of Origin	China

7. WARRANTY INFORMATION

This Xtrike Me GM-217 Wired Gaming Mouse is covered by the Xtrike Me Standard Warranty. Please refer to the warranty card included with your product or visit the official Xtrike Me website for detailed terms and conditions regarding warranty coverage, duration, and claims procedures.

8. CUSTOMER SUPPORT

For further assistance, technical support, or inquiries regarding your Xtrike Me GM-217 Wired Gaming Mouse, please contact your retailer or the manufacturer directly. Contact information can typically be found on the product packaging or the official Xtrike Me website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question