

- Manuals.plus /
- › WeurGhy /
- › WeurGhy Smart Watch Y6 User Manual

WeurGhy Y6

# WeurGhy Smart Watch Y6 User Manual

Model: Y6

## 1. INTRODUCTION

Thank you for choosing the WeurGhy Smart Watch Y6. This device is designed to enhance your daily life by providing convenient access to communication features, comprehensive fitness tracking, and health monitoring. This manual will guide you through the setup, operation, and maintenance of your new smartwatch.



**Image 1.1:** The WeurGhy Smart Watch Y6. The left display shows the time (09:30), date (MON MAY 30), battery level (50%), current weather (24°C), calories burned (410 KCAL), steps taken (8196), distance covered (0.25 KM), and heart rate (98 BPM). The right display shows a numeric dial pad for making calls.

## 2. WHAT'S IN THE BOX

Please check the package contents carefully. If any items are missing or damaged, contact customer support.

- WeurGhy Smart Watch Y6 Unit
- Magnetic Charging Cable
- User Manual

## 3. SETUP

### 3.1 Charging the Smart Watch

Before first use, fully charge your smartwatch.

1. Connect the magnetic charging cable to the charging contacts on the back of the watch.
2. Plug the USB end of the cable into a standard USB power adapter (5V/1A recommended) or a computer's USB port.
3. The watch screen will display a charging indicator. Allow approximately 2 hours for a full charge.

### 3.2 App Installation

To unlock the full functionality of your WeurGhy Smart Watch Y6, you need to install the companion application on your smartphone.

- Scan the QR code provided in the quick start guide (if available) or search for "WeurGhy Fit" (or similar app name) in your smartphone's app store (Google Play Store for Android, Apple App Store for iOS).
- Download and install the application.
- Follow the on-screen instructions to create an account and set up your profile.

### 3.3 Pairing with Your Smartphone

Ensure your smartphone's Bluetooth is enabled and the watch is sufficiently charged.

1. Open the "WeurGhy Fit" app on your smartphone.
2. Navigate to the "Device" or "My Watch" section within the app.
3. Tap "Add Device" or "Scan for Device".
4. Select "Y6" or the corresponding device name from the list of discovered Bluetooth devices.
5. Confirm the pairing request on both your smartphone and the smartwatch if prompted.
6. Once paired, the watch will synchronize data with the app.

## 4. OPERATING INSTRUCTIONS

### 4.1 Basic Navigation

- **Touch Screen:** Swipe left/right, up/down to navigate through menus and features. Tap to select.
- **Side Button:** Press to wake the screen, return to the watch face, or access the main menu. Long press for power options.

### 4.2 Bluetooth Call Function

After successful Bluetooth pairing, you can make and receive calls directly from your watch.

- **Making a Call:** Swipe to the call interface, tap the dial pad icon, enter the number, and tap the green call icon. You can also access your contacts or call history.
- **Receiving a Call:** When a call comes in, the watch will display the caller ID. Tap the green icon to answer or the red icon to reject.

### 4.3 Message Notifications

Enable app notifications in the "WeurGhy Fit" app to receive alerts on your watch.

- Swipe down from the watch face to view recent notifications.
- Tap on a notification to read the full message (if supported).

### 4.4 Health Monitoring

The WeurGhy Smart Watch Y6 tracks various health metrics.

- **Heart Rate:** Swipe to the heart rate interface and tap to start a measurement.
- **SpO2 (Blood Oxygen):** Swipe to the SpO2 interface and tap to measure.
- **Sleep Tracking:** Wear the watch to bed for automatic sleep monitoring. View data in the app.
- **Steps/Activity:** The watch automatically tracks steps, distance, and calories burned throughout the day.

*Note: This device is not a medical device. Health data is for reference only and should not be used for medical diagnosis or treatment.*

4.5 Sport Modes

The watch supports over 112 sport modes to track your workouts.

1. Swipe to the "Sport" or "Workout" menu.
2. Select your desired activity (e.g., running, cycling, walking).
3. Tap to start the activity. The watch will record duration, calories, heart rate, and other relevant metrics.
4. Swipe right or press the side button to pause or end the workout.

5. MAINTENANCE

- **Cleaning:** Regularly wipe the watch screen and strap with a soft, dry cloth. For stubborn dirt, use a slightly damp cloth and then dry thoroughly. Avoid harsh chemicals.
- **Battery Care:** Avoid extreme temperatures. Do not fully discharge the battery for extended periods. Charge the watch regularly, even if not in use, to maintain battery health.
- **Water Resistance:** The watch has a certain level of water resistance (check product specifications for details). Avoid prolonged immersion in water, hot water, or steam. Do not operate buttons underwater.

6. TROUBLESHOOTING

| Problem                      | Solution                                                                                                                                                                                                    |
|------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Watch does not turn on.      | Ensure the watch is fully charged. Connect it to the charger for at least 10 minutes.                                                                                                                       |
| Cannot pair with smartphone. | Ensure Bluetooth is enabled on your phone.<br>Make sure the watch is within range.<br>Restart both the watch and your phone.<br>Forget the device in your phone's Bluetooth settings and try pairing again. |
| No notifications received.   | Check if notifications are enabled in the "WeurGhy Fit" app.<br>Ensure the app has necessary permissions on your phone.<br>Verify the watch is properly connected via Bluetooth.                            |
| Inaccurate health data.      | Ensure the watch is worn snugly on your wrist, not too tight or too loose. Clean the sensor on the back of the watch.                                                                                       |

7. SPECIFICATIONS

| Feature | Detail |
|---------|--------|
|---------|--------|

| Feature                         | Detail                                                              |
|---------------------------------|---------------------------------------------------------------------|
| Model Name                      | Y6                                                                  |
| Brand                           | WeurGhy                                                             |
| Screen Size                     | 1.85 Inches                                                         |
| Standing Screen Display Size    | 1.85 Inches                                                         |
| Shape                           | Rectangular                                                         |
| Operating System                | Android/iOS compatible                                              |
| Special Feature                 | Activity Tracker (Heart Rate, Sleep, SpO2, Steps, 112+ Sport Modes) |
| Connectivity Technology         | Bluetooth                                                           |
| Wireless Communication Standard | Bluetooth                                                           |
| Battery Cell Composition        | Lithium Polymer                                                     |
| Batteries Required              | 1 AAAA battery (included)                                           |
| GPS                             | GPS Via Smartphone                                                  |
| Item Weight                     | 0.035 ounces                                                        |
| Package Dimensions              | 0.39 x 0.39 x 0.39 inches                                           |
| Manufacturer                    | WeurGhy                                                             |

## 8. SAFETY INFORMATION

- Do not attempt to disassemble or modify the watch.
- Keep the watch away from extreme temperatures, direct sunlight, and open flames.
- Avoid strong impacts or dropping the device.
- Keep out of reach of children.
- If you experience skin irritation, discontinue use and consult a doctor.
- Dispose of the device and its battery according to local regulations.

## 9. WARRANTY AND SUPPORT

The WeurGhy Smart Watch Y6 comes with a standard manufacturer's warranty. For specific warranty terms and conditions, please refer to the warranty card included in your package or contact WeurGhy customer support. For technical assistance, troubleshooting, or general inquiries, please visit the official WeurGhy website or contact their customer service team.

**ASK A QUESTION ABOUT THIS MANUAL**

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

Open the live page

<https://manuals.plus/asin/B0DPCF7Y32>

More documents and user manuals: <https://manuals.plus/>