

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [QueenFun](#) /

› QueenFun 60x30 Black Medicine Cabinet with Mirror User Manual

QueenFun 60x30 IN (Three-door)

QueenFun 60x30 Black Medicine Cabinet with Mirror User Manual

Model: 60x30 IN (Three-door) | Brand: QueenFun

1. INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your QueenFun 60x30 Black Medicine Cabinet with Mirror. Please read this manual thoroughly before installation and retain it for future reference. This cabinet is designed for both surface-mounted and recessed installations, offering versatile storage solutions for your bathroom.

2. SAFETY INFORMATION

- Always wear appropriate safety gear, including safety glasses, during installation.
- Ensure the mounting surface is structurally sound and capable of supporting the weight of the cabinet and its contents.
- If drilling into walls, verify the absence of electrical wires or plumbing pipes using a stud finder or other detection tools.
- Handle the mirror and glass shelves with care to prevent breakage and injury.
- Keep small parts and hardware out of reach of children.
- For recessed installation, ensure the wall cutout dimensions are accurate to prevent damage to the cabinet or wall.

3. PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- Pre-assembled Medicine Cabinet with Mirror (1 unit)
- Adjustable Tempered Glass Shelves (9 units)
- Mounting Hardware (screws, wall anchors, mounting brackets)
- Installation Guide (this document)

4. SETUP AND INSTALLATION

The QueenFun medicine cabinet is pre-assembled and can be installed as either surface-mounted or recessed. The door is reversible for left or right opening.

4.1. Installation Options

The cabinet supports two installation methods: surface mounting or recessed mounting. Choose the method that best suits your bathroom design and wall structure.



Figure 1: Flexible Installation Options - Recessed and Surface Mounting.

4.2. Surface Mount Installation

1. **Measure and Mark:** Determine the desired height and position for the cabinet. Use a level to mark the top and bottom mounting points on the wall.
2. **Install Mounting Bracket:** Secure the heavy-duty mounting bracket to the wall using the provided screws and wall anchors. Ensure it is level and firmly attached.
3. **Hang the Cabinet:** Carefully lift the cabinet and hook it onto the installed mounting bracket.
4. **Secure Bottom Reinforcement:** Install the bottom reinforced screw or bracket to prevent the cabinet from shifting.



Figure 2: Surface Mount Installation Steps.

4.3. Recessed Mount Installation

1. **Measure and Cutout:** Measure and reserve a space in the wall according to the precise cutout dimensions provided in the specifications table below. Make a precise wall cutout.

2. **Secure Cabinet:** Insert the cabinet into the wall cutout. Secure the cabinet to the wall from the inside with screws. For brick walls, pre-install wall anchors (included).
3. **Place Shelves:** Once the cabinet is secured, place the glass shelves onto the support clips inside the cabinet.



Figure 3: Recessed Mount Installation Steps.

Recessed Cutout Dimension Reference

Size Name	Width (inch)	Height (inch)	Depth (inch)
16x24"	15.375	23.5	4.5
16x26"	15.375	25.375	4.5
20x26"	19.5	25.375	4.5
24x30"	23.5	29.375	4.5
30x26"	29.375	25.375	4.5
40x30"	39.125	29.375	4.5
48x30"	47	29.375	4.5
60x30"	58.875	29.375	4.5
72x30"	70.625	29.375	4.5



Figure 4: Recessed Cutout Measurement Guide.

4.4. Reversible Door Installation

The cabinet features a reversible door, allowing for left or right opening. This flexibility is determined during installation by the orientation of the cabinet. No additional steps are required beyond choosing the desired orientation before mounting.

180° REVERSIBLE INSTALLATION



Figure 5: Reversible Door Installation.

4.5. Adjustable Shelves Installation

The tempered thickened glass shelves are height-adjustable. Locate the small brackets inside the cabinet. Position the shelves at your desired height by inserting the shelf pins into the corresponding holes.



Figure 6: Adjustable Glass Shelves and Soft-Close Hinges.

4.6. Installation Videos

Recessed/Surface Mirrored Cabinet - Installation Guide

Your browser does not support the video tag.

This video provides a comprehensive guide for installing the QueenFun mirrored medicine cabinet, covering both recessed and surface mounting methods.

QueenFun Pre-assembled Bevel Framed Medicine Cabinet Mirror

Your browser does not support the video tag.

This video showcases the pre-assembled QueenFun bevel framed medicine cabinet mirror, highlighting its features and ease of installation.

QueenFun Beveled Black Framed Mirrored

Medicine Cabinet

Your browser does not support the video tag.

A detailed video presenting the QueenFun beveled black framed mirrored medicine cabinet, demonstrating its design and functionality.

5. OPERATING INSTRUCTIONS

- **Opening/Closing Doors:** Gently pull the door handle to open. The soft-close DTC hinges ensure a quiet and smooth closing action, preventing slamming.
- **Adjusting Shelves:** To adjust the height of the glass shelves, carefully remove the shelf pins from their current position. Reposition the pins into the desired holes and place the glass shelf securely on top.

6. MAINTENANCE

- **Cleaning the Mirror:** Use a soft, lint-free cloth and a non-abrasive glass cleaner to wipe the mirror surface. Avoid harsh chemicals that may damage the mirror's eco-friendly coating.
- **Cleaning the Cabinet:** Wipe the aluminum cabinet body and shelves with a damp cloth and mild soap. Dry thoroughly to prevent water spots. The aluminum construction is rust-proof and water-resistant.
- **Hinge Care:** Periodically check the soft-close hinges for smooth operation. If needed, gently wipe away any dust or debris.

7. TROUBLESHOOTING

- **Door Not Closing Smoothly:** Check the soft-close hinges for any obstructions. Ensure the cabinet is level and securely mounted. Hinge adjustments can be made if necessary (refer to hinge manufacturer's instructions if specific to the hinge model).
- **Mirror Distortion:** The mirror is designed for 100% HD reflection. If distortion occurs, ensure the mirror surface is clean and free from smudges or residue.
- **Cabinet Feels Loose:** Re-check all mounting screws and brackets to ensure they are tightened securely. For recessed installations, verify the internal screws are firm.

8. SPECIFICATIONS

Feature	Description
Brand	QueenFun
Model	60x30 IN (Three-door)
Color	Black
Product Dimensions	5.39"D x 59.45"W x 29.92"H
Mounting Type	Recessed/Wall Mounted
Material	Aluminum
Special Features	Adjustable Shelf, Moisture Resistant, Removable Shelf, Rust Resistant, Shatterproof
Number of Shelves	9
Assembly Required	No (Pre-assembled)
Mirror Type	HD Eco-Friendly Mirror with Anti-Explosion Film
Hinges	Soft-close DTC Hinges

Overall Cabine Dimensions(with Mirror Frame) $\approx 60'' \times 30'' \times 5.39''$



Figure 7: Overall Cabinet Dimensions.

9. WARRANTY AND SUPPORT

QueenFun provides 24/7 customer support. If you encounter any issues with your medicine cabinet, please contact us directly for assistance. We are committed to ensuring your satisfaction with our products.