

HUDORA 205

HUDORA Big Wheel Scooter 205 Instruction Manual

Model: 205 | Brand: HUDORA

1. INTRODUCTION

This manual provides essential information for the safe assembly, operation, and maintenance of your HUDORA Big Wheel Scooter 205. Please read all instructions carefully before first use to ensure proper function and safety.

2. SAFETY INFORMATION

Always wear appropriate safety gear, including a helmet, knee pads, and elbow pads. Ensure all locking mechanisms are securely fastened before riding. Do not ride in traffic or on uneven surfaces. Adult supervision is recommended for younger riders. The scooter is designed for individuals up to 220 pounds.

3. PACKAGE CONTENTS

Your HUDORA Big Wheel Scooter 205 package should contain the following items:

- HUDORA Big Wheel Scooter 205 (partially assembled)
- Instruction Manual
- Carry Strap
- Necessary tools for final assembly (if any, usually included or integrated)

4. SETUP AND ASSEMBLY

The HUDORA Big Wheel Scooter 205 comes largely pre-assembled. Follow these steps to prepare your scooter for use:

1. **Unpacking:** Carefully remove the scooter from its packaging. Remove all protective cardboard and plastic wrapping.
2. **Unfolding the Scooter:** Locate the folding mechanism near the base of the handlebar stem. Release the latch and unfold the scooter until it locks securely into the upright position. Ensure the mechanism is fully engaged and stable.

3. **Attaching Handlebars:** The handlebars are typically folded down or detached for shipping. Insert the handlebar grips into the T-bar until they click into place. Ensure they are firmly seated and do not wobble.
4. **Adjusting Handlebar Height:** Loosen the quick-release clamp on the handlebar stem. Press the button on the stem and slide the handlebar to your desired height. Ensure the button snaps into one of the adjustment holes for secure locking. Tighten the quick-release clamp firmly.
5. **Attaching Carry Strap:** If not already attached, secure the carry strap to the designated points on the scooter frame.



Image: The HUDORA Big Wheel Scooter 205 in its fully assembled, upright position.

Assembly Video Guides:

Your browser does not support the video tag.

Video: Detailed instructions on how to assemble the HUDORA 205 scooter, including unfolding and handlebar setup.

Your browser does not support the video tag.

Video: A guide on setting up HUDORA scooters, demonstrating key assembly steps.

5. OPERATING INSTRUCTIONS

To operate your HUDORA Big Wheel Scooter 205 safely and effectively, follow these guidelines:

1. **Riding Position:** Place one foot firmly on the deck of the scooter. Use your other foot to push off the ground to gain momentum. Maintain a balanced stance with both hands on the handlebars.
2. **Steering:** Steer by gently leaning in the desired direction and turning the handlebars. Avoid sudden sharp turns at high speeds.
3. **Braking:** The scooter features a rear foot brake. To slow down or stop, gently press your heel down on the rear fender above the back wheel. Apply pressure gradually to avoid sudden stops.
4. **Folding for Transport/Storage:** To fold the scooter, release the quick-release clamp on the handlebar stem and lower the handlebars to their lowest position. Then, activate the main folding mechanism near the deck to collapse the scooter. Secure any latches to keep it folded.

BigWheel® 205, gris/vert



Image: A rider demonstrating the use of the HUDORA Big Wheel Scooter 205.

Operation Video Guides:

Your browser does not support the video tag.

Video: Demonstrates the HUDORA scooter in use by teens and adults, highlighting its large wheels for smooth riding.

Your browser does not support the video tag.

Video: Showcases various HUDORA scooters, including the Big Wheel 205, in action.

Your browser does not support the video tag.

Video: Highlights the features and popularity of HUDORA scooters, including the Big Wheel 205.

Your browser does not support the video tag.

Video: Features the HUDORA scooter being used by adults, teens, and kids, emphasizing its versatility.

6. MAINTENANCE

- **Cleaning:** Wipe down the scooter with a damp cloth after use to remove dirt and debris. Avoid using harsh chemicals that could damage the finish.

- **Wheel Inspection:** Regularly check the wheels for wear and tear. Ensure they spin freely and are securely attached.
- **Brake Check:** Verify that the rear foot brake is functioning correctly before each ride.
- **Fastener Check:** Periodically inspect all screws, bolts, and clamps to ensure they are tight. Tighten any loose fasteners.
- **Storage:** Store the scooter in a dry, protected area away from direct sunlight and extreme temperatures.

7. TROUBLESHOOTING

- **Scooter feels unstable:** Ensure all handlebar and folding mechanisms are securely locked. Check that the handlebars are adjusted to an appropriate height for the rider.
- **Wheels not spinning freely:** Inspect wheels for debris or damage. Clean any obstructions. If wheels are worn, consider replacement.
- **Brake not effective:** Check the rear fender for any damage or misalignment. Ensure sufficient pressure is applied when braking.
- **Unusual noises:** Inspect all moving parts for loose components. Tighten any bolts or screws that may have come loose.

8. SPECIFICATIONS

Feature	Detail
Brand	HUDORA
Model Name	205
Color	Green
Age Range (Description)	Adult
Weight Limit	220 Pounds
Number of Wheels	2
Wheel Material	Polyurethane
Frame Material	Aluminum
Item Weight	4.17 Kilograms
Handlebar Type	Adjustable
Handle Height	41 Inches (Maximum)
Wheel Size	8 Inches
Suspension Type	Dual Suspension
Brake Style	Rear Braking
Special Feature	Adjustable Handlebar Height, Foldable, Non-Slip Deck

9. WARRANTY AND SUPPORT

The HUDORA Big Wheel Scooter 205 comes with a **1-year limited warranty**. For any suggestions or assistance, please contact HUDORA customer support. They aim to respond within 12 hours to ensure your satisfaction.

Additional protection plans are available for purchase, including a 2-Year Protection Plan and a Complete Protect plan.

© 2023 HUDORA. All rights reserved.