

Ejoyous Ejoyouss1u2g07kz4-11

Ejoyous Bone Conduction Bluetooth Pillow Speaker User Manual

Model: Ejoyouss1u2g07kz4-11

1. INTRODUCTION

Thank you for choosing the Ejoyous Bone Conduction Bluetooth Pillow Speaker. This device is designed to provide a unique and comfortable audio experience, transmitting sound directly through your pillow to help you achieve deep and restful sleep without disturbing others. Please read this manual carefully to ensure proper use and optimal performance.



Figure 1: Ejoyous Bone Conduction Bluetooth Pillow Speaker (White)

2. WHAT'S IN THE BOX

- 1 x Bluetooth Pillow Speaker
- 1 x Wrist Lanyard
- 1 x Charging Cable (Type-C)



Figure 2: Included items: Pillow Speaker, Wrist Lanyard, and Charging Cable.

3. PRODUCT FEATURES

- **Bone Conduction Technology:** Transmits sound directly through your pillow, allowing you to enjoy audio

privately without disturbing others.

- **Dual Mode Connectivity:** Supports both Bluetooth 5.3 for wireless streaming from your smartphone or tablet, and MP3 mode via a Micro-SD card (up to 32GB, not included).
- **Integrated Timer Function:** Set the device to automatically turn off after 30, 60, or 90 minutes, promoting uninterrupted sleep and saving power.
- **Long-lasting Battery:** Enjoy approximately 20 hours of playback in sleep mode on a single charge, with a full charge taking only about 2 hours.
- **Compact and Portable Design:** Lightweight and slim, making it easy to place under your pillow or carry for travel.



Figure 3: The pillow speaker is designed to be placed under your pillow for private listening.

4. GETTING STARTED

4.1. Charging the Device

Before first use, fully charge the pillow speaker. Connect the provided Type-C charging cable to the speaker's charging port and the other end to a 5V/500mA USB power adapter (not included).

- A full charge takes approximately 2 hours.
- The indicator light will show charging status (e.g., red for charging, off when fully charged).

4.2. Power On/Off

- **To Power On:** Press and hold the power button for 3 seconds.
- **To Power Off:** Press and hold the power button for 3 seconds.

5. OPERATING INSTRUCTIONS

5.1. Switching Modes (Bluetooth / MP3)

The speaker supports both Bluetooth and MP3 playback. After powering on, you can switch between modes:

- **To switch to Bluetooth Mode:** Double-click the power button. The device will enter pairing mode.
- **To switch to MP3 Mode:** Double-click the power button again. Ensure a Micro-SD card with audio files is inserted.

5.2. Bluetooth Mode Operation

1. Turn on the pillow speaker and switch to Bluetooth mode (indicator light will flash).
2. Enable Bluetooth on your smartphone, tablet, or other compatible device.
3. Search for "Ejoyous Speaker" (or similar name) in your device's Bluetooth settings and select it to pair.
4. Once paired, the indicator light will become solid, and you can play audio from your device.

10m/32.8ft wireless distance, strong signal acceptance

wireless 5.3 chip, fast connection, strong signal, high speed transmission without delay



Figure 4: Connect wirelessly via Bluetooth 5.3 for a stable connection up to 10 meters.

5.3. MP3 Mode Operation

1. Insert a Micro-SD card (up to 32GB, not included) loaded with MP3, WMA, AAC, APE, or FLAC audio files into the designated slot.

2. Turn on the pillow speaker and switch to MP3 mode. The device will automatically start playing audio from the Micro-SD card.

5.4. Timer Function

To set the automatic shutdown timer:

- Double-click the volume button (or a dedicated timer button if present) to cycle through the timer options: 30 minutes, 60 minutes, or 90 minutes.
- The device will automatically power off after the selected duration.

5.5. Volume Control

You can adjust the volume directly on the pillow speaker or through your connected device (in Bluetooth mode).

- Use the volume up (+) and volume down (-) buttons on the speaker to adjust the volume.
- For optimal sound quality and to prevent sound leakage, it is recommended to keep the volume levels low on both the speaker and your connected device.

6. SPECIFICATIONS

Feature	Detail
Item Type	Bluetooth Pillow Speaker
Material	ABS
Dimensions	Approx. 132 x 52 x 10 mm / 5.20 x 2.05 x 0.39 inches
Bluetooth Version	5.3
Connection Distance	10 m / 32.8 ft
Playback Time	Approx. 20 hours (sleep mode)
Battery Capacity	500 mAh
Charging Time	Approx. 2 hours
Charging Voltage	5 V, 500 mA
Standby Time	30 days
Max. Micro-SD Card Support	32 GB (not included)
Supported Audio Formats	MP3, WMA, AAC, APE, FLAC
Scheduled Downtime Options	30 minutes, 60 minutes, 90 minutes
Interface	Type-C Charging Port
Control Method	Touch
Audio Output Mode	Stereo
Recommended Use	For sleeping, travel

7. MAINTENANCE

- Keep the device dry and clean. Avoid exposure to moisture or extreme temperatures.
- Clean the surface with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Store the speaker in a cool, dry place when not in use for extended periods.

8. TROUBLESHOOTING

8.1. No Sound / Low Sound

- Ensure the device is powered on and fully charged.
- Check the volume levels on both the pillow speaker and your connected audio source.
- Verify that the speaker is correctly positioned under your pillow. For best results, place it directly under your head.
- If using Bluetooth, ensure the device is properly paired and within the 10m range.
- If using MP3 mode, ensure the Micro-SD card is inserted correctly and contains supported audio files.

8.2. Bluetooth Pairing Issues

- Make sure the pillow speaker is in Bluetooth pairing mode (indicator light flashing).
- Turn off and on Bluetooth on your audio source device.
- Forget the device from your audio source's Bluetooth list and try pairing again.
- Ensure no other Bluetooth devices are interfering with the connection.

8.3. Device Not Turning On

- Ensure the device is fully charged. Connect it to a power source and wait a few minutes before attempting to power on again.
- Press and hold the power button for the required 3 seconds.

9. OFFICIAL PRODUCT VIDEOS

Pillow Speaker Mini Overview

Your browser does not support the video tag.

This video provides a brief overview of a mini pillow speaker, demonstrating its compact size and basic functionality. It highlights how the speaker can be used for personal audio without disturbing others.

Bluetooth Pillow Speaker Demonstration

Your browser does not support the video tag.

Watch this video for a demonstration of the Bluetooth pillow speaker, showcasing its connectivity features and how it delivers sound for a private listening experience.

10. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official Ejoyous website. If you encounter any issues not covered in this manual, please contact Ejoyous customer service for assistance.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question