



[Manuals.plus](#) /

› [COMHOMA](#) /

› COMHOMA Big and Tall Office Chair CH533 - Instruction Manual

COMHOMA CH533

COMHOMA Big and Tall Office Chair

Model: CH533

1. INTRODUCTION

Thank you for choosing the COMHOMA Big and Tall Office Chair. This manual provides detailed instructions for the proper assembly, safe operation, and effective maintenance of your new chair. Please read this manual thoroughly before assembly and use to ensure optimal performance and longevity of your product.

This chair is engineered for comfort and durability, supporting individuals up to 650 lbs with its robust design and ergonomic features.



Image 1.1: The COMHOMA Big and Tall Office Chair, showcasing its robust design and charcoal black finish.

2. SAFETY INFORMATION

Please adhere to the following safety guidelines to prevent injury and ensure the safe operation of your chair:

- **Maximum Weight Capacity:** Do not exceed the maximum weight capacity of 650 pounds (295 kg). Exceeding this limit may compromise the chair's stability and lead to injury.
- **Assembly:** Always follow the assembly instructions precisely. Ensure all screws and bolts are securely tightened before use.
- **Adjustments:** Use adjustable parts with care. Avoid sudden movements when adjusting the chair's height or recline.
- **Stability:** Do not stand on the chair. Avoid leaning excessively to one side, especially when the chair is reclined, to prevent tipping.
- **Children and Pets:** Keep children and pets away from the chair during assembly and operation to prevent accidents.
- **Maintenance:** Regularly inspect the chair for loose parts or damage. Do not use the chair if any components are damaged or missing.

3. PACKAGE CONTENTS

Before beginning assembly, please verify that all components are present and undamaged. The package should include:

- Backrest
- Seat Cushion
- Armrests (2)
- Gas Lift Cylinder
- Star Base
- Casters (5)
- Mechanism Plate
- Hardware Kit (screws, washers, Allen wrench)
- Instruction Manual

4. ASSEMBLY INSTRUCTIONS

Assembly can typically be completed by one person in approximately 30 minutes. An illustrated manual and all necessary tools are included in the package.

1. **Attach Casters to Base:** Insert the five casters into the holes at the end of each leg of the star base. Push firmly until they click into place.
2. **Insert Gas Lift:** Place the gas lift cylinder into the center hole of the star base.
3. **Attach Mechanism Plate to Seat:** Align the mechanism plate with the pre-drilled holes on the underside of the seat cushion. Secure it using the provided screws and Allen wrench. Ensure the front of the mechanism faces the front of the seat.
4. **Attach Armrests to Seat:** Secure the armrests to the sides of the seat cushion using the designated screws. Do not fully tighten yet.
5. **Attach Backrest to Seat and Armrests:** Align the backrest with the mounting points on the seat and armrests. Secure with screws. Once all screws are in place, fully tighten all armrest and backrest screws.
6. **Connect Seat Assembly to Gas Lift:** Carefully place the assembled seat and backrest onto the gas lift cylinder, ensuring the tapered end of the gas lift fits securely into the mechanism plate.



Image 4.1: Components for the chair base, including the one-piece all-metal base, removable wheels, and SGS Class-4 adjustable gaslift.

5. OPERATING INSTRUCTIONS

5.1 Adjusting Seat Height

To adjust the seat height, locate the lever on the right side, beneath the seat. While seated, pull the lever upwards to lower the seat. To raise the seat, stand up slightly to relieve weight from the seat, then pull the lever upwards. Release the lever at your desired height.

5.2 Adjusting Headrest

The headrest features a 6-position adjustment. To raise it, simply lift the headrest until you hear a click at your

preferred height. To lower it, pull the headrest upward to its highest setting, then release it, and it will automatically return to the lowest position.

5.3 Rocking Function

To activate the rocking function, pull the handle on the left side, beneath the seat, outwards. To lock the chair in an upright position, push the handle inwards. The tilt tension knob, located at the front of the mechanism plate, allows you to adjust the resistance of the rocking motion. Turn clockwise to increase tension (stiffer rock) and counter-clockwise to decrease tension (looser rock).

Image 5.1: The ergonomic chair features a 40-degree rocking function for relaxation.

6. KEY FEATURES

6.1 Big and Tall Design

This chair is specifically designed for big and tall individuals, supporting up to 650 lbs. It features a 7.09-inch thick seat cushion for maximum comfort and a large 27.55-inch five-star base for enhanced stability, preventing tipping.



Image 6.1: Detailed dimensions illustrating the large size and capacity of the office chair.

6.2 Breathable Backrest

The chair incorporates a mesh layer design along the backrest and seat cushion. This promotes airflow, helping to keep you cool and dry, and preventing discomfort from a "sweaty back" during long periods of sitting.



Image 6.2: The airy mesh design helps prevent a sweaty back by promoting air circulation.

6.3 Comfort and Quality Materials

The chair is constructed with high-quality materials for superior comfort and durability. It features a wide and thick seat (22.83 inches wide), a four-layer headrest, triple-padded side wings for support, and three-layer cushions. The materials include skin-friendly leather, high-rebound sponge, and premium wood, ensuring a comfortable and supportive seating experience.

Image 6.3: Illustration of the high-quality materials, including skin-friendly leather, high-rebound sponge, and premium wood.

7. MAINTENANCE AND CARE

To maintain the appearance and functionality of your COMHOMA office chair, follow these care instructions:

- **Cleaning:** Wipe clean with a damp cloth. For tougher stains, use a mild soap solution and wipe dry immediately. Avoid harsh chemicals or abrasive cleaners.
- **Regular Inspection:** Periodically check all screws and bolts to ensure they are tight. Re-tighten if necessary to maintain stability and safety.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause the leather material to fade or crack.
- **Weight Distribution:** Distribute your weight evenly on the chair to prevent undue stress on specific components.

8. TROUBLESHOOTING

If you encounter any issues with your COMHOMA office chair, refer to the following common troubleshooting tips:

Problem	Possible Cause	Solution
Chair does not raise or lower	Gas lift malfunction or lever not engaged.	Ensure the lever is fully pulled. If the issue persists, the gas lift may need replacement. Contact customer support.
Chair is wobbly or unstable	Loose screws or uneven floor.	Check and tighten all assembly screws. Ensure the chair is on a flat, even surface.
Squeaking noises	Loose connections or friction between parts.	Tighten all screws. Apply a small amount of silicone lubricant to moving parts or connection points if necessary.
Casters not rolling smoothly	Debris in casters or damaged casters.	Clean any hair or debris from the caster wheels. If damaged, casters are removable and can be replaced.

If you experience an issue not listed here or if the suggested solutions do not resolve the problem, please contact COMHOMA customer support for assistance.

9. SPECIFICATIONS

Feature	Detail
Brand	COMHOMA
Model Name	CH533
Color	Charcoal Black
Product Dimensions	27.55"D x 23.62"W x 40"H
Maximum Weight Recommendation	650 Pounds (295 kg)

Feature	Detail
Item Weight	40 pounds (18.1 kg)
Seat Depth	20.87 inches
Headrest Adjustment	6-position, max 3.5 inches
Seat Height Adjustment	3.93 inches
Reclining Position Count	3 (90-130 degrees)
Furniture Finish	Leather
Fill Material	Foam
Special Features	Adjustable Headrest, Head Support, Arm Rest, Big and Tall, High Back, Ergonomic, Heavy Duty, Swivel, Rocking

10. WARRANTY AND SUPPORT

COMHOMA offers the following support for your product:

- **30-Day Replacement Service:** If you encounter any issues within 30 days of purchase, a replacement service is available.
- **1-Year Warranty on Parts:** The chair comes with a 1-year warranty covering parts.
- **Customer Support:** Our 24/7 customer support team is available to assist you with any questions or concerns.
- **Returns:** The product is eligible for 30-day free returns, refund/replacement.

For warranty claims or technical assistance, please contact COMHOMA customer support through the retailer's platform or the official COMHOMA website.