

Armitron Eclipse

Armitron Eclipse Smartwatch User Manual

[Introduction](#) [Package](#)

[Contents](#)

[Setup](#)

[Operating](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty & Support](#)

1. INTRODUCTION

This manual provides essential instructions for setting up, operating, and maintaining your Armitron Eclipse Smartwatch. Please read this guide thoroughly to ensure proper use and to maximize the features of your device. The Armitron Eclipse Smartwatch is designed to combine style with functionality, offering comprehensive health and fitness tracking, communication features, and smart notifications.

2. PACKAGE CONTENTS

Verify that all items are present in your package:

- Armitron Eclipse Smartwatch
- Magnetic Rapid Charger
- Quick-Release Silicone Band (pre-attached or separate)
- User Manual (this document)

Image: A visual representation of all items included in the Armitron Eclipse Smartwatch package, neatly arranged.

3. SETUP

3.1. Charging the Smartwatch

Before initial use, fully charge your Armitron Eclipse Smartwatch.

1. Connect the magnetic rapid charger to a USB power source (e.g., computer USB port, USB wall adapter).
2. Align the magnetic pins of the charger with the charging contacts on the back of the smartwatch. The charger will snap into place.

3. The smartwatch display will indicate charging status. Allow approximately 2-3 hours for a full charge.

Image: Close-up view of the Armitron Eclipse Smartwatch connected to its magnetic rapid charger, showing the charging pins aligned.

3.2. Installing the Armitron Connect App

The Armitron Connect App is required to unlock the full functionality of your smartwatch.

1. Scan the QR code provided in the packaging or search for "Armitron Connect" in your smartphone's app store (Apple App Store for iOS, Google Play Store for Android).
2. Download and install the app.
3. Ensure your smartphone meets the compatibility requirements: Android 5.0+ or iOS 9.0+.

3.3. Pairing with Your Smartphone

Follow these steps to pair your smartwatch with the Armitron Connect App:

1. Enable Bluetooth on your smartphone.
2. Open the Armitron Connect App and follow the on-screen instructions to create an account or log in.
3. In the app, navigate to the device pairing section (usually indicated by a '+' icon or "Add Device").
4. Select your Armitron Eclipse Smartwatch from the list of available devices. A pairing request may appear on both your phone and smartwatch. Confirm the pairing.
5. Once paired, the app will synchronize data with your smartwatch.

Image: Screenshot of the Armitron Connect App interface showing the device pairing screen with the Eclipse Smartwatch listed.

4. OPERATING THE SMARTWATCH

4.1. Basic Navigation

The Armitron Eclipse Smartwatch features a full touchscreen display for intuitive navigation.

- **Swipe Up/Down:** Scroll through menus, notifications, or widgets.
- **Swipe Left/Right:** Access quick functions, different watch faces, or health summaries.
- **Tap:** Select an item or open an application.
- **Press Side Button:** Typically returns to the home screen or activates a specific function (configurable in settings).

Image: Diagram illustrating common swipe gestures on the Armitron Eclipse Smartwatch screen.

4.2. Call Functionality

Once paired, you can make and receive calls directly from your smartwatch.

- **Making Calls:** Access the dialer or contact list on your smartwatch. Tap to initiate a call.
- **Receiving Calls:** When a call comes in, the smartwatch will display the caller ID. Tap the green icon to answer or the red icon to decline.

4.3. Fitness Tracking

The smartwatch monitors various fitness metrics:

- **Step Counting:** Tracks your daily steps.

- **Calorie Tracking:** Estimates calories burned based on activity.
- **Heart Rate Monitoring:** Provides real-time heart rate data.
- **Sports Modes:** Select specific modes for activities like running, walking, cycling, etc., for more accurate tracking.

Image: Screenshot of the Armitron Eclipse Smartwatch display showing the heart rate monitoring interface.

4.4. Health Monitoring

Beyond fitness, the smartwatch offers health insights:

- **Sleep Tracking:** Monitors sleep patterns and quality.
- **Women's Health Tracking:** Provides features for menstrual cycle tracking (requires setup in the app).
- **Sedentary Reminders:** Alerts you to move after periods of inactivity.
- **Breathing Exercises:** Guided breathing sessions for relaxation.

4.5. Notifications

Receive notifications from your smartphone directly on your smartwatch.

- Ensure notification permissions are enabled in both your smartphone settings and the Armitron Connect App.
- Swipe down from the top of the watch face to view recent notifications.

5. MAINTENANCE

5.1. Cleaning

To keep your smartwatch in optimal condition:

- Wipe the screen and band regularly with a soft, damp, lint-free cloth.
- Avoid using harsh chemicals, abrasive cleaners, or solvents.
- Ensure the charging contacts are clean and dry before charging.

5.2. Water Resistance

The Armitron Eclipse Smartwatch is water resistant up to 1.5 meters for 30 minutes.

- It is suitable for everyday use, such as washing hands or light rain.
- *Do not* use for swimming, diving, or exposure to high-velocity water.
- *Do not* expose to hot water, steam, or saunas, as this may compromise the water resistance.
- If the smartwatch gets wet, dry it thoroughly before charging.

6. TROUBLESHOOTING

If you encounter issues with your Armitron Eclipse Smartwatch, refer to the following common solutions:

Problem	Solution
Smartwatch not turning on	Ensure the device is fully charged. Connect to the magnetic charger and check for charging indication.

Problem	Solution
Unable to pair with smartphone	<ol style="list-style-type: none"> 1. Ensure Bluetooth is enabled on your phone. 2. Make sure the smartwatch is within range. 3. Restart both the smartwatch and your phone. 4. Clear previous pairings in your phone's Bluetooth settings and try again.
Notifications not appearing	<ol style="list-style-type: none"> 1. Check notification permissions in your phone's settings for the Armitron Connect App. 2. Ensure notifications are enabled within the Armitron Connect App itself. 3. Verify the smartwatch is properly paired and connected.
Inaccurate health/fitness data	<ol style="list-style-type: none"> 1. Ensure the smartwatch is worn snugly on your wrist, but not too tight. 2. Keep the sensor area clean. 3. Calibrate settings within the Armitron Connect App if available.
Charging issues	<ol style="list-style-type: none"> 1. Ensure the magnetic charger is correctly aligned with the smartwatch contacts. 2. Try a different USB power source or cable. 3. Clean the charging contacts on both the watch and charger.

If the problem persists, please contact Armitron customer support.

7. SPECIFICATIONS

- **Case Size:** 45mm ABS case
- **Display:** TFT 1.83" 240*280 LCD display
- **Band:** Silicone band with quick-release technology
- **Charger:** Magnetic rapid charger
- **Water Resistance:** Up to 1.5 meters for 30 minutes
- **App Compatibility:** Free Armitron Connect App (Android 5.0+ and iOS 9.0+)
- **Connectivity:** Bluetooth
- **GTIN:** 086702741885
- **ASIN:** B0DWKQZFSN

8. WARRANTY AND SUPPORT

Your Armitron Eclipse Smartwatch comes with a limited warranty. For detailed warranty information, please refer to the warranty card included in your package or visit the official Armitron website. For technical support, troubleshooting assistance, or warranty claims, please contact Armitron customer service through their official website or the contact information provided in the Armitron Connect App.

Armitron Official Website: www.armitron.com