



[Manuals.plus](#) /

› [Evenflo](#) /

› Evenflo Revolve180 LiteMax NXT Accessory Base Instruction Manual

Evenflo CS900610000C

Evenflo Revolve180 LiteMax NXT Accessory Base Instruction Manual

Model: CS900610000C

1. INTRODUCTION

This manual provides essential instructions for the safe and proper installation, operation, and maintenance of your Evenflo Revolve180 LiteMax NXT Accessory Base. This accessory base is designed exclusively for use with the Evenflo Revolve180 LiteMax NXT Rotational Infant Car Seat and LiteMax NXT Infant Car Seat. Please read all instructions carefully before use and retain this manual for future reference.

2. SAFETY INFORMATION

Your child's safety is paramount. Always follow these safety guidelines:

- **Read All Instructions:** Before installing or using the accessory base, thoroughly read this manual and the instruction manual for your compatible Evenflo infant car seat.
- **Vehicle Compatibility:** Always refer to your vehicle owner's manual for specific car seat installation instructions and restrictions.
- **Proper Installation:** Ensure the base is installed correctly and securely in your vehicle. The LockStrong™ belt tensioning system and installation indicators are designed to assist with proper installation.
- **Child Weight Limits:** This base is designed for children weighing between 3 pounds (minimum) and 30 pounds (maximum) in a rear-facing orientation.
- **Rear-Facing Only:** This accessory base is for rear-facing use only.
- **Damage Inspection:** Regularly inspect the base for any signs of damage, wear, or missing parts. Do not use if damaged.
- **Never Leave Unattended:** Never leave a child unattended in the car seat or base.

3. PRODUCT OVERVIEW

The Evenflo Revolve180 LiteMax NXT Accessory Base provides a convenient solution for families with multiple vehicles, allowing for easy transfer of compatible infant car seats. It features a robust design for secure installation.



Figure 3.1: Front view of the Evenflo Revolve180 LiteMax NXT Accessory Base. This image shows the overall design of the black car seat base, highlighting its compact form factor.



Figure 3.2: Angled view of the Evenflo Revolve180 LiteMax NXT Accessory Base. This perspective provides a clearer look at the base's contours and the 'Push to Rotate' button.



**LIGHTWEIGHT, PORTABLE
AND EASY TO USE**

Figure 3.3: The accessory base, emphasizing its lightweight and portable design. This feature facilitates easy transfer between vehicles.



COMPATIBLE WITH REVOLVE180™ LITEMAX™
NXT & LITEMAX™ NXT INFANT CAR SEATS

Not compatible with other LiteMax™ Infant Car Seats

Figure 3.4: The accessory base shown with a compatible Evenflo Revolve180 LiteMax NXT infant car seat attached, demonstrating its intended use.

Key Features:

- **Exclusive Compatibility:** Pairs only with Evenflo Revolve180 LiteMax NXT Rotational Infant Car Seat or LiteMax NXT Infant Car Seat.
- **LockStrong™ Belt Tensioning System:** Provides a secure and stable installation.
- **Installation Indicators:** Visual cues to confirm proper installation.
- **Lightweight and Portable:** Designed for easy transfer between vehicles.

4. SETUP AND INSTALLATION

Follow these steps for secure installation of the accessory base in your vehicle. Always ensure your vehicle is parked on a level surface.

1. **Position the Base:** Place the accessory base on the vehicle seat in the desired rear-facing position. Ensure it sits flat against the vehicle seat back and cushion.
2. **Engage LockStrong™ System:** Route the vehicle's seat belt or LATCH connectors through the designated belt path on the base. Engage the LockStrong™ belt tensioning system to tighten the belt. This system is designed to provide a solid, secure installation.



SECOND BASE IDEAL FOR ON-THE-GO
FAMILIES WITH MULTIPLE VEHICLES

Figure 4.1: A person demonstrating the initial placement and installation of the accessory base into a vehicle's back seat.



LOCKSTRONG™ BELT TENSIONING SYSTEM FOR SECURE INSTALLATION

Figure 4.2: Close-up view of the LockStrong™ belt tensioning system, illustrating how the vehicle's seat belt is secured for a tight fit.

- 3. Check Indicators:** Verify that the installation indicators on the base show a 'green' or 'secure' status. These indicators provide visual confirmation of proper installation. If the indicator is not green, re-adjust the belt tension until it is.



INDICATORS GUIDE PROPER INSTALLATION

Figure 4.3: A close-up of the installation indicator, which changes color (e.g., to green) to confirm a secure installation.

- 4. Test for Movement:** Once installed, firmly grasp the base at the belt path and attempt to move it side-to-side and front-to-back. The base should not move more than one inch (2.5 cm) in any direction.
- 5. Attach Infant Car Seat:** Refer to your Evenflo infant car seat manual for instructions on how to properly attach and secure the car seat to the installed accessory base.

5. OPERATING THE ACCESSORY BASE

The accessory base is designed to simplify the transfer of your compatible Evenflo infant car seat between vehicles.

- **Attaching the Car Seat:** Align the infant car seat with the base and firmly press down until you hear an audible click, indicating it is securely latched. Always check the car seat's indicators (if applicable) to confirm proper attachment.
- **Detaching the Car Seat:** Locate the car seat release handle or button (typically on the car seat itself) and activate it while lifting the car seat upwards from the base.
- **Vehicle Swapping:** With an accessory base installed in each vehicle, you can quickly and easily move your infant car seat from one car to another without needing to reinstall the base each time.

6. MAINTENANCE

Proper maintenance ensures the longevity and safety of your accessory base.

- **Cleaning:** Clean the plastic parts of the base with mild soap and water. Do not use abrasive cleaners or solvents. Allow to air dry completely.
- **Harness/Belt Cleaning:** If any part of the vehicle's seat belt or LATCH system used with the base becomes soiled, follow your vehicle's manual for cleaning instructions. Do not immerse the base in water.
- **Storage:** When not in use, store the base in a cool, dry place away from direct sunlight.
- **Inspection:** Periodically check all components for wear, damage, or loose parts. Ensure all labels are legible.

7. TROUBLESHOOTING

If you encounter issues with your Evenflo Revolve180 LiteMax NXT Accessory Base, consider the following:

- **Base Movement:** If the base moves more than one inch at the belt path, re-read the installation instructions carefully. Ensure the LockStrong™ system is fully engaged and the vehicle belt is tightened as much as possible. Check that the installation indicators are green.
- **Difficulty Attaching/Detaching Car Seat:** Ensure the car seat is correctly aligned with the base. Check for any obstructions. If the car seat is difficult to detach, ensure the release mechanism is fully activated.
- **Missing or Damaged Parts:** Do not use the base if any parts are missing or damaged. Contact Evenflo Consumer Care for assistance.

8. SPECIFICATIONS

Feature	Detail
Model Number	CS900610000C
Product Dimensions	22 x 15 x 8 inches (57 x 37.4 x 23.5 cm)
Item Weight	12.2 pounds
Minimum Weight Recommendation	3 Pounds
Maximum Weight Recommendation	30 Pounds
Material Type	100% Plastic
Orientation	Rear Facing
Installation Type	Latch / Vehicle Seat Belt



Figure 8.1: Diagram showing the key dimensions of the Evenflo Revolve180 LiteMax NXT Accessory Base for reference.

9. WARRANTY INFORMATION

For detailed warranty information regarding your Evenflo Revolve180 LiteMax NXT Accessory Base, please refer to the warranty card included with your product packaging or visit the official Evenflo website. Warranty terms and conditions may vary.

10. SUPPORT

Should you require further assistance or have questions not covered in this manual, please contact the Evenflo ParentLink® Consumer Care Team.

- **Online Support:** Visit the Evenflo official website for FAQs, product registration, and additional resources.
- **Live Video Support:** Evenflo offers live video support with certified car seat safety technicians to assist with proper vehicle installation. Check the Evenflo website for details on how to access this service.
- **Contact Information:** Refer to your product packaging or the Evenflo website for current phone numbers and email contact options.