

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [HotHands](#) /

› [HotHands Rechargeable Hand Warmers Instruction Manual H163650](#)

## HotHands H163650

# HotHands Rechargeable Hand Warmers

Model: H163650

## 1. INTRODUCTION

---

Thank you for choosing HotHands Rechargeable Hand Warmers. This manual provides essential information for the safe and effective use of your new hand warmers. Please read it thoroughly before operation and retain it for future reference.

### Package Contents:

- 2 x HotHands Rechargeable Hand Warmers
- 1 x 2-in-1 Charging Cable
- 2 x Wrist Lanyards
- 1 x User Manual (this document)
- 1 x Warranty Card

# HOTHANDS®

## RECHARGEABLE HAND WARMERS

Model: H163650

### CONTENTS:



2\* Hand Warmers



1\* 2-in-1 Charging Cable



2\* Wrist Lanyards



1\* User Manual



1\* Warranty Card

### **⚠️ WARNING**

Before use, read the instructions and warnings in the enclosed User Manual. Failure to follow the warnings and use instructions could result in serious injuries from electric shock, burns, or fire.

### **⚠️ WARNING**

This product can potentially expose you to chemicals including lead, nickel and chromium which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov)

\*1 Compared to air-activated hand warmers.

\*2 Under test environment with low temperature setting.

 **KOBAYASHI** Consumer Products, LLC  
P.O. Box 1191, Dalton, GA 30722

Consumer comments call: 1-800-432-8629  
[HotHands.com](http://HotHands.com)

MADE IN CHINA 23123.000

Share your feedback at:  
[feedback.HotHands.com](http://feedback.HotHands.com) for a chance to win an assortment of Kobayashi products.



Figure 1: Back of product packaging illustrating included items and important warnings.

The HotHands Rechargeable Hand Warmers are designed to provide quick, long-lasting, and adjustable heat for your hands. They feature three temperature settings and can provide warmth for up to 8 hours on the lowest setting. Their lightweight and compact design makes them suitable for various activities.

## 2. SAFETY INFORMATION

**WARNING: Failure to follow these instructions and warnings could result in serious injuries from electric shock, burns, or fire.**

- Read all instructions and warnings in this manual before use.
- Do not expose the hand warmers to extreme temperatures or direct sunlight.
- Do not puncture, disassemble, or modify the device.
- Keep out of reach of children and pets.
- Do not use if the device is damaged or malfunctioning.
- Use only the provided charging cable or a certified equivalent.
- This product contains chemicals, including lead, nickel, and chromium, known to the State of California to cause cancer and birth defects or other reproductive harm. For more information, visit [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).

### 3. SETUP

---

#### Charging the Hand Warmers:

1. Locate the charging port on each hand warmer.
2. Connect the provided 2-in-1 charging cable to both hand warmers.
3. Plug the USB end of the cable into a compatible USB power adapter (not included) or a computer USB port.
4. The indicator lights on the hand warmers will illuminate during charging. A full recharge takes approximately 3.5 hours.
5. Once fully charged, disconnect the hand warmers from the charging cable.

# ULTRA THIN ULTRA LIGHT

Thickness 3/4"

Weight 2.3 oz.

Thin, light and ideal for  
pocket and gloves



Figure 2: Hand warmer with the charging port visible.

## Attaching Wrist Lanyards:

Thread the provided wrist lanyards through the designated loop on each hand warmer for added security and convenience.

## 4. OPERATING INSTRUCTIONS

---

### Turning On/Off:

- To turn on: Press and hold the power button for a few seconds until the indicator lights illuminate. The hand warmer will start on the lowest heat setting.
- To turn off: Press and hold the power button for a few seconds until the indicator lights turn off.

## Adjusting Heat Settings:

The hand warmers feature three adjustable heat settings. Once the device is on, short press the power button to cycle through the settings:

- **Low (1 LED light):** Approximately 100-108°F (38-42°C), lasting up to 8 hours.
- **Medium (2 LED lights):** Approximately 109-117°F (43-47°C), lasting up to 6 hours.
- **High (3 LED lights):** Approximately 118-125°F (48-52°C), lasting up to 4 hours.

**NEW! FROM**  
**HOT HANDS**

**FAST, LONG-LASTING,  
ADJUSTABLE HEAT**

**Three adjustable temperature settings**

- 100 - 108 ° F | Up to 8-Hours
- 109 - 117 ° F | Up to 6-Hours
- 118 - 125 ° F | Up to 4-Hours

**Up to 8-Hours of comfortable heat**

The image shows a hand warmer device with three red LED indicators on top. A yellow arrow points to the top of the device, and another yellow arrow points to the orange heating area. The text 'Up to 8-Hours of comfortable heat' is positioned next to the second arrow.

Figure 3: Hand warmer displaying the three heat settings via LED indicators.

The hand warmers heat up quickly, providing warmth within seconds of activation.

## 5. MAINTENANCE

- **Cleaning:** Wipe the surface of the hand warmers with a soft, dry cloth. Do not use abrasive cleaners or immerse in water.

- **Storage:** Store the hand warmers in a cool, dry place when not in use. Ensure they are fully charged before long-term storage to maintain battery health.
- **Battery Care:** To prolong battery life, avoid completely draining the battery frequently. Recharge when the battery is low.

## 6. TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Hand warmer not turning on	Low battery; Incorrect operation	Charge the hand warmer; Press and hold the power button for several seconds.
Hand warmer not heating	Low battery; Device malfunction	Charge the hand warmer; If problem persists, contact customer support.
Charging not working	Cable not connected properly; Faulty cable/adaptor	Ensure cable is securely connected; Try a different USB port or adaptor.

If you encounter issues not listed here or if problems persist, please contact HotHands Customer Support.

## 7. SPECIFICATIONS

---

Feature	Detail
Model Name	HotHands Rechargeable Hand Warmer
Part Number	H163650
Brand	HotHands
Manufacturer	Kobayashi
Power Source	Battery Powered (Lithium-Polymer)
Charging Time	Approximately 3.5 Hours
Heat Settings	3 (Low, Medium, High)
Max Heat Duration	Up to 8 hours (on low setting)
Material	Plastic
Color	Orange
Item Weight	0.44 Pounds (approx. 200g)
Item Dimensions (LxWxH)	1.9 x 4.2 x 5.7 inches (approx. 4.8 x 10.7 x 14.5 cm)
Certifications	UL Certified

## 8. WARRANTY AND SUPPORT

---

**Warranty Information:**

HotHands Rechargeable Hand Warmers come with a 1-year limited warranty from the date of purchase. Please refer to the enclosed Warranty Card for full terms and conditions.

### Customer Support:

For any questions, concerns, or support needs, please contact HotHands Customer Service:

- **Phone:** 1-800-432-8629
- **Website:** [HotHands.com](https://HotHands.com)
- **Feedback:** [feedback.HotHands.com](https://feedback.HotHands.com)