

POSEIDON Wireless Tattoo Pen Kit B0F249Y6WZ

POSEIDON Wireless Tattoo Pen Kit Instruction Manual

Model: B0F249Y6WZ

INTRODUCTION

This manual provides comprehensive instructions for the safe and effective use of your POSEIDON Wireless Tattoo Pen Kit. Please read all instructions carefully before operation to ensure proper setup, usage, and maintenance.

PACKAGE CONTENTS

Your POSEIDON Tattoo Pen Kit includes the following items:

- 1 x Tattoo Pen
- 2 x Rechargeable Batteries (1500mAh each)
- 20 x Assorted Tattoo Cartridge Needles (1205RL×5, 1207RL×5, 1209RS×5, 1207RM×5)
- 1 x Self-Cohesive Grip Cover
- 1 x Type-C Charging Cable
- 40 x Ink Cups
- 2 x Practice Skin (3mm thickened)
- 2 x Transfer Papers
- 10 x 5ml Color Inks
- 1 x 30ml Black Ink
- 1 x Pair of Gloves
- 4 x Table Mats
- Tattoo Stickers

POSEIDON Tattoo Pen Kit

POSEIDON

High Quality Motor

MORE POWERFUL

QUIETER

VIBRATES LESS

Working Voltage

5-12V

Stroke Length

3.5MM

Speed

8V10000RPM

Image: Overview of the POSEIDON Wireless Tattoo Pen Kit components.

SETUP

1. Charging the Batteries

Before initial use, fully charge both 1500mAh batteries using the provided Type-C charging cable. A full charge typically takes 2 hours with a 1A+ charger. Each battery provides 4-6 hours of operation depending on the voltage used.

PORTABLE TATTOO BATTERY X2



Battery Capacity: 1500mAh
Charging Method: Type-C



4V-12V

Output Voltage

DC 5V/1A

Input Voltage

2h (1A+ charger)

Charging Time

4-6h(8V)

Operating Time

62g

Image: Two portable tattoo batteries with their specifications and charging method.

TATTOO INK



Image: Detailed illustration of the dual battery system, highlighting capacity, charging, and operating times.

2. Attaching the Battery to the Pen

Align the battery pack with the top of the tattoo pen. Gently twist to secure the battery to the pen. Ensure a firm connection for stable power delivery.



Image: Close-up of the wireless battery being connected to the tattoo pen, showing the RCA connection.

3. Inserting a Cartridge Needle

Select the desired sterilized cartridge needle. Carefully push the needle into the front opening of the tattoo pen until it clicks securely into place. Ensure the needle is fully seated to prevent movement during operation.



Image: A selection of assorted tattoo cartridge needles, including 1205RL, 1207RL, 1209RS, and 1207RM types.



OPERATING INSTRUCTIONS

1. Power On/Off and Voltage Adjustment

Press and hold the power button on the battery pack to turn the pen on or off. Use the '+' and '-' buttons to adjust the voltage. The pen features 9 adjustable voltage levels, ranging from 4V to 12V. The current voltage will be displayed on the battery screen.



Image: Specifications of the tattoo pen, including working voltage (5-12V), stroke length (3.5mm), and speed (8V 10000RPM).

2. Practice Usage

For beginners, it is highly recommended to practice on the provided thickened practice skin before tattooing on human skin. This allows you to familiarize yourself with the pen's operation, needle depth, and ink flow. Use the included color inks for practice.



11 INK BOTTLES

Meeting every color requirement
for vibrant creations

Image: A set of 11 ink bottles, including 10 color inks and 1 black ink, suitable for practice.

DOUBLE BATTERY POWER



Battery Capacity: 1500mAh



Full Charge Time: 2h (1A+ charger)



Operating Time: 4-6h (8V)

Equipped with two wireless batteries
it delivers double the runtime
for uninterrupted tattoo creation



Image: Display of tattoo ink bottles alongside ink cups.

3. Video Demonstration

Watch this video for a visual guide on setting up and operating your POSEIDON Tattoo Pen Kit.

Your browser does not support the video tag.

Video: A demonstration of the POSEIDON Tattoo Pen Kit, showing assembly and basic operation.

MAINTENANCE

1. Cleaning the Tattoo Pen

After each use, disconnect the battery and carefully wipe down the exterior of the tattoo pen with a sterile wipe or a cloth dampened with a suitable disinfectant solution. Ensure no liquids enter the internal components. Do not submerge the pen in water or cleaning solutions.

2. Needle Disposal

Always dispose of used cartridge needles in a designated sharps container immediately after use. Needles are single-use and sterilized with EO gas for safety; never reuse them.

3. Battery Care

Store batteries in a cool, dry place away from direct sunlight. Avoid overcharging or completely draining the batteries to prolong their lifespan. If not used for an extended period, charge them periodically to maintain battery health.

TROUBLESHOOTING

- **Pen Not Turning On:** Ensure the battery is fully charged and securely attached. Check if the power button is pressed and held correctly.
- **Needle Not Moving:** Verify that the cartridge needle is properly inserted and clicked into place. Check the voltage setting; increase if necessary.
- **Battery Not Charging:** Confirm the Type-C cable is correctly connected to both the battery and a working power source. Try a different charging cable or adapter if available.
- **Excessive Vibration/Noise:** Ensure all components are securely assembled. If the issue persists, contact customer support.

SPECIFICATIONS

Feature	Specification
Model	Wireless Tattoo Pen Kit (ASIN: B0F249Y6WZ)
Brand	POSEIDON
Battery Capacity	2 x 1500mAh Lithium Polymer
Output Voltage	4V-12V (9 adjustable levels)
Charging Time	Approx. 2 hours (with 1A+ charger)
Operating Time	4-6 hours per battery (at 8V)

Stroke Length	3.5mm
Speed	10000 RPM (at 8V)
Needle Types Included	1205RL, 1207RL, 1209RS, 1207RM
Package Dimensions	8.46 x 7.76 x 3.9 inches
Weight	2.34 Pounds
UPC	765569744375
GTIN	765569744375

WARRANTY AND SUPPORT

POSEIDON stands behind its products. If you encounter any issues or are not completely satisfied with your purchase, please contact customer support for assistance. We offer a no-hassle refund or replacement. For support, please refer to the contact information provided with your purchase or visit the official POSEIDON store on Amazon: [POSEIDON Store](#).