

[Manuals.plus](#) /

> [Yeabomy](#) /

> Yeabomy Smart Bluetooth Glasses E13C User Manual

Yeabomy E13C

Yeabomy Smart Bluetooth Glasses E13C User Manual

Model: E13C

1. INTRODUCTION

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your Yeabomy Smart Bluetooth Glasses E13C. Please read this manual thoroughly before using the product to ensure proper function and longevity.



A pair of black smart Bluetooth sunglasses, viewed from an angle, showcasing the integrated technology in the temples.

2. PRODUCT OVERVIEW

2.1 Package Contents

Verify that all items are present in the package:

- Smart Bluetooth Glasses (E13C)
- Magnetic Charging Cable
- Cleaning Cloth
- Eyeglasses Storage Bag
- Glasses Case
- User Manual (this document)

What You Will Get?



1. Glasses case

4. Cleaning cloth

2. Eyeglasses storage bag

5. Instruction manual

3. Audio bluetooth glasses

6. Magnetic charging cable

An image displaying the package contents: a glasses case, an eyeglasses storage bag, the audio Bluetooth glasses, a cleaning cloth, an instruction manual, and a magnetic charging cable.

2.2 Key Features

- **Intelligent Voice Control:** Operate functions using voice commands.
- **Polarized Lenses:** Effective blue light filtering and 100% UV protection. Lenses are replaceable with

prescription lenses.

- **Wide Compatibility:** Connects with various devices including smartphones (Android, iOS) and computers via Bluetooth 5.4.
- **One-Step Pairing:** Automatic reconnection to the last paired device.
- **Waterproof (IPX5):** Resistant to sweat and rain.
- **Lightweight Design:** Weighs approximately 27g for comfortable extended wear.
- **Dual Magnetic Charging:** Efficient and secure charging.
- **Intuitive Touch Controls:** For media playback, calls, and voice assistant activation.

3. SETUP

3.1 Charging the Glasses

Before first use, fully charge the smart glasses. Use the provided magnetic charging cable.


1. Connect the magnetic charging cable to the charging contacts on the temple of the glasses.
2. Connect the USB end of the cable to a standard USB power adapter (not included) or a computer's USB port.
3. The indicator light will show yellow during charging.
4. Charging is complete when the indicator light turns green. A full charge takes approximately 1.5 hours.

The glasses provide approximately 4-6 hours of media playback and over 300 hours of standby time on a full charge.

Dual Magnetic Charging Delivers Greater Efficiency

Powerful magnetic adsorption, secure and stable; long-lasting battery life

80 mAh Battery capacity	1.5 h Charging time	5 h Continuous Playback Time (Music)	4 h continuous Calling Time
-----------------------------------	-------------------------------	--	--



Precise Magnetic Suction, Fast Charging

Yellow light: Charging

Green light: Charging completed

An illustration showing the magnetic charging cable connecting to the glasses' temple, with indicators for charging (yellow light) and fully charged (green light). Battery capacity, charging time, playback time, and calling time are also displayed.

3.2 Bluetooth Pairing

To connect your smart glasses to a device:

1. Ensure the glasses are charged and powered on.
2. Enable Bluetooth on your smartphone or other device.
3. Search for available Bluetooth devices. The glasses will appear as "E13".
4. Select "E13" to pair. Once paired, the glasses will automatically reconnect to this device when powered on and within range (up to 33 feet).

Under Bluetooth 5.4 Transmission Range

Compatible with any devices has bluetooth function



A person wearing the smart glasses while running, with a smartphone screen showing Bluetooth settings and the glasses (E13) connected. The image highlights the 33ft Bluetooth 5.4 transmission range and voice control functionality.

4. OPERATING INSTRUCTIONS

4.1 Power On/Off

- **Power On:** Long touch the control area for 5 seconds.
- **Power Off:** Long touch the control area for 5 seconds.


4.2 Touch Controls


The smart glasses feature intuitive touch controls located on the temples:


- **Play/Pause Music:** Once-Tap
- **Next Track:** Twice-Tap
- **Previous Track:** Twice-Tap
- **Answer Call:** Once-Tap
- **Hang Up Call:** Once-Tap
- **Activate Voice Assistant:** Long Touch for 2 seconds
- **Remote Photography:** Double click to control your smartphone's camera.

Smart Touch Control

One touch stimulation

 Pick up phone call

 Turn on the music

 Open navigation

 Take photos



Previous Track
Twice-Tap



Next Track
Twice-Tap



Play/ Pause
Once-Tap



Voice Assistant
Long Touch 2 Second



Double click on
remote photography



Answer Call
Once-Tap



Hang Up
Once-Tap



Long Touch
5 seconds
Power on/off

A diagram illustrating the touch control gestures on the smart glasses for various functions: pick up calls, turn on music, open navigation, take photos, previous/next track, play/pause, voice assistant, answer/hang up calls, and power on/off.

4.3 Voice Control

After activating the voice assistant (Long Touch for 2 seconds), you can use voice commands for various functions, such as:

- Making calls (e.g., "Call [Contact Name]")
- Playing music (e.g., "Play [Song Title]")
- Sending messages
- Opening navigation

5. MAINTENANCE

- **Cleaning:** Use the provided cleaning cloth to gently wipe the lenses and frame. Avoid harsh chemicals or abrasive materials.
- **Water Resistance:** The glasses are IPX5 water-resistant, meaning they can withstand sweat and light rain. Do not submerge them in water or expose them to strong jets of water.

- **Storage:** When not in use, store the glasses in the provided eyeglasses storage bag or glasses case to protect them from scratches and dust.
- **Temperature:** Avoid exposing the glasses to extreme temperatures (hot or cold) as this can affect battery life and electronic components.

Long Term Wearing is Not Tiring

With a self weight of only 27g, it seems to be lightweight and comfortable to wear, if not available



A pair of smart glasses resting on a surface, emphasizing their lightweight design (27g) and comfort for extended wear. A magnified inset shows the dual magnetic charging contacts.

6. TROUBLESHOOTING

- **Cannot Power On:** Ensure the glasses are fully charged. Connect to the magnetic charging cable and check the indicator light.
- **Cannot Pair with Device:**
 - a. Ensure Bluetooth is enabled on your device.
 - b. Make sure the glasses are within the 33-foot Bluetooth range.
 - c. Turn the glasses off and on again, then try pairing.
 - d. Forget the device from your phone's Bluetooth settings and try pairing again.

- **No Sound/Low Volume:**

- a. Check the volume settings on both the glasses (if applicable via touch control) and your connected device.
- b. Ensure the glasses are properly connected via Bluetooth.
- c. Confirm that the audio output on your device is set to the smart glasses.

- **Touch Controls Not Responding:** Ensure the glasses are powered on and connected. Try restarting the glasses.

7. SPECIFICATIONS

Model	E13C
Brand	Yeabomy
Connectivity Technology	Bluetooth 5.4
Operating System Compatibility	Android, iOS Devices
Special Features	Music Player, Phone Call, Voice Control, UV Protection, Polarized Lenses, Remote Photography
Battery Capacity	1 Amp Hours (80mAh per temple)
Charging Time	Approx. 1.5 hours
Continuous Playback Time (Music)	Approx. 5 hours
Continuous Calling Time	Approx. 4 hours
Standby Time	Over 300 hours
Item Weight	0.07 pounds (approx. 27g)
Water Resistance	IPX5
Package Dimensions	6.65 x 2.4 x 2.24 inches
Screen Size	1.96 Inches (Visible screen diagonal)
Memory Storage Capacity	128 MB
GPS	No GPS

Product Information

Size



Suitable for all face shapes



Oval



Triangle



Round



Square



Diamond

An image detailing the physical dimensions of the smart glasses, including lens width, frame width, and temple length. It also shows various face shapes (oval, triangle, round, square, diamond) indicating suitability.

8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase documentation or visit the official Yeabomy website. Keep your proof of purchase for any warranty claims.